
DPS8M: GE™ / Honeywell™ / Bull™ 6000-series & DPS-8/M simulator

DPS8M X3.1.0: Omnibus Documentation

The DPS8M Development Team and contributors



DPS8M X3.1.0: 2025-05-15 01:17:54 UTC

DPS8M Omnibus Documentation

- **Version** `git_f0d311a99c630e4d7d067d16000b62ddca81fefc`
- **Updated** 2025-05-15 01:17:54 UTC

Version Information

- This documentation is intended for use with the following software:
 - **DPS8M** **X3.1.0+1**
 - **tap2raw** **1.1.1**
 - **prt2pdf** **3.0.3**
 - **punutil** **0.2**

Contents

DPS8M Omnibus Documentation	i
Version Information	i
DPS8M Authors and Contributors	1
The DPS8M Development Team	1
Introduction	3
About this manual	3
What is DPS8M?	4
GE/Honeywell/Bull DPS-8/M Processor	4
Processor characteristics	4
Functional organization	5
Appending unit	5
Associative memory assembly	5
Control unit	5
Operation unit	5
Decimal unit	5
Modes of operation	6
Native data sizes	6
Interrupt handling	6
Fault handling	6
Instruction repertoire	7
Registers	7
The DPS8M Simulator	8
Simulator overview	8
Security	8
Supported components	9
Unsupported components	9
Obtaining the simulator	11
Binary distributions	11
Source code distributions	12
Source kits	12
Git repository	12
Git cloning	12
Git mirroring	12
Compiling from source	13
General Information	13
FreeBSD	14
FreeBSD prerequisites	14
Standard FreeBSD compilation	14
Optimized FreeBSD compilation	14
blinkerLights2 on FreeBSD	14
Additional FreeBSD Notes	15

NetBSD	15
NetBSD prerequisites	15
Standard NetBSD compilation	15
Optimized NetBSD compilation	16
Compilation using Clang	16
blinkenLights2 on NetBSD	16
OpenBSD	17
OpenBSD prerequisites	17
Standard OpenBSD compilation	17
Optimized OpenBSD compilation	17
Compilation using Clang	18
Additional OpenBSD Notes	18
DragonFly BSD	18
DragonFly BSD prerequisites	18
Standard DragonFly BSD compilation	19
Optimized DragonFly BSD compilation	19
Compiling using Clang	19
Solaris	19
Solaris prerequisites	20
Solaris compilation	20
GCC	20
Clang	20
Oracle Developer Studio	21
OpenIndiana	21
OpenIndiana prerequisites	21
Standard OpenIndiana compilation	21
Compiling using Clang	21
AIX	22
Recommended compilers	22
Other supported compilers	22
AIX prerequisites	23
Libraries and tools	23
GNU C compilers	23
Clang compilers	23
IBM compiler support	23
AIX compilation	23
IBM Open XL C/C++ for AIX	23
Clang	24
IBM XL C/C++ for AIX	25
GCC	25
Haiku	25
Haiku prerequisites	26
Standard Haiku compilation	26
Compiling using Clang	26
Additional Haiku Notes	26
Linux	26
Linux compilers	27
Linux prerequisites	27
Standard Linux compilation	28
Alternative Linux compilation	28
Clang	28

Intel oneAPI DPC++/C++	28
AMD Optimizing C/C++	28
AOCC with AMD Optimized CPU Libraries	29
Oracle Developer Studio	29
IBM Open XL C/C++ for Linux	29
IBM XL C/C++ for Linux	29
NVIDIA HPC SDK C Compiler	30
Arm HPC C/C++ Compiler for Linux	30
ACFL with Arm Performance Libraries	30
Linux cross-compilation	31
IBM Advance Toolchain	31
Arm GNU Toolchain	31
Linux/ARMv7-HF	31
Linux/ARM64	32
Linux/ARM64BE	32
Linaro GNU Toolchain	32
Linux/ARMv7-HF	32
Linux/ARM64	33
crosstool-NG	33
Linux/RV64	33
Linux/i686	33
Linux/ARMv6-HF	34
Linux/PPC64le	34
Additional Linux Notes	34
macOS	35
macOS prerequisites	35
macOS compilation	35
macOS cross-compilation	35
ARM64	36
Intel	36
Universal	36
Windows	37
Cygwin	38
Cygwin prerequisites	38
Standard Cygwin compilation	38
Cygwin-hosted cross-compilation to MinGW	39
Windows i686	39
Windows x86_64	39
MSYS2	40
Unix-hosted LLVM-MinGW Clang cross-compilation	40
Windows i686	40
Windows x86_64	41
Windows ARM64	41
Unix-hosted MinGW-w64 GCC cross-compilation	41
Windows i686	42
Windows x86_64	42
Simulator Command Reference	43
!	43
Executing System Commands	43
ASSERT	43

ATTACH (AT)	44
Switches	44
-n	44
-e	44
-r	44
-q	44
-f	44
AUTOINPUT (AI)	45
AUTOINPUT2 (AI2)	45
BOOT (BO)	46
BURST	46
CABLE (C)	46
UNCABLE (U)	47
CABLE_RIPOUT	48
CABLE_SHOW	48
CABLE DUMP	50
CABLE GRAPH	50
Complete Cabling Graph	51
CPU / SCU / IOM Cabling Graph	52
Storage Cabling Graph	53
Controller Cabling Graph	54
CALL	54
CHECKPOLL	55
CLRAUTOINPUT	55
CLRAUTOINPUT2	55
CONTINUE (CO)	55
DEFAULT_BASE_SYSTEM	55
DETACH (DET)	55
DO	56
Switches	56
-v	56
-e	56
-o	56
-q	56
ECHO	56
EVALUATE	56
EXIT (QUIT, BYE)	57
FNPSEVERADDRESS	57
FNPSEVERPORT	57
FNPSTART	57
GO	58
GOTO	58
IF	58
Conditional Expressions	58
Simulator State Expressions	59
String Comparison Expressions	59
LOAD (UNLOAD)	60
LUF (NOLUF)	60
MOUNT	60
NEXT (N)	60
ON	60

POLL	60
PROCEED (IGNORE)	60
READY	61
RESET	61
RETURN	61
REWIND	62
RUN (RU)	62
SEGLDR	62
SET	62
Logging	62
Switches	63
-N	63
-B	63
Debug Messages	63
Switches	63
-T	63
-A	63
-R	63
-P	63
-N	63
-D	63
-E	63
Environment Variables	64
Command Status Trap Dispatching	64
Command Execution Display	64
Command Error Status Display	64
Command Output Display	64
Local Operator Console	64
Command Prompt	64
Device and Unit Settings	65
CPU Configuration	65
L68 (DPS8M)	65
RESET	65
INITIALIZE	66
INITIALIZEANDCLEAR (IAC)	66
NUNITS	66
KIPS	67
STALL	67
DEBUG (NODEBUG)	68
CONFIG	69
FAULTBASE	69
NUM	69
DATA	69
STOPNUM	70
MODE	70
SPEED	70
PORT	71
ASSIGNMENT	71
INTERLACE	71
ENABLE	72
INIT_ENABLE	72

STORE_SIZE	72
ENABLE_CACHE	72
SDWAM	73
PTWAM	73
DIS_ENABLE	73
STEADY_CLOCK	74
HALT_ON_UNIMPLEMENTED	74
ENABLE_WAM	74
REPORT_FAULTS	74
TRO_ENABLE	75
DRL_FATAL	75
USEMAP	75
ADDRESS	76
PROM_INSTALLED	76
HEX_MODE_INSTALLED	76
CACHE_INSTALLED	77
CLOCK_SLAVE_INSTALLED	77
ENABLE_EMCALL	77
ISOLTS_MODE	77
NODIS	78
L68_MODE	78
IOM Configuration	78
NUNITS	78
DEBUG (NODEBUG)	79
RESET	79
CONFIG	79
PORT	79
ADDR	79
INTERLACE	80
ENABLE	80
INITENABLE	80
HALFSIZE	80
STORE_SIZE	80
MODEL	80
OS	80
BOOT	81
IOM_BASE	81
MULTIPLEX_BASE	81
TAPECHAN	82
CARDCHAN	82
SCUPOINT	82
SCU Configuration	82
DEBUG (NODEBUG)	82
NUNITS	82
RESET	83
CONFIG	83
MODE	83
MASKA	83
MASKB	83
PORT0	83
PORT1	84

PORT2	84
PORT3	84
PORT4	84
PORT5	84
PORT6	84
PORT7	84
LWRSTORESIZE	84
CYCLIC	84
NEA	85
ONL	85
INT	85
LW	85
ELAPSED_DAYS	85
STEADY_CLOCK	85
BULLET_TIME	85
CLOCK_DELTA	85
TAPE Configuration	86
DEBUG (NODEBUG)	86
DEFAULT_PATH	86
ADD_PATH	87
CAPACITY_ALL	88
CAPACITY	88
REWIND	88
READY	88
NAME	88
NUNITS	89
MTP Configuration	89
DEBUG (NODEBUG)	89
NAME	89
NUNITS	89
BOOT_DRIVE	90
CONFIG	90
IPC Configuration	90
NAME	90
NUNITS	90
MSP Configuration	91
NAME	91
NUNITS	91
Disk Configuration	91
DEBUG (NODEBUG)	91
TYPE	91
READY	91
NAME	91
NUNITS	92
RDR Configuration	92
Submitting punched card decks to the card reader	92
Punched card formats	92
Punched card “card” format	92
Punched card “stream” format	93
Punched card “7punch” format	93
Punched card “xDeck” format	93

Punched card format determination	93
Punched card format / simulator interaction	93
Restarting the card reader device	93
Working with card decks	94
Using the punched card format “card” (‘cdeck.*’)	94
Using the punched card format “stream” (‘sdeck.*’)	94
Using the punched card format “7punch” (‘7deck.*’)	95
Using the punched card format “xDeck” (‘xdeck.*’)	95
DEBUG (NODEBUG)	95
PATH	95
NAME	96
NUNITS	96
PUN Configuration	97
Overview	97
Card format	97
DEBUG (NODEBUG)	98
PATH	98
NAME	98
NUNITS	98
CONFIG	99
LOGCARDS	99
PRT Configuration	99
DEBUG (NODEBUG)	99
PATH	100
MODEL	100
READY	100
NAME	100
NUNITS	100
CONFIG	101
SPLIT	101
FNP Configuration	101
DEBUG (NODEBUG)	101
NUNITS	101
CONFIG	102
MAILBOX	102
IPC_NAME	102
SERVICE	102
OPC Configuration	102
DEBUG (NODEBUG)	102
AUTOINPUT	103
NAME	103
NUNITS	103
CONFIG	103
AUTOACCEPT	103
NOEMPTY	104
ATTN_FLUSH	104
PORT	104
ADDRESS	104
PW	104
URP Configuration	104
DEBUG (NODEBUG)	104

NAME	104
NUNITS	105
SHIFT	105
SHOW	105
BUILDINFO (B)	105
CLOCKS (CL)	106
CONFIGURATION (C)	106
DEFAULT_BASE_SYSTEM (D)	107
DEVICES (DEV)	107
MODIFIERS (M)	107
ON (O)	107
PROM (P)	107
QUEUE (Q)	108
SHOW (S)	108
TIME (T)	108
VERSION (V)	108
CPU	109
CONFIG	109
NUNITS	110
KIPS	111
STALL	111
DEBUG	111
DISK	111
NAME	111
NUNITS	112
TYPE	112
DEBUG	112
FNP	112
CONFIG	112
IPC_NAME	113
NAME	113
NUNITS	113
SERVICE	113
STATUS	114
DEBUG	114
IOM	115
CONFIG	115
NUNITS	115
DEBUG	115
IPC	116
NAME	116
NUNITS	116
MSP	116
NAME	116
NUNITS	117
MTP	117
BOOT_DRIVE	117
NAME	117
NUNITS	117
DEBUG	118

OPC	118
CONFIG	118
ADDRESS	118
AUTOINPUT	118
NAME	119
NUNITS	119
PORT	119
PW	119
DEBUG	119
PRT	120
CONFIG	120
MODEL	120
NAME	120
NUNITS	120
PATH	121
DEBUG	121
PUN	121
CONFIG	121
NAME	121
NUNITS	122
PATH	122
DEBUG	122
RDR	122
NAME	122
NUNITS	123
PATH	123
DEBUG	123
SCU	123
CONFIG	123
NUNITS	124
STATE	124
DEBUG	125
TAPE	125
ADD_PATH	125
CAPACITY	125
DEFAULT_PATH	125
NAME	126
NUNITS	126
DEBUG	126
URP	126
NAME	126
NUNITS	127
DEBUG	127
SKIPBOOT	127
SLOWPOLL	127
STEP (S)	127
Step Execution	127
Switches	127
-T	127
Simulator Defaults	129
Default Base System Script	129

Default Base System Configuration	141
Default Base System Cable Dump	147
External Simulator Utilities	153
Multics Punched Card Utility — <code>punutil</code>	153
Multics Print File Utility — <code>prt2pdf</code>	154
Multics Tape Conversion Utility — <code>tap2raw</code>	155
Tips and Tricks	157
Protecting DPS8M in low-memory situations	157
Exempting DPS8M from the Linux OOM Killer	157
Automatic Linux <code>oom_adj</code> adjustment	158
Exempting DPS8M from FreeBSD OOM termination	158
Automatic FreeBSD OOM protection	159
Legal	161
DPS8M Omnibus Documentation Licensing Terms	161
DPS8M Omnibus Documentation-specific Content Licensing	161
General Attribution License (Documentation)	162
Multics License (Documentation)	163
General Attribution License (Multics Rings Logo)	164
BSD License (Eisvogel)	165
ISC License (Pagebreak)	166
SIL™ Open Font License 1.1 (Source™ Code Pro)	167
SIL™ Open Font License 1.1 (Source™ Sans Pro)	168
DPS8M Software Licensing Terms	169
DPS8M Simulator	169
ICU License (DPS8M Simulator)	169
Multics License (Simulator Code Comments)	170
Third-party Software	170
<code>libsir</code>	171
<code>libuv</code>	172
<code>UDPLib</code>	173
<code>Open SIMH</code>	174
<code>punutil</code>	175
<code>tap2raw</code>	176
<code>prt2pdf</code>	177
<code>decNumber</code>	178
<code>LibTELNET</code>	179
<code>Line History</code>	180
<code>BSD Random</code>	181
<code>musl libc</code>	182
<code>mcomb</code>	183
Multics Software Materials and Documentation	184
Scope of Intended Application	185
Disclaimer of Liability and Endorsement	185

DPS8M Authors and Contributors

The DPS8M Development Team

- **The DPS8M Development Team** is, in alphabetical order:
 - Dean S. Anderson,
 - Charles Anthony <charles.unix.pro@gmail.com>,
 - Jeffrey H. Johnson <trnsz@pobox.com>,
 - Jean-Michel Merliot,
 - Michael Mondy <michael.mondy@coffebird.net>,
 - Harry Reed,
 - Craig Ruff,
 - Eric Swenson <eric@swenson.org>,
 - M—— T——,
 - Björn Victor <bjorn@victor.se>,
 - Juergen Weiss <weiss@uni-mainz.de>,
 - M. Williams (OrangeSquid)
 - *and others ...*

Introduction

About this manual

This manual describes the **DPS8M Simulator**.

It is important to note that this manual does **not** provide documentation on **Multics**. It *only* documents the simulator.

This manual is intended for:

- anyone who wants to better understand the configuration and usage of the **DPS8M Simulator**, *especially*,
- Multics *System* and *Site Administrators* who wish to change the default configuration.

For detailed information about **Multics** itself, please see the following resources:

Multics Wiki	https://swenson.org/multics_wiki/	<i>Home of the Multics operating system</i>
Bitsavers	https://bitsavers.org/pdf/honeywell/	<i>Multics documentation (in PDF format)</i>
Multicians	https://multicians.org/	<i>Multics history</i>

What is DPS8M?

DPS8M is a simulator of the **36-bit** GE Large Systems / Honeywell / Bull 600/6000-series mainframe computers (Honeywell 6180, Honeywell Series-60 / Level-68, and Honeywell / Bull **DPS-8/M**) descended from the **GE-645** and engineered to support the **Multics** operating system.

GE/Honeywell/Bull DPS-8/M Processor

Processor characteristics

- Hardware-based enforcement of access restrictions
- Seven hierarchical protection rings (0 ... 7)
- Segmentation and paging
- 36- & 72-bit fixed-point integer, fixed-point fraction, and floating point arithmetic
- Big-endian word ordering
- Two's complement numeric representation
- Hexadecimal floating point (*HFP*) option (*range of ± 10 to the 153rd power*)
- Hardware rounding and normalization
- Content-addressable associative memory for intermediate storage of address and control information
- Address modification and appending
- Absolute address computation at execution time
- High-resolution asynchronous alarm timer (512 KHz; 1.953125 μ s *precision*)
- Direct memory access (*DMA*) I/O
- Multilevel fault and priority interrupt handling
- Deferred handling of low-priority faults
- Instruction and operand caching (*with selective clear and bypass*)

Functional organization

Appending unit

- Controls data input/output to main memory
- Interfaces with caches
- Performs main memory selection and interlace control
- Does address appending and virtual address translation
- Controls fault recognition

Associative memory assembly

- Provides register-based access to pointers to most recently used segments and pages
- Reduces the need for multiple memory accesses (before obtaining an absolute address of an operand or instruction)

Control unit

- Performs address modification
- Controls mode of operation
- Performs interrupt recognition
- Decodes instruction words and indirect words
- Performs timer register loading and decrementing

Operation unit

- Performs fixed- and floating-point binary (*base-2*) arithmetic
- Does shifting and boolean operations

Decimal unit

- Performs decimal (*base-10*) arithmetic
- Decimal number formatting (e.g. **COBOL** or **PL/I** “**PIC**”)
- Specialized character-string and bit-string operations (e.g. **PL/I** “**INDEX**”)

Modes of operation

- Three memory addressing modes
 - **absolute** mode
 - **append** mode
 - **BAR** mode
- Two instruction execution modes
 - **normal** mode
 - **privileged** mode

Native data sizes

- **36-bit** native word size
- **4-** and **6-bit** “character” sizes
- **9-bit** byte size
- **18-bit** half-word size
- **72-bit** double-word (*word pair*) size
- **15-bit** segment size (**32,768** segments)
- **18-bit** address size (**262,144** words per segment)

Interrupt handling

- **32** interrupt cells per **SCU**
 - interrupt cells are organized in a numbered priority chain

Fault handling

- **27** fault conditions (*expandable to 32*)
 - **32** fault priority levels
 - **7** fault priority groups

Instruction repertoire

- **547** instructions (*expandable to 1024*)
 - **456** basic instructions (*in 7 functional classes*)
 - * **181** fixed-point binary arithmetic instructions
 - * **85** boolean operation instructions
 - * **75** pointer register operation instructions
 - * **36** control flow instructions
 - * **34** floating-point binary arithmetic instructions
 - * **28** privileged instructions
 - * **17** miscellaneous instructions
 - **91** Extended Instruction Set (**EIS**) instructions
 - * **62** single-word and **29** multi-word instructions, *operating on:*
 - **4-**, **6-**, and **9-bit** alphanumeric strings,
 - **4-** and **9-bit** numeric strings, *and*
 - bit strings
 - * **21** opcodes for moving, comparison, scanning, conversion, and translation
 - * **20** opcodes for loading, storing, and modifying address pointers and lengths
 - * **17** “*micro-operations*” for control of string move and edit operations
 - * **8** opcodes for decimal arithmetic

Registers

- Two **36-bit** accumulator registers (**A & Q**)
- One **72-bit** accumulator-quotient register (**AQ**)
- Eight **18-bit** index registers (**X0 ... X7**)
- One **8-bit** exponent register (**E**)
- One **80-bit** exponent-accumulator-quotient register (**EAQ**)
- One **14-bit** indicator register (**IR**)
- One **18-bit** base address register (**BAR**)
- One **27-bit** timer register (**TR**)
- One **3-bit** ring alarm register (**RALR**)
- Eight **42-bit** pointer registers (**PR0 ... PR7**)
- Eight **24-bit** address registers (**AR0 ... AR7**)
- One **37-bit** procedure pointer register (**PPR**)
- One **42-bit** temporary pointer register (**TPR**)
- One **51-bit** descriptor segment base register (**DSBR**)
- One **35-bit** fault register (**FR**)
- One **33-bit** mode register (**MR**)
- One **28-bit** cache mode register (**CMR**)
- Sixteen **51-bit** page table word associative memory (**PTWAM**) registers
- Sixteen **108-bit** segment descriptor word associative memory (**SDWAM**) registers
- Sixteen **72-bit** control unit (**CU**) history registers
- Sixteen **72-bit** operations unit (**OU**) history registers
- Sixteen **72-bit** decimal unit (**DU**) history registers
- Sixteen **72-bit** appending unit (**APU**) history registers
- Five **36-bit** configuration switch data (**CSD**) registers
- One **288-bit** control unit data (**CUD**) register
- One **288-bit** decimal unit data (**DUD**) register

The DPS8M Simulator

Simulator overview

- **DPS8M** is **open source software** developed by **The DPS8M Development Team** and **many contributors**.
- **DPS8M** supports most operating systems conforming to *IEEE Std 1003.1-2008* (**POSIX.1-2008**), many C compilers conforming to *ISO/IEC 9899:2011* (**C11**), and numerous hardware architectures.
 - Operating systems supported are **IBM AIX**, **IBM i (OS/400)**, **QNX**, **FreeBSD**, **NetBSD**, **OpenBSD**, **DragonFly BSD**, **Haiku**, **Android**, **illumos (OpenIndiana)**, **Linux**, **macOS**, **Solaris**, **SerenityOS**, and **Windows** (both **Cygwin** and native).
 - C compilers supported are **Clang**, **LLVM-MinGW**, AMD Optimizing C/C++ (**AOCC**), Arm C/C++ Compiler (**ARMClang**), GNU C (**GCC**), IBM Advance Toolchain (**AT**), IBM XL C/C++ (**XLC**), IBM Open XL C/C++ (**IBMClang**), Intel oneAPI DPC++/C++ (**ICX**), NVIDIA HPC SDK C Compiler (**NVC**), Oracle Developer Studio (**SunCC**), and МЦСТ Эльбрус C Compiler (**LCC**).
 - Hardware architectures actively supported include **Intel x86** (i686, x86_64), **ARM** (ARMv6, ARMv7, ARM64), **LoongArch** (LA64), **MIPS** (MIPS, MIPS64), **OpenRISC** (OR1200, MOR1KX), **PowerPC** (PPC, PPC64, PPC64le), **RISC-V** (RV64), **SPARC** (SPARC, UltraSPARC), **E2K** (МЦСТ Эльбрус), **KVX** (Kalray MPPA®, Coolidge™), and **IBM Z** (s390x, z13+).
- Various releases of **DPS8M** have been ported to **embedded systems**, **cell phones**, **tablets**, **handheld gaming consoles**, **wireless routers**, and even modern **mainframes**. A full-featured port should be possible for any 32- or 64-bit platform (preferably with appropriate hardware atomic operations) and able to support ports of the **libuv** asynchronous I/O library and **libsir** logging library.
- The simulator is distributed as an **easy-to-build** source code **distribution** (buildable simply via **'make'** on most systems) or as ready-to-run **pre-compiled binaries** for several popular platforms.
- **DPS8M** development is hosted courtesy of **GitLab**, providing version control, issue tracking, and CI/CD services.

Security

- Static application security testing by:
 - **PVS-Studio** - A static analysis tool for code quality, security, and safety.
 - **Coverity® Scan** - Find and fix defects in Java, C/C++, C#, JavaScript, Ruby, or Python code.
 - **Oracle Developer Studio** - Performance, security, and thread analysis tools to help write higher quality code.
 - **Cppcheck** - A static analysis tool for C/C++ code.
 - **Clang Static Analyzer** - A source code analysis tool that finds bugs in C, C++, and Objective-C programs.
 - **Flawfinder** - Examine C/C++ source code for possible security weaknesses.

Supported components

DPS8M simulates not only the **DPS-8/M** CPU, but an *entire* Honeywell / Bull **Distributed Processing System** mainframe.

- {6×} Central Processing Units (**CPU**)
- {8×} Front-End Network Processors (**FNP**)
- {4×} System Control Units (**SCU**)
- {2×} Operator Consoles (**OPC**)
- {2×} Input/Output Multiplexers (**IOM**)
- {10×} Unit Record Processors (**URP**)
- Integrated Peripheral Controllers (**IPC**)
- Magnetic Tape Processors (**MTP**)
- Mass Storage Processors (**MSP**)
- Microprogrammed Peripheral Controllers (**MPC**)
- Socket Controllers (**SKC**)
- ABSI Interfaces
- Tape Drives
- Disk Storage Units
- Printers
- Card Readers
- Card Punches
- DIA cabling

Unsupported components

- Diagnostic Processor Unit (**DPU**)
- Chaosnet Interfaces (**MGP**)
- Information Multiplexer Units (**IMU**)
- Maintenance Channel Adapter (**MCA**)
- Remote Maintenance Interface (**RMI**)
- Multidrop Interfaces (**MDI**)
- New System Architecture Extensions (**VU**)
- DPS-6 (*Level-6*) Satellite Processors
- DIA Port Expanders

Obtaining the simulator

Official releases of the simulator are available from:

The DPS8M Simulator Homepage	https://dps8m.gitlab.io/	<i>Binary distributions and source kits</i>
-------------------------------------	---	---

GitLab DPS8M <code>git</code> Repository	https://gitlab.com/dps8m/dps8m/	<i>Developmental source code</i>
---	---	----------------------------------

Binary distributions

- **The DPS8M Simulator Homepage** offers **binary releases** for several popular operating systems, including:
 - **AIX**
 - **Linux**
 - **macOS**
 - **FreeBSD**
 - **NetBSD**
 - **Windows**
 - **Solaris**
 - **illumos**
 - **Haiku**
 - *and others ...*
- Executables are provided for many hardware architectures, including:
 - **x86 / ix86**
 - **x86_64 / AMD64**
 - **ARM** (e.g. Raspberry Pi, Pine64, Orange Pi ...)
 - **ARM64 / AArch64** (e.g. Apple M, Fujitsu A64FX, Ampere AmpereOne, Arm Neoverse ...)
 - **POWER** (e.g. IBM Power Systems, Raptor Talos™, Freescale PowerPC ...)
 - **RISC-V** (e.g. SiFive HiFive, AndesCore™ V5 ...)
 - **МЦСТ Эльбрус**
 - *and others ...*

NOTE: Other operating systems and hardware architectures are supported when building the from source code.

Source code distributions

Source kits

The **DPS8M Simulator Homepage** offers downloadable **source kit distributions** for released versions of the simulator, bleeding edge snapshots, and historical releases.

- The **DPS8M Development Team** recommends most new users who wish to build from source code download a source kit distribution from the **DPS8M Releases** section of **The DPS8M Simulator Homepage**.
- Advanced users and developers may wish to clone the **git repository** and work with the 'master' branch.

Git repository

DPS8M development is coordinated using the **git** distributed version control system, hosted courtesy of *GitLab*, providing project management tools, wiki and web hosting, issue tracking, and CI/CD (*continuous integration/continuous delivery*) services.

Most development takes place on branches of the **git repository**, which are merged into the 'master' branch after GitLab CI/CD verification and other manual testing. Simulator releases are cut from the 'master' branch. The head of the **git** 'master' branch is the version of the simulator used by most of the development team, and *should* be stable enough for daily usage, although regressions and new bugs may be encountered periodically.

Git cloning

- Anyone may clone the repository via **HTTPS**:

```
git clone --recursive https://gitlab.com/dps8m/dps8m.git
```

- Users with a *GitLab* account may clone the repository via **SSH**:

```
git clone --recursive git@gitlab.com:/dps8m/dps8m.git
```

- After cloning the repository, it can be updated by executing the following command from the cloned repository directory:

```
git pull
```

Git mirroring

Users who wish to **mirror** the **git repository** for backup or archival purposes (*i.e.* copying **all** remote-tracking branches, tags, notes, references, etc.) should use the mirroring functionality of **git**.

- Anyone may mirror the repository via **HTTPS**:

```
git clone --recursive --mirror https://gitlab.com/dps8m/dps8m.git
```

- Users with a *GitLab* account may mirror the repository via **SSH**:

```
git clone --recursive --mirror git@gitlab.com:/dps8m/dps8m.git
```

- After mirroring the repository, it can be updated (including removing local branches when they are removed upstream) by executing the following command from the mirrored repository directory:

```
git remote update --prune
```

Compiling from source

The simulator is distributed in various forms, including an easy-to-build **source code distribution**, which can be built simply via **make** on *most* systems.

General Information

- Expert users may wish to build the simulator from source code to enable experimental features, or for reasons of performance and compatibility.
 - Building on a **64-bit** platform is **strongly encouraged for optimal performance**.
 - **The DPS8M Development Team** recommends most users download a **source kit distribution**.
 - A source kit requires approximately **20 MiB** of storage space to decompress and **40 MiB** to build.
 - Advanced users may prefer to clone the **git repository** which contains additional tools not required for simulator operation, but useful to developers.
 - The **git repository** requires approximately **275 MiB** of storage space to clone and **300 MiB** to build.
-

FreeBSD

- Ensure you are running a supported release of **FreeBSD** on a supported platform.
 - The current release versions of **FreeBSD/amd64** and **FreeBSD/arm64** are regularly tested by **The DPS8M Development Team**.

FreeBSD prerequisites

Install the required prerequisites (using FreeBSD Packages or Ports):

- Using FreeBSD Packages (as *root*):

```
pkg install gmake libuv
```

- Using FreeBSD Ports (as *root*):

```
cd /usr/ports/devel/gmake/ && make install clean
cd /usr/ports/devel/libuv/ && make install clean
```

Standard FreeBSD compilation

- Build the simulator (*standard build*) from the top-level source directory (using **GNU Make**):

```
gmake
```

Optimized FreeBSD compilation

- **FreeBSD** provides the **Clang** compiler as part of the base system. While *sufficient* to build the simulator, we recommend that version 12 or later of the **GNU C (gcc)** compiler be used for optimal performance.
- At the time of writing, **GCC 14.2** is available for **FreeBSD** systems and is the version of GCC currently recommended by **The DPS8M Development Team**.

It can be installed via FreeBSD Packages or Ports:

- Using FreeBSD Packages (as *root*):

```
pkg install gcc14
```

- Using FreeBSD Ports (as *root*):

```
cd /usr/ports/lang/gcc14/ && make install clean
```

- Build the simulator from the top-level source directory (using **GNU Make**):

```
env CC="gcc14" LDFLAGS="-Wl,-rpath=/usr/local/lib/gcc14" gmake
```

blinkerLights2 on FreeBSD

- To build the **blinkerLights2** front-panel display, install its prerequisites via FreeBSD Packages or Ports:
 - Using FreeBSD Packages (as *root*):

```
pkg install pkgconf gtk3
```

- Using FreeBSD Ports (as *root*):

```
cd /usr/ports/devel/pkgconf/ && make install clean
cd /usr/ports/x11-toolkits/gtk30/ && make install clean
```

- Build **blinkenLights2** from the top-level source directory (using **GNU Make**):

```
gmake blinkenLights2
```

Additional FreeBSD Notes

- When running on **FreeBSD**, **DPS8M** utilizes **FreeBSD-specific** atomic operations.
- The **FreeBSD-specific** `atomic_testandset_64` operation is currently not implemented in all versions of **FreeBSD** or on all platforms **FreeBSD** supports (e.g. **powerpc64**, or **arm64** prior to **13.0-RELEASE**).

If you are unable to build the simulator because this atomic operation is unimplemented on your platform, specify `ATOMICS="GNU"` as an argument to `gmake`, or export this value in the shell environment before compiling.

NetBSD

- Ensure you are running a supported release of **NetBSD** on a supported platform.
 - **NetBSD/amd64** and **NetBSD/evbarm** are regularly tested by **The DPS8M Development Team**.
- **DPS8M** is fully supported on **NetBSD 9.2** or later.

NetBSD prerequisites

Install the required prerequisites (using NetBSD Packages or pkgsrc):

- Using NetBSD Packages (as *root*):

```
pkgin in gmake libuv
```

- Using pkgsrc (as *root*):

```
cd /usr/pkgsrc/devel/gmake/ && make install clean
cd /usr/pkgsrc/devel/libuv/ && make install clean
```

Standard NetBSD compilation

- Build the simulator (*standard build*) from the top-level source directory (using **GNU Make**):

```
gmake
```

Optimized NetBSD compilation

- **NetBSD** provides an older version of **GCC** (or **Clang**) as part of the base system (depending on the platform). While *sufficient* to build the simulator, we recommend that version 12 or later of the **GNU C** (`gcc`) compiler be used for optimal performance.
- At the time of writing, **GCC 14.2** is available for **NetBSD 10** systems and is the version of GCC currently recommended by **The DPS8M Development Team**.

It can be installed via Packages or pkgsrc.

- Using NetBSD Packages (as *root*):

```
pkgin in gcc14
```

- Using pkgsrc (as *root*):

```
cd /usr/pkgsrc/lang/gcc14/ && make install clean
```

- Build the simulator from the top-level source directory (using **GNU Make**):

```
env CC="/usr/pkg/gcc14/bin/gcc" LDFLAGS="-Wl,-rpath=/usr/pkg/gcc14/lib" gmake
```

Compilation using Clang

- **GCC** is recommended for optimal performance, but compilation using **Clang** (and linking using **LLD**, the LLVM linker) is supported.

Both **Clang** and **LLD** can be installed via Packages or pkgsrc.

- Using NetBSD Packages (as *root*):

```
pkgin in clang lld
```

- Using pkgsrc (as *root*):

```
cd /usr/pkgsrc/lang/clang/ && make install clean
cd /usr/pkgsrc/devel/lld/ && make install clean
```

- Build the simulator from the top-level source directory (using **GNU Make**):

```
env CC="clang" \
LDFLAGS="-L/usr/lib -L/usr/pkg/lib -fuse-ld=\"$(command -v ld.lld)\" gmake
```

blinkerLights2 on NetBSD

- To build the **blinkerLights2** front-panel display, install its prerequisites via NetBSD Packages or pkgsrc:

- Using NetBSD Packages (as *root*):

```
pkg install pkgconf gtk3+
```

- Using pkgsrc (as *root*):

```
cd /usr/pkgsrc/devel/pkgconf/ && make install clean
cd /usr/pkgsrc/x11/gtk3/ && make install clean
```


- Build **blinkenLights2** from the top-level source directory (using **GNU Make**):

```
gmake blinkenLights2
```

OpenBSD

- Ensure you are running an up-to-date and supported release of **OpenBSD** on a supported platform.
 - **OpenBSD/amd64** and **OpenBSD/arm64** are regularly tested by **The DPS8M Development Team**.
- The following instructions were verified using **OpenBSD 7.5** on **amd64** and **arm64**.

OpenBSD prerequisites

Install the required prerequisites (using OpenBSD Packages or Ports):

- Using OpenBSD Packages (as *root*):

```
pkg_add gmake libuv
```

- Using OpenBSD Ports (as *root*):

```
cd /usr/ports/devel/gmake/ && make install clean
cd /usr/ports/devel/libuv/ && make install clean
```

Standard OpenBSD compilation

- Build the simulator (*standard build*) from the top-level source directory (using **GNU Make**):

```
gmake
```

Optimized OpenBSD compilation

- **OpenBSD** provides an older version of **GCC** (or **Clang**) as part of the base system (depending on the platform). While *sufficient* to build the simulator, we recommend that a recent version of the **GNU assembler** (**gas**) and version 11 or later of the **GNU C** (**gcc**) compiler be used for optimal performance.
- At the time of writing, appropriate versions of the **GNU assembler** and **GNU C** (version **11.2**) are available for **OpenBSD**. (In addition, **LLD**, the LLVM linker, may be required.) These tools have been tested and are highly recommended by **The DPS8M Development Team**.

They can be installed via OpenBSD Packages or Ports:

- Using OpenBSD Packages (as *root*):

```
pkg_add gas gcc
```

- Using OpenBSD Ports (as *root*):

```
cd /usr/ports/devel/gas/ && make install clean
cd /usr/ports/lang/gcc/11/ && make install clean
```

- LLVM **LLD** 16.0.6 or later is recommended for linking, even when using **GCC 11.2** for compilation. **LLD** is the default linker on **most** (but not all) supported OpenBSD platforms. To determine the linker in use, examine the output of `ld --version`.

If the linker identifies itself by a name *other* than **LLD** (e.g. “**GNU ld**” or similar), **LLD** must be installed via OpenBSD Packages or Ports.

- Using OpenBSD Packages (as *root*):

```
pkg_add llvm
```

- Using OpenBSD Ports (as *root*):

```
cd /usr/ports/devel/llvm/ && make install clean
```

- Configure **GCC** to execute the correct assembler and/or linker:

```
mkdir -p ~/.override
test -x /usr/local/bin/gas && ln -fs /usr/local/bin/gas ~/.override/as
test -x /usr/local/bin/ld && ln -fs /usr/local/bin/ld ~/.override/ld
```

- Build the simulator from the top-level source directory (using **GNU Make**):

```
env CC="egcc" CFLAGS="-B ~/.override" gmake
```

Compilation using Clang

- **GCC** is recommended for optimal performance, but compilation using **Clang** is supported.
- A version of **Clang** newer than the base system version may be available via the ‘**llvm**’ package or port.
- Once installed, it can be used for compilation by setting the appropriate environment variables before invoking the ‘**gmake**’ program (i.e. ‘**CC="/usr/local/bin/clang"**’ and ‘**LDFLAGS="-fuse-ld=lld"**’).

Additional OpenBSD Notes

- **OpenBSD/luna88k** is **not supported**.
-

DragonFly BSD

- At the time of writing, **DragonFly BSD 6.4.0** was current and used to verify the following instructions.

DragonFly BSD prerequisites

- Install the required prerequisites using DragonFly BSD DPorts (as *root*):

```
pkg install gmake libuv
```

Standard DragonFly BSD compilation

- Build the simulator (*standard build*) from the top-level source directory (using **GNU Make**):

```
env CFLAGS="-I/usr/local/include" \
    LDFLAGS="-L/usr/local/lib" \
    ATOMICS="GNU" \
    gmake
```

Optimized DragonFly BSD compilation

- **DragonFly BSD** provides an older version of **GCC** as part of the base system. While this compiler is *sufficient* to build the simulator, we recommend that version 12 or later of the **GNU C** (*gcc*) compiler be used for optimal performance.
- At the time of writing, **GCC 13.1** is available for DragonFly BSD and recommended by **The DPS8M Development Team**.
 - **GCC 13.1** may be installed using DragonFly BSD DPorts (as *root*):

```
pkg install gcc13
```

- Build the simulator from the top-level source directory (using **GNU Make**):

```
env CC="gcc13" CFLAGS="-I/usr/local/include" \
    LDFLAGS="-L/usr/local/lib -Wl,-rpath=/usr/local/lib/gcc13" \
    ATOMICS="GNU" \
    gmake
```

Compiling using Clang

- **GCC** is recommended for optimal performance, but compilation using **Clang** is supported.
- At the time of writing, **Clang 17** is available for DragonFly BSD and recommended by **The DPS8M Development Team**.
- While some optional utilities *may* fail to build using **Clang** on DragonFly, the simulator (*src/dps8/dps8*) is fully tested with each DragonFly release.
 - **Clang 17** may be installed using DragonFly BSD DPorts (as *root*):

```
pkg install llvm17
```

- Build the simulator from the top-level source directory (using **GNU Make**):

```
env CC="clang17" CFLAGS="-I/usr/include -I/usr/local/include" \
    LDFLAGS="-L/usr/lib -L/usr/local/lib -fuse-ld=lld" \
    ATOMICS="GNU" \
    gmake
```

Solaris

- Ensure your **Solaris** installation is reasonably current.
 - **Oracle Solaris 11.4 SRU42** or later is recommended.
- The simulator can be built on **Solaris** using the **GCC**, **Clang**, and **Oracle Developer Studio** compilers.

- **GCC 11** is the recommended compiler for optimal performance on all Intel-based **Solaris** systems.
 - **GCC 11** can be installed from the standard IPS repository via `'pkg install gcc-11'`.
 - Link-time optimization (*LTO*) is supported **only** when building with **GCC** version 10 or later.
 - The `NO_LTO=1` build option should be specified when using earlier versions of the **GCC** compiler.
- Building with **Clang 11** (or later) is also supported (*but not recommended due to lack of LTO support*).
 - **Clang 11** can be installed from the standard IPS repository, i.e. `'pkg install clang@11 llvm@11'`.
- Building with the **Oracle Developer Studio 12.6** (`suncc`) compiler is also supported.
 - Note that building for **Solaris** using the **Oracle Developer Studio** compiler currently requires a non-trivial amount of `CFLAGS` to be specified. This will be simplified in a future release of the simulator.

Solaris prerequisites

- Install the required prerequisites from the standard IPS repository (as *root*):

```
pkg install gnu-make gnu-binutils gnu-sed gnu-grep gnu-tar gawk \  
gnu-coreutils pkg-config libtool autoconf automake wget
```

Solaris compilation

The following commands will download and build a local static **libuv** before compiling the simulator.

If a site-provided **libuv** library has been installed (in the `"/usr/local"` prefix), the **libuvrel** stage of the build may be omitted.

Build **libuv** and the simulator from the top-level source directory (using **GNU Make**):

GCC

- Build using **GCC**:

- Build **libuv**:

```
env TAR="gtar" TR="gtr" CC="gcc" gmake libuvrel
```

- Build the simulator:

```
env TR="gtr" CC="gcc" gmake
```

Clang

- Build using **Clang**:

- Build **libuv**:

```
env TAR="gtar" NO_LTO=1 TR="gtr" CC="clang" gmake libuvrel
```

- Build the simulator:

```
env NO_LTO=1 TR="gtr" CC="clang" gmake
```

Oracle Developer Studio

- Build using **Oracle Developer Studio 12.6**:

- Build `libuv`:

```
env TAR="gtar" NO_LTO=1 SUNPRO=1 NEED_128=1 TR="gtr" CSTD="c11" \
  CFLAGS="-DNO_C_ELLIPSIS -Qy -xO5 -m64 -xlibmil -xCC -mt -xlibmopt \
  -fno-semantic-interposition -xprefetch=auto -xprefetch_level=3" \
  CC="/opt/developerstudio12.6/bin/suncc" \
  gmake libuvrel
```

- Build the simulator:

```
env NO_LTO=1 SUNPRO=1 NEED_128=1 TR="gtr" CSTD="c11" \
  CFLAGS="-DNO_C_ELLIPSIS -Qy -xO5 -m64 -xlibmil -xCC -mt -xlibmopt \
  -fno-semantic-interposition -xprefetch=auto -xprefetch_level=3" \
  CC="/opt/developerstudio12.6/bin/suncc" \
  gmake
```

OpenIndiana

- Ensure your **OpenIndiana** installation is up-to-date.
 - **OpenIndiana Hipster December 2024** was used to verify these instructions.
- **GCC 14.2** is currently the recommended compiler for optimal performance.
 - **GCC 14.2** can be installed from the standard IPS repository via `'pkg install developer/gcc-14'`.
 - Link-time optimization (*LTO*) is supported **only** when building with **GCC** version 10 or later.
 - The `NO_LTO=1` build option should be specified when using earlier versions of the **GCC** compiler.
- Building with **Clang** (version 13 or later) is also supported (*but not recommended due to lack of LTO support*).
 - **Clang 19** can be installed from the standard IPS repository via `'pkg install developer/clang-19'`.

OpenIndiana prerequisites

- Install the required prerequisites from the standard IPS repository (as *root*):

```
pkg install gnu-make libuv gnu-binutils gnu-coreutils
```

Standard OpenIndiana compilation

- Build the simulator from the top-level source directory (using **GNU Make** and **GCC 14**):

```
env CC="gcc-14" gmake
```

Compiling using Clang

- Build the simulator from the top-level source directory (using **GNU Make** and **Clang 19**):

```
env NO_LTO=1 CC="clang-19" gmake
```

AIX

- Ensure you are running a supported release of **IBM AIX®** on a supported platform.
 - **IBM AIX® 7.2** (TL5 SP9) and **7.3** (TL3) on **POWER8®**, **POWER9™**, and **Power10** systems are regularly tested by **The DPS8M Development Team**.
- The simulator can be built for **64-bit AIX®** systems using **IBM XL C/C++ for AIX (xlc)**, **IBM Open XL C/C++ for AIX (ibm-clang)**, mainline **Clang (clang)**, and **GNU C (gcc)**. When using **XL compilers**, ensure that you are using the latest available XL compiler and associated PTF updates for your **IBM AIX** OS level. Review the current fix list for XL compilers on AIX for complete details.
- **The DPS8M Development Team** recommends building with **IBM Open XL C/C++ V17.1.2** (or later) or mainline **Clang 18** (or later) for optimal performance. Building with **GNU C** is supported (*but not recommended*) when using **GCC 10** (or later).

Recommended compilers

- **IBM Open XL C/C++ for AIX V17.1.3 Fix Pack 2** (April 2025) is the recommended compiler for **Power11** systems.
 - LTO (*link-time optimization*) and native 128-bit integer operations are both fully supported.
- **IBM Open XL C/C++ for AIX V17.1.2 Fix Pack 15** (February 2025) is the *minimum* recommended version of the **Open XL C/C++ V17.1.2** compiler for **POWER8**, **POWER9**, and **Power10** systems.
 - LTO (*link-time optimization*) and native 128-bit integer operations are both fully supported.
- **Clang 20.1.2** is the *minimum* recommended version of the mainline **Clang** compiler.
 - LTO (*link-time optimization*) and native 128-bit integer operations are both fully supported.

Other supported compilers

- **IBM Open XL C/C++ for AIX V17.1.1 Fix Pack 6** (February 2024) is the *minimum* recommended version of the **Open XL C/C++ V17.1.1** compiler for **POWER8**, **POWER9**, and **Power10** systems.
 - LTO (*link-time optimization*) is supported, but 128-bit integer operations are **not supported**.
 - * Use of the **NEED_128=1** option is required when building with **Open XL C/C++ V17.1.1**.
- **IBM XL C/C++ for AIX V16.1.0 Fix Pack 20** (December 2024) is the *minimum* recommended version of the **IBM XL C/C++ V16.1.0** compiler for **POWER8** and **POWER9** systems.
 - LTO (*link-time optimization*) and 128-bit integer operations are both **not supported**.
 - * Use of the **NEED_128=1** and **NO_LTO=1** options are required when building with **IBM XL C/C++ V16.1.0**.
 - **IBM XL C/C++ V16.1.0** is **not** recommended for **Power10** systems.
- **GNU C 11.3.0** is the *minimum* recommended version of the **GNU C** compiler for **POWER8**, **POWER9**, and **Power10** systems.
 - LTO (*link-time optimization*) and 128-bit integer operations are both **not supported**.
 - * Use of the **NEED_128=1** and **NO_LTO=1** options are required when building with **GNU C**.
 - **GCC 11** (and **GCC 12**) can be installed from the IBM AIX Toolbox for Open Source Software repository.
- Note that building fully-featured binaries for **IBM AIX** currently requires a non-trivial number of options to be specified *after* the **gmake** command, which overrides various build defaults appropriate for **Linux**, **macOS**, and **BSD** systems, but not **IBM AIX**. This will be simplified in a future release of the simulator.

AIX prerequisites

Libraries and tools

- Install the required prerequisites from the IBM AIX Toolbox for Open Source Software repository (as *root*):

```
/opt/freeware/bin/dnf install sed gmake libuv libuv-devel popt coreutils gawk
```

GNU C compilers

- *Optionally* install **GCC 11.3** (or **GCC 12.3**) from the IBM AIX Toolbox for Open Source Software repository (as *root*).
 - GCC availability from the IBM AIX Toolbox for Open Source Software site varies depending on **IBM AIX OS** version.

- Install **GCC 11.3**:

```
/opt/freeware/bin/dnf install gcc gcc11
```

- Install **GCC 12.3**:

```
/opt/freeware/bin/dnf install gcc gcc12
```

Clang compilers

- *Optionally* install mainline **Clang**. At the time of writing, mainline **Clang** for **AIX** was not yet available from the IBM AIX Toolbox for Open Source Software repository, but can be obtained from:
 - LLVM Downloads (*source code*), or,
 - IBM GitHub Releases (*source code and binary releases*)
 - LLVM GitHub Releases (*source code and binary releases*)

IBM compiler support

- IBM does not provide support for any version of **GNU C** through **IBM AIX** support cases; we recommend IBM customers with support contracts use **Open XL C/C++** if possible.

AIX compilation

Build the simulator from the top-level source directory (using **GNU Make**):

IBM Open XL C/C++ for AIX

- Using **IBM Open XL C/C++ for AIX V17.1.2** (*and later*):

```

env PATH="/opt/freeware/bin:${PATH}" \
CC="/opt/IBM/openxlC/17.1.2/bin/ibm-clang_r" \
ATOMICS="AIX" \
AWK="gawk" \
OBJECT_MODE=64 \
gmake PULIBS="-lpopt" \
LDFLAGS="-L/opt/freeware/lib -L/usr/local/lib -flto=auto -b64" \
LIBS="-lpthread -luv -lbsd -lm" \
CFLAGS="-flto=auto -I/opt/freeware/include -I/usr/local/include \
-I../simh -I../decNumber -DUSE_FLOCK=1 -DUSE_FCNTL=1 \
-I../libsir/include -DHAVE_POPT=1 -DAIX_ATOMICS=1 -m64 \
-DLOCKLESS=1 -D_ALL_SOURCE -D_GNU_SOURCE -O3 \
-U__STRICT_POSIX__ -fno-strict-aliasing -mcpu=power8"

```

- When building on IBM **POWER9** (or **Power10**) systems, '-mcpu=power9' (or '-mcpu=power10') should replace '-mcpu=power8' in the above compiler invocation.
- Refer to the **IBM Open XL C/C++ for AIX V17.1.2 documentation** for additional information.

- Using **IBM Open XL C/C++ for AIX V17.1.1**:

```

env PATH="/opt/freeware/bin:${PATH}" \
CC="/opt/IBM/openxlC/17.1.1/bin/ibm-clang_r" \
ATOMICS="AIX" \
AWK="gawk" \
OBJECT_MODE=64 \
NEED_128=1 \
gmake PULIBS="-lpopt" \
LDFLAGS="-L/opt/freeware/lib -L/usr/local/lib -flto=auto -b64" \
LIBS="-lpthread -luv -lbsd -lm" \
CFLAGS="-flto=auto -I/opt/freeware/include -I/usr/local/include \
-I../simh -I../decNumber -DUSE_FLOCK=1 -DUSE_FCNTL=1 \
-I../libsir/include -DHAVE_POPT=1 -DNEED_128=1 \
-DAIX_ATOMICS=1 -m64 -DLOCKLESS=1 -D_ALL_SOURCE \
-D_GNU_SOURCE -O3 -U__STRICT_POSIX__ \
-fno-strict-aliasing -mcpu=power8"

```

- When building on IBM **POWER9** (or **Power10**) systems, '-mcpu=power9' (or '-mcpu=power10') should replace '-mcpu=power8' in the above compiler invocation.
- Refer to the **IBM Open XL C/C++ for AIX V17.1.1 documentation** for additional information.

Clang

- Using mainline **Clang 18.1.8**:

```

env PATH="/opt/llvm/bin:/opt/freeware/bin:${PATH}" \
CC="/opt/llvm/bin/clang" \
ATOMICS="AIX" \
AWK="gawk" \
OBJECT_MODE=64 \
gmake PULIBS="-lpopt" \
LDFLAGS="-L/opt/freeware/lib -L/usr/local/lib -flto=auto -b64" \
LIBS="-lpthread -luv -lbsd -lm" \
CFLAGS="-flto=auto -I/opt/freeware/include -I/usr/local/include \
-I../simh -I../decNumber -DUSE_FLOCK=1 -DUSE_FCNTL=1 \
-I../libsir/include -DHAVE_POPT=1 -DAIX_ATOMICS=1 -m64 \
-DLOCKLESS=1 -D_ALL_SOURCE -D_GNU_SOURCE -O3 \
-U__STRICT_POSIX__ -fno-strict-aliasing -mcpu=power8"

```


- When building on IBM **POWER9** (or **Power10**) systems, '-mcpu=power9' (or '-mcpu=power10') should replace '-mcpu=power8' in the above compiler invocation.
- Refer to the **Clang documentation** for additional information.

IBM XL C/C++ for AIX

- Using **IBM XL C/C++ for AIX V16.1.0**:

```
env PATH="/opt/freeware/bin:${PATH}" \
  ATOMICS="AIX" \
  AWK="gawk" \
  NO_LTO=1 \
  OBJECT_MODE=64 \
  gmake CC="/opt/IBM/xlC/16.1.0/bin/xlc_r" \
  NEED_128=1 \
  USE_POPT=1 \
  PULIBS="-lpopt" \
  LDFLAGS="-L/opt/freeware/lib -L/usr/local/lib -b64" \
  LIBS="-luv -lbsd -lm" \
  CFLAGS="-O3 -qhot -qarch=pwr8 -qalign=natural -qtls -DUSE_POPT=1 \
  -DUSE_FLOCK=1 -DUSE_FCNTL=1 -DAIX_ATOMICS=1 -DNEED_128=1 \
  -DLOCKLESS=1 -I/opt/freeware/include -I../simh \
  -I../decNumber -I/usr/local/include -D_GNU_SOURCE \
  -I../libsir/include -D_ALL_SOURCE -U__STRICT_POSIX__"
```

- When building on **POWER9** systems, '-qarch=pwr9' should replace '-qarch=pwr8' in the above compiler invocation.
- Compilation using higher optimization levels (i.e. '-O4' or '-O5' replacing '-O3 -qhot -qarch=pwr8') and/or enabling automatic parallelization (i.e. '-qsmp') may be possible, but the resulting binaries have *not* been benchmarked or extensively tested by **The DPS8M Development Team**.
- Refer to the **IBM XL C/C++ for AIX V16.1 Optimization and Tuning Guide** for additional information.

GCC

- Using **GCC 11.3**:

```
env PATH="/opt/freeware/bin:${PATH}" CC="gcc-11" \
  ATOMICS="AIX" NO_LTO=1 gmake
```

- Refer to the **GCC 11.3 online documentation** for additional information.

- Using **GCC 12.3**:

```
env PATH="/opt/freeware/bin:${PATH}" CC="gcc-12" \
  ATOMICS="AIX" NO_LTO=1 gmake
```

- Refer to the **GCC 12.3 online documentation** for additional information.

Haiku

- Ensure you are running a recent release of **Haiku** on a supported **64-bit** platform.
 - Use the **SoftwareUpdater** application to ensure your **Haiku** installation is up-to-date.

- **The DPS8M Development Team** regularly tests the simulator using the nightly **Haiku x86_64** snapshots.
 - **Haiku x86_64 (hrev58181)** was used to verify the following instructions.

Haiku prerequisites

The default **Haiku** installation includes the required header files, an acceptable compiler (at the time of writing, **GCC 13.3**), and most of the necessary development utilities (*i.e.* **GNU Make**) required to build **DPS8M**. The remaining prerequisites are available via the standard package management tools.

- Install the required prerequisites (from *HaikuPorts* using **pkgman** or the ‘**HaikuDepot**’ application):
 - `libuv`
 - `libuv_devel`
 - `getconf`

Standard Haiku compilation

- Build the simulator (*standard build*) from the top-level source directory (using **GNU Make**):

```
make
```

Compiling using Clang

- Compiling with Clang on Haiku is **highly recommended**; the resulting binary runs approximately **35% faster**.
- At the time of writing, **Clang 19** is available from *HaikuPorts* (as the ‘`llvm19_clang`’ and ‘`llvm19_llvm`’ packages), installable using **pkgman** or the ‘**HaikuDepot**’ application.
- Build the simulator from the top-level source directory (using **GNU Make**):

```
env CC="clang" make
```

Additional Haiku Notes

- **DPS8M** on **32-bit Haiku** platforms (*i.e.* **x86**, **x86_gcc2**) is **not** supported at this time.

Linux

- Most major **Linux** distributions using the **GNU C Library**, **musl-libc**, and **uClibc-ng** (with `NO_LOCALE=1`) are supported.
 - **Debian GNU/Linux** and derivatives (**Raspberry Pi OS**), **Red Hat** variants (**Fedora**, **CentOS Stream**, **RHEL**) and compatibles (**AlmaLinux**, **Amazon Linux**, **Oracle Linux**), **Alpine**, **SUSE (SLES, OpenSUSE)**, **Void**, and **Ubuntu** are regularly tested on **Intel**, **ARM**, **RISC-V**, **POWER**, and **МЦСТ Эльбрус** systems.

Linux compilers

- **GCC 12** or later is recommended for optimal performance on most architectures including **Intel** and **ARM**.
 - **The DPS8M Development Team** regularly tests and supports a wide range of Linux compilers, including **Clang**, AMD Optimizing C/C++ (**AOCC**), Arm C/C++ Compiler (**ARMClang**), GNU C (**GCC**) (*version 9+*), IBM Advance Toolchain for Linux, IBM XL C/C++ for Linux (**XL**C), IBM Open XL C/C++ for Linux (**IBMClang**), Intel oneAPI DPC++/C++ (**ICX**), NVIDIA HPC SDK C Compiler (**NVC**), Oracle Developer Studio (**SunCC**), and МЦСТ Эльбрус C Compiler (**LCC**)..
- **Red Hat** offers the **Red Hat Developer Toolset** for **Red Hat Enterprise Linux** and **CentOS Stream**, which provides up-to-date versions of **GCC** on a rapid release cycle, with *full support*.
 - The *Toolset* packages are also included in various “clone” distributions such as **AlmaLinux**. These tools are regularly tested and highly recommended by **The DPS8M Development Team**. Check your distribution packager manager (*i.e.* ‘**dnf search**’) for packages named ‘**gcc-toolset-13**’, ‘**gcc-toolset-14**’, or similar.
- **Canonical** similarly offers two **Ubuntu Toolchain PPAs**, one providing **GCC** updates for release branches, and the other providing new **GCC** versions for both current and **LTS** releases, maintained by the Ubuntu Toolchain team.
 - For example, at the time of writing, Ubuntu 22.04 LTS ships **GCC 11.3** and **GCC 12.1**, and the **Toolchain PPAs** ship **GCC 12.3** and **GCC 13.1**. Although these packages are *not formally supported* by Canonical, they are regularly and successfully used by **The DPS8M Development Team**.
 - **NOTE:** Ubuntu has shipped multiple versions of the **LLVM** and **Clang** packages that are **broken** in various ways (*incorrect library paths, missing libraries, broken LTO support, etc.*). If you encounter problems building from source code using **Clang** on Ubuntu, try installing different package versions, wait for an update, or use **GCC** to build instead.
- **Intel® C++ Compiler Classic (ICC) for Linux** is **no longer supported** for building **DPS8M** (*as of R3.0.0*):
 - Users should upgrade to the current version of the **Intel® oneAPI DPC++/C++ (ICX) Compiler**.
 - Intel® has *retired* support for **ICC**.
- Cross-compilation is supported. Popular targets including various **Linux** platforms, **Microsoft Windows** on **Intel** and **ARM** (using the **MinGW-w64** and **LLVM-MinGW** toolchains) and **Linux on POWER** (using the **IBM Advance Toolchain for Linux**) are regularly built and tested.

Linux prerequisites

Users of some **Red Hat** variants may need to enable the **PowerTools** repository or the **CodeReady Builder** AppStream to install **libuv**:

- RHEL 8:

```
subscription-manager repos --enable \  
"codeready-builder-for-rhel-8-$(arch)-rpms"
```

- CentOS Stream 8:

```
dnf config-manager --set-enabled "powertools"
```

- RHEL 9:

```
subscription-manager repos --enable \  
"codeready-builder-for-rhel-9-$(arch)-rpms"
```

- CentOS Stream 9:

```
dnf config-manager --set-enabled "crb"
```

Install the required prerequisites using a distribution package manager:

- Using **dnf** (for most **rpm**-based distributions) (as *root*):

```
dnf install "@Development Tools" libuv-devel
```

- Using **apt** (for most **deb**-based distributions) (as *root*):

```
apt install build-essential libuv1-dev
```

Standard Linux compilation

- Build the simulator (*standard build*) from the top-level source directory (using **GNU Make**):

```
make
```

Alternative Linux compilation

To use a compiler other than the default it is *usually* sufficient to simply set the **CC** environment variable (*if* the compiler accepts command-line arguments compatible with **GCC** or **Clang**). Other compilers are supported as well, but require additional configuration.

Examples of building the simulator on **Linux** using various popular compilers follows:

Clang

- Build the simulator using **Clang** (**Clang 15** or later recommended):

```
env CC="clang" make
```

Intel oneAPI DPC++/C++

- Build the simulator using **Intel oneAPI DPC++/C++ (ICX)**:

```
source /opt/intel/oneapi/setvars.sh && \
env CC="icx" make
```

AMD Optimizing C/C++

- Build the simulator using **AMD Optimizing C/C++ (AOCC)**, version 5.0.0, (with **AOCC**-provided **AMD LibM**):

```
export AOCCVER="5.0.0" && \
export AOCLPATH="/opt/AMD/aocc-compiler-${AOCCVER}" && \
source ${AOCLPATH}/setenv_AOCC.sh && \
env CC="clang" CFLAGS="-mllvm -vector-library=AMDLIBM" \
  LDFLAGS="-Wno-unused-command-line-argument" \
  LOCALLIBS="-lalm" \
make
```

AOCC with AMD Optimized CPU Libraries

- Build the simulator using **AMD Optimizing C/C++ (AOCC)**, version 5.0.0, with **AMD Optimized CPU Libraries (AOCL)** (**AMD AOCL-LibM** and **AMD AOCL-LibMem**), version 5.0.0:

```
export AOCCVER="5.0.0" && \
export AOCCPATH="/opt/AMD/aocc-compiler-${AOCCVER}" && \
export AOCLVER="5.0.0" && \
export AOCLPATH="/opt/AMD/aocl/aocl-linux-aocc-${AOCLVER}" && \
export LD_LIBRARY_PATH="${AOCLPATH}/aocc/lib:${LD_LIBRARY_PATH}" && \
source ${AOCCPATH}/setenv_AOCC.sh && \
env CC="clang" CFLAGS="-mllvm -vector-library=AMDLIBM" \
    LDFLAGS="-Wno-unused-command-line-argument -L${AOCLPATH}/aocc/lib" \
    LOCALLIBS="-lalm -laocl -libmem" \
make
```

Oracle Developer Studio

- Build the simulator using **Oracle Developer Studio (SunCC)** for Linux, version 12.6:

```
env CFLAGS="-DNO_C_ELLIPSIS -Qy -x05 -m64 -xlibmil -xCC -mt \
    -xlibmopt -fno-semantic-interposition \
    -xprefetch=auto -xprefetch_level=3" \
    CC="/opt/oracle/developerstudio12.6/bin/suncc" \
    NO_LTO=1 SUNPRO=1 NEED_128=1 CSTD="c11" \
make
```

IBM Open XL C/C++ for Linux

- Build the simulator using **IBM Open XL C/C++ for Linux V17.1.1 Fix Pack 2** (*February 2024*) for Linux on POWER:

```
env CFLAGS="-mcpu=power8" \
    CC="/opt/ibm/openxlC/17.1.1/bin/ibm-clang_r" \
make
```

- When building on IBM **POWER9** (or **Power10**) systems, ‘-mcpu=power9’ (or ‘-mcpu=power10’) should replace ‘-mcpu=power8’ in the above compiler invocation.
- Refer to the **IBM Open XL C/C++ for Linux V17.1.1 documentation** for additional information.

IBM XL C/C++ for Linux

- Build the simulator using **IBM XL C/C++ for Linux V16.1.1 Fix Pack 15** (*September 2023*) for Linux on POWER:

```
env CFLAGS="-qtls -qarch=pwr8" \
    CC="/opt/ibm/xlC/16.1.1/bin/c99_r" \
    CSTD="c11" NO_LTO=1 \
make
```

- When building on **POWER9** or higher systems, ‘-qarch=pwr9’ should replace ‘-qarch=pwr8’ in the above compiler invocation.
- Compilation using higher optimization levels (e.g. ‘-O4’, ‘-O5’, ‘-qhot’, etc.) and/or enabling automatic parallelization (i.e. ‘-qsmp’) may be possible, but the resulting binaries have *not* been benchmarked or tested by **The DPS8M Development Team**.

NVIDIA HPC SDK C Compiler

- Build the simulator using **NVIDIA HPC SDK C Compiler (NVC)**, version 25.3, for Linux/**x86_64** (with versions also available for Linux/**ARM64** and Linux/**OpenPOWER**):

```
export NVCVER="25.3" && \
export NVPLAT="Linux_x86_64" && \
export NVCPATH="/opt/nvidia/hpc_sdk/${NVPLAT}/${NVCVER}/compilers/bin" && \
env CFLAGS="-noswitcherror --diag_suppress=mixed_enum_type \
--diag_suppress=branch_past_initialization \
--diag_suppress=set_but_not_used" \
CC="${NVCPATH}/nvc" NO_LTO=1 \
make OPTFLAGS="-fast -O4 -Mnofprelaxed"
```

- DPS8M** is known to trigger bugs in some versions of the **NVIDIA HPC SDK C Compiler**, such as:

```
NVC++-F-0000-Internal compiler error. add_cilis(): bad jmp code 1056
```

If you encounter this (or similar) compiler errors, try adding '-Mnovect' to 'OPTFLAGS' as a workaround.

Arm HPC C/C++ Compiler for Linux

The **Arm HPC C/C++ Compiler for Linux** with **Arm Performance Libraries** (also available as a component of **Arm Allinea Studio**) provides a packaged **Clang/LLVM**-based toolchain with optimized math and string libraries, validated against common ARM HPC platforms.

Note the following examples *do not* make use of **Environment Modules** and/or **Lmod**, commonly used to manage compiler and development tool installations in HPC environments.

If your site uses modules (i.e. `module avail`), loading the appropriate module is usually preferred to setting paths manually. Contact your system administrator for site-specific configuration details and recommended local compiler flags.

- Build the simulator using the **Arm HPC C/C++ Compiler for Linux (ARMClang)**, version 24.10.1, for Linux/**ARM64**:

```
export ACFLVER="24.10.1" && \
export ACFLCMP="arm-linux-compiler-${ACFLVER}" && \
export ACFLTYP="Generic-AArch64_RHEL-9_aarch64-linux" && \
export ACFLPATH="/opt/arm/${ACFLCMP}_${ACFLTYP}" && \
export PATH="${ACFLPATH}/bin:${PATH}" && \
env CFLAGS="-mcpu=native" \
CC="armclang" \
make
```

ACFL with Arm Performance Libraries

- Build the simulator using the **Arm HPC C/C++ Compiler for Linux (ARMClang)** with the integrated **Arm Performance Libraries (ArmPL)**, version 24.10.1, for Linux/**ARM64**:

```
export ACFLVER="24.10.1" && \
export ACFLCMP="arm-linux-compiler-${ACFLVER}" && \
export ACFLTYP="Generic-AArch64_RHEL-9_aarch64-linux" && \
export ACFLPATH="/opt/arm/${ACFLCMP}_${ACFLTYP}" && \
export PATH="${ACFLPATH}:${PATH}" && \
env CFLAGS="-mcpu=native -armpl" \
LDLFLAGS="-armpl" \
CC="armclang" \
make
```

- Build the simulator using the **Arm HPC C/C++ Compiler for Linux (ARMClang)** with the integrated **Arm Performance Libraries (ArmPL)**, version 24.10.1, for Linux/**ARMv8-A+SVE2** (*Scalable Vector Extensions*):

```
export ACFLVER="24.10.1" && \
export ACFLCMP="arm-linux-compiler- $\{\}$ ACFLVER}" && \
export ACFLTYP="Generic-AArch64_RHEL-9_aarch64-linux" && \
export ACFLPATH="/opt/arm/ $\{\}$ ACFLCMP_ $\{\}$ ACFLTYP}" && \
export PATH=" $\{\}$ ACFLPATH: $\{\}$ PATH" && \
env CFLAGS="-march=armv8-a+sve2 -mcpu=native -armpl=sve" \
    LDFLAGS="-armpl=sve" \
    CC="armclang" \
make
```

Linux cross-compilation

The following commands will download and cross-compile a local static **libuv** and then cross-compile the simulator.

IBM Advance Toolchain

- Using the **IBM Advance Toolchain V17** to cross-compile for Linux/**POWER**:

- Build **libuv**:

```
env CC="/opt/at17.0/bin/powerpc64le-linux-gnu-gcc" \
    LOCAL_CONFOPTS="--host=powerpc64le-linux-gnu" \
    CFLAGS="-mcpu=power8 -mtune=power8" \
make libuvrel
```

- Build the simulator:

```
env CC="/opt/at17.0/bin/powerpc64le-linux-gnu-gcc" \
    CFLAGS="-mcpu=power8 -mtune=power8" \
make
```

- When targeting **POWER9** or **Power10** processors, 'power9' or 'power10' should replace 'power8' in the above compiler invocation.
- The **IBM Advance Toolchain** versions **14**, **15**, **16**, and **17** have been extensively tested and used for cross-compiling **DPS8M**.

Arm GNU Toolchain

The **GNU Toolchain for the Arm Architecture** (referred to as the "**Arm GNU Toolchain**") provides regularly updated, high-quality, validated Linux/**ARM** cross-compilers running on Microsoft Windows, Linux, and macOS.

Linux/ARMv7-HF

- Using the **Arm GNU Toolchain** on Linux/x86_64, version **13.2.Rel1**, to cross-compile for Linux/**ARMv7-HF** (*hardware floating point*):

- Build **libuv**:

```
export AGTREL="arm-gnu-toolchain-13.2.rel1-x86_64" && \
export AGTPATH="/opt/ $\{\}$ AGTREL-arm-none-linux-gnueabi/hf/bin/" && \
env CC=" $\{\}$ AGTPATH/arm-none-linux-gnueabi/hf-gcc" \
    CFLAGS="-march=armv7-a+fp" \
    LOCAL_CONFOPTS="--host=arm-none-linux-gnueabi/hf" \
make libuvrel
```

- Build the simulator:

```
env CC="${AGTPATH}/arm-none-linux-gnueabi-hf-gcc" \
    CFLAGS="-march=armv7-a+fp" \
    NEED_128=1 \
    make
```

Linux/ARM64

- Using the **Arm GNU Toolchain** on Linux/x86_64, version **13.2.Rel1**, to cross-compile for Linux/**ARM64**:

- Build libuv:

```
export AGTREL="arm-gnu-toolchain-13.2.rel1-x86_64" && \
export AGTPATH="/opt/${AGTREL}-aarch64-none-linux-gnu/bin/" && \
env CC="${AGTPATH}/aarch64-none-linux-gnu-gcc" \
    LOCAL_CONF_OPTS="--host=aarch64-none-linux-gnu" \
    make libuvrel
```

- Build the simulator:

```
env CC="${AGTPATH}/aarch64-none-linux-gnu-gcc" \
    make
```

Linux/ARM64BE

- Using the **Arm GNU Toolchain** on Linux/x86_64, version **13.2.Rel1**, to cross-compile for Linux/**ARM64BE** (*big endian*):

- Build libuv:

```
export AGTREL="arm-gnu-toolchain-13.2.rel1-x86_64" && \
export AGTPATH="/opt/${AGTREL}-aarch64_be-none-linux-gnu/bin/" && \
env CC="${AGTPATH}/aarch64_be-none-linux-gnu-gcc" \
    LOCAL_CONF_OPTS="--host=aarch64_be-none-linux-gnu" \
    make libuvrel
```

- Build the simulator:

```
env CC="${AGTPATH}/aarch64_be-none-linux-gnu-gcc" \
    make
```

Linaro GNU Toolchain

The **Linaro GNU Toolchain Integration Builds** provides Linux/**ARM** and Linux/**ARM64** reference toolchains, closely tracking upstream repositories, allowing developers to easily test new compiler and processor features before the next **Arm GNU Toolchain** release.

Linux/ARMv7-HF

- Using the **Linaro GNU Toolchain Integration Build** on Linux/x86_64, version **14.0.0-2023.06**, to cross-compile for Linux/**ARMv7-HF** (*hardware floating point*):

- Build libuv:

```
export LINREL="gcc-linaro-14.0.0-2023.06-x86_64" && \
export LINPATH="/opt/${LINREL}_arm-linux-gnueabi-hf/bin/" && \
env CC="${LINPATH}/arm-linux-gnueabi-hf-gcc" \
    CFLAGS="-march=armv7-a+fp" \
    LOCAL_CONF_OPTS="--host=arm-linux-gnueabi-hf" \
    make libuvrel
```


- Build the simulator:

```
env CC="${LINPATH}/arm-linux-gnueabi-gcc" \
    CFLAGS="-march=armv7-a+fp" \
    NEED_128=1 \
    make
```

Linux/ARM64

- Using the **Linaro GNU Toolchain Integration Build** on Linux/x86_64, version **14.0.0-2023.06**, to cross-compile for Linux/ARM64:

- Build `libuv`:

```
export LINREL="gcc-linaro-14.0.0-2023.06-x86_64" && \
export LINPATH="/opt/${LINREL}_aarch64-linux-gnu/bin/" && \
env CC="${LINPATH}/aarch64-linux-gnu-gcc" \
    LOCAL_CONFOPTS="--host=aarch64-linux-gnu" \
    make libuvrel
```

- Build the simulator:

```
env CC="${LINPATH}/aarch64-linux-gnu-gcc" \
    make
```

crosstool-NG

crosstool-NG is a versatile cross-toolchain generator, which can be used to generate **GCC**-based toolchains for a huge variety of architectures and operating systems (*mainly Linux*).

DPS8M is regularly built by **The DPS8M Development Team** for many **Linux** architectures using **crosstool-NG** generated toolchains, utilizing both the **glibc** and **musl** C libraries. The following **CT-NG** examples are intended to be instructive, but are by no means exhaustive.

Linux/RV64

- Using a **crosstool-NG** generated **GCC+musl** toolchain to cross-compile for Linux/**RV64 (64-bit RISC-V static binary)**:

- Build `libuv`:

```
export CTNG="riscv64-local-linux-musl" && \
env CC="/home/user/x-tools/${CTNG}/bin/${CTNG}-gcc" \
    LOCAL_CONFOPTS="--host=${CTNG}" \
    make libuvrel
```

- Build the simulator:

```
env CC="/home/user/x-tools/${CTNG}/bin/${CTNG}-gcc" \
    LDFLAGS="-static" \
    LOCALLIBS="-latomic" \
    make
```

Linux/i686

- Using a **crosstool-NG** generated **GCC+musl** toolchain to cross-compile for Linux/**i686 (32-bit static binary)**:

- Build `libuv`:

```

export CTNG="i686-local-linux-musl" && \
env CC="/home/user/x-tools/${CTNG}/bin/${CTNG}-gcc" \
    LOCAL_CONFOPTS="--host=${CTNG}" \
    make libuvrel

```

- Build the simulator:

```

env CC="/home/user/x-tools/${CTNG}/bin/${CTNG}-gcc" \
    LDFLAGS="-static" \
    LOCALLIBS="-latomic" \
    NEED_128=1 \
    make

```

Linux/ARMv6-HF

- Using a **crosstool-NG** generated **GCC+glibc** toolchain to cross-compile for Linux/**ARMv6-HF** (*hardware floating point*):

- Build libuv:

```

export CTNG="armv6-local-linux-gnueabiHF" && \
env CC="/home/user/x-tools/${CTNG}/bin/${CTNG}-gcc" \
    LOCAL_CONFOPTS="--host=${CTNG}" \
    CFLAGS="-march=armv6+fp" \
    make libuvrel

```

- Build the simulator:

```

env CC="/home/user/x-tools/${CTNG}/bin/${CTNG}-gcc" \
    CFLAGS="-march=armv6+fp" \
    LOCALLIBS="-latomic" \
    NEED_128=1 \
    make

```

Linux/PPC64le

- Using a **crosstool-NG** generated **GCC+musl** toolchain to cross-compile for Linux/**PPC64le** (**64-bit POWER9** *little endian static binary*):

- Build libuv:

```

export CTNG="powerpc64le-local-linux-musl" && \
env CC="/home/user/x-tools/${CTNG}/bin/${CTNG}-gcc" \
    LOCAL_CONFOPTS="--host=${CTNG}" \
    CFLAGS="-mcpu=power9" \
    make libuvrel

```

- Build the simulator:

```

env CC="/home/user/x-tools/${CTNG}/bin/${CTNG}-gcc" \
    CFLAGS="-mcpu=power9" \
    LDFLAGS="-static" \
    LOCALLIBS="-latomic" \
    make

```

Additional Linux Notes

- Although normally handled automatically, when building on (*or cross-compiling to*) some 32-bit targets using a compiler lacking support for 128-bit integer types, it may be necessary to explicitly set the **NEED_128=1** build option via the environment or as an argument to **make**.

macOS

- Ensure you are running a supported release of **macOS** with current updates applied.
 - Both **Intel** and **ARM64** systems are regularly tested by **The DPS8M Development Team**.
- **Xcode** is required; it is **strongly recommended** to use the most recent release for optimal performance.
 - **Intel® C++ Compiler Classic for macOS (icc)** is **no longer supported** for building **DPS8M** (as of **R3.0.2**).
 - * Intel® has *retired* support for **ICC**.
 - Building the simulator on **macOS** using **GCC** is **not recommended**.
- The following instructions were verified using **macOS 15.4.1** with **Xcode 16.4** (Apple Clang 17.0.0).

macOS prerequisites

- **Homebrew** is the recommended package manager for installing build prerequisites:

```
brew install libuv pkg-config
```

- Installation and configuration of **Homebrew** and its prerequisites (*i.e.* Xcode CLT) is outside the scope of the **DPS8M** documentation. Refer to the **Homebrew Installation Documentation** if support is required.
- Users of other package managers (*e.g.* pkgsrc, MacPorts) must set the **CFLAGS** (*e.g.* `'-I/opt/include'`), **LDFLAGS** (*e.g.* `'-L/opt/lib'`), and **LIBUV** (*e.g.* `'-luv'`) environment variables appropriately.

macOS compilation

Build the simulator from the top-level source directory (using **GNU Make**):

- Build using **Xcode**:

```
make
```

macOS cross-compilation

The following commands will download and cross-compile a local static **libuv** and then cross-compile the simulator using **Xcode**.

You **must** perform a `'make distclean'` before building for a different target.

- Install required prerequisites (using **Homebrew**):

```
brew install wget pkg-config autoconf automake libtool coreutils
```

Build the simulator from the top-level source directory (using **GNU Make**):

ARM64

- Cross-compilation targeting **ARM64 macOS 12**:

- Build `libuv`:

```
make distclean && \
env CFLAGS="-target arm64-apple-macos12 \
           -mmacosx-version-min=12.0" \
LOCAL_CONFOPTS="--host=arm64-apple-darwin" \
make libuvrel HOMEBREW_INC= HOMEBREW_LIB=
```

- Build the simulator:

```
env CFLAGS="-target arm64-apple-macos12 \
           -mmacosx-version-min=12.0" \
LDFLAGS="-target arm64-apple-macos12 \
         -mmacosx-version-min=12.0" \
make HOMEBREW_INC= HOMEBREW_LIB=
```

Intel

- Cross-compilation targeting **Intel macOS 10.15**:

- Build `libuv`:

```
make distclean && \
env CFLAGS="-target x86_64-apple-macos10.15 \
           -mmacosx-version-min=10.15" \
LOCAL_CONFOPTS="--host=x86_64-apple-darwin" \
make libuvrel HOMEBREW_INC= HOMEBREW_LIB=
```

- Build the simulator:

```
env CFLAGS="-target x86_64-apple-macos10.15 \
           -mmacosx-version-min=10.15" \
LDFLAGS="-target x86_64-apple-macos10.15 \
         -mmacosx-version-min=10.15" \
make HOMEBREW_INC= HOMEBREW_LIB=
```

Universal

- The following more complex example builds a **macOS Universal Binary**.
 - The **Universal Binary** will support *three* architectures: **ARM64**, **Intel**, and **Intel Haswell**.
 - The simulator (and **libuv**) will be cross-compiled three times each, once for each architecture.
 - The **lipo** utility will be used to create the universal **dps8** binary (in the top-level build directory).
- Cross-compilation targeting **ARM64, Intel, Intel Haswell (AVX2)**:

- Build **ARM64** `libuv`:

```
make distclean && \
env CFLAGS="-target arm64-apple-macos11 \
           -mmacosx-version-min=11.0" \
LOCAL_CONFOPTS="--host=arm64-apple-darwin" \
make libuvrel HOMEBREW_INC= HOMEBREW_LIB=
```

- Build **ARM64** dps8:

```
env CFLAGS="-target arm64-apple-macos11 \
        -mmacosx-version-min=11.0" \
    LDFLAGS="-target arm64-apple-macos11 \
        -mmacosx-version-min=11.0" \
    make HOMEBREW_INC= HOMEBREW_LIB= && \
    cp -f "src/dps8/dps8" "dps8.arm64"
```

- Build **Intel** libuv:

```
make distclean && \
env CFLAGS="-target x86_64-apple-macos10.15 \
        -mmacosx-version-min=10.15" \
    LOCAL_CONFOPTS="--host=x86_64-apple-darwin" \
    make libuvrel HOMEBREW_INC= HOMEBREW_LIB=
```

- Build **Intel** dps8:

```
env CFLAGS="-target x86_64-apple-macos10.15 \
        -mmacosx-version-min=10.15" \
    LDFLAGS="-target x86_64-apple-macos10.15 \
        -mmacosx-version-min=10.15" \
    make HOMEBREW_INC= HOMEBREW_LIB= && \
    cp -f "src/dps8/dps8" "dps8.x86_64"
```

- Build **Intel Haswell** libuv:

```
make distclean && \
env CFLAGS="-target x86_64h-apple-macos10.15 \
        -mmacosx-version-min=10.15 \
        -march=haswell" \
    LOCAL_CONFOPTS="--host=x86_64-apple-darwin" \
    make libuvrel HOMEBREW_INC= HOMEBREW_LIB=
```

- Build **Intel Haswell** dps8:

```
env CFLAGS="-target x86_64h-apple-macos10.15 \
        -mmacosx-version-min=10.15 \
        -march=haswell" \
    LDFLAGS="-target x86_64h-apple-macos10.15 \
        -mmacosx-version-min=10.15" \
    make HOMEBREW_INC= HOMEBREW_LIB= && \
    cp -f "src/dps8/dps8" "dps8.x86_64h"
```

- Create the **Universal Binary** using lipo:

```
lipo -create -output "dps8" \
    "dps8.x86_64" "dps8.x86_64h" "dps8.arm64" && \
    make distclean && rm -f \
    "dps8.x86_64" "dps8.x86_64h" "dps8.arm64" && \
    lipo "dps8"
```

Windows

- Ensure you are running a supported release of Microsoft **Windows** on a supported platform.

- Microsoft **Windows 10** and **11** on **x86_64** and **i686** are regularly tested by **The DPS8M Development Team**.
- Microsoft **Windows** supports various development and runtime environments, including **Universal CRT**, **MinGW-w64**, **Cygwin**, **Midipix**, **MSYS2**, and many others.
 - Care must be taken to avoid mixing incompatible libraries and tools.
- Cross-compilation is supported. Builds targeting Microsoft **Windows (MinGW and Cygwin)** running on **x86_64**, **i686**, and **ARM64** platforms are regularly cross-compiled from a variety of UNIX-like systems (using **LLVM-MinGW** and **MinGW-GCC**), and from Microsoft **Windows** using **Cygwin**.
- Microsoft **Windows** also provides **Linux** compatibility via the **Windows Subsystem for Linux (WSL)**.
 - **Windows Subsystem for Linux** users should refer to the **Linux** sections of the documentation.

Cygwin

- Ensure you are running a current and up-to-date version of **Cygwin**.
- Only current **64-bit** versions of **Cygwin** are regularly tested by **The DPS8M Development Team**.
 - The **32-bit** version of **Cygwin** was **discontinued** in 2022 and is **no longer supported** for building **DPS8M** (as of **R3.0.2**).

Cygwin prerequisites

- Compilation problems in the **Cygwin** environment are often caused by incomplete or interrupted package installations, or by the installation of packages using non-standard tools (e.g. **apt-cyg**), resulting in missing files and dangling or missing symbolic links.
 - Before attempting to build **DPS8M** using **Cygwin**:
 1. First, update the **Cygwin setup.exe** application to the latest available version.
 2. Update **all** installed packages using the new **Cygwin setup.exe** application.
 3. Install the required prerequisite packages using **Cygwin setup.exe**:
 - * **autoconf**
 - * **cmake**
 - * **cygcheck**
 - * **gcc**
 - * **libtool**
 - * **libuv1**
 - * **libuv1-devel**
 - * **make**
 - * **pkg-config**
 - * **unzip**
 - * **wget**
 4. **Most importantly**, invoke the **cygcheck** utility (i.e. **cygcheck -cv**) to verify the integrity of all currently installed packages and correct any problems before continuing.

Standard Cygwin compilation

- Build the simulator from the top-level source directory (using **GNU Make**):

```
make
```

Cygwin-hosted cross-compilation to MinGW

The following commands will download and cross-compile a local native **libuv** library and then cross-compile the simulator.

You **must** perform a 'make distclean' followed by an 'rm -rf \${HOME}/libuv-build' before building for a different target (or changing build flags).

In the following cross-compilation examples, the *latest* **libuv** sources (from the *v1.x* git branch) are used, but the current official release (available from <https://libuv.org/>) can also be used.

Windows i686

- Using **GCC** (the **Cygwin mingw64-i686-gcc-core** package) to cross-compile a native **32-bit** Windows executable (not depending on Cygwin):

- Build libuv:

```
mkdir -p "${HOME}/libuv-build" && \
mkdir -p "${HOME}/libuv-win32-i686" && \
( cd "${HOME}/libuv-build" && \
  wget -v "https://github.com/libuv/libuv/archive/v1.x.zip" && \
  unzip -xa "v1.x.zip" && cd "libuv-1.x" && \
  mkdir -p "build" && cd "build" && \
  cmake .. -DCMAKE_SYSTEM_NAME="Windows" \
    -DCMAKE_SYSTEM_VERSION="10" \
    -DCMAKE_C_COMPILER="i686-w64-mingw32-gcc" \
    -DCMAKE_INSTALL_PREFIX="${HOME}/libuv-win32-i686" && \
  cmake --build . && cmake --install . )
```

- Build the simulator:

```
env CFLAGS="-I${HOME}/libuv-win32-i686/include -D__MINGW64__" \
  CC="i686-w64-mingw32-gcc" \
  LDFLAGS="-L${HOME}/libuv-win32-i686/lib" NEED_128=1 \
  make CROSS="MINGW64"
```

- The compiled native binary will require `libwinpthread-1.dll` (located at `/usr/i686-w64-mingw32/sys-root/mingw/bin/libwinpthread-1.dll`) and `libuv.dll` (located at `${HOME}/libuv-win32-i686/bin/libuv.dll`) at runtime.

★ It is sufficient to copy these files into the directory containing the `dps8.exe` binary.

Windows x86_64

- Using **GCC** (the **Cygwin mingw64-x86_64-gcc-core** package) to cross-compile a native **64-bit** Windows executable (not depending on Cygwin):

- Build libuv:

```
mkdir -p "${HOME}/libuv-build" && \
mkdir -p "${HOME}/libuv-win32-x86_64" && \
( cd "${HOME}/libuv-build" && \
  wget -v "https://github.com/libuv/libuv/archive/v1.x.zip" && \
  unzip -xa "v1.x.zip" && cd "libuv-1.x" && \
  mkdir -p "build" && cd "build" && \
  cmake .. -DCMAKE_SYSTEM_NAME="Windows" \
    -DCMAKE_SYSTEM_VERSION="10" \
    -DCMAKE_C_COMPILER="x86_64-w64-mingw32-gcc" \
    -DCMAKE_INSTALL_PREFIX="${HOME}/libuv-win32-x86_64" && \
  cmake --build . && cmake --install . )
```

- Build the simulator:

```
env CFLAGS="-I${HOME}/libuv-win32-x86_64/include -D__MINGW64__" \
    CC="x86_64-w64-mingw32-gcc" \
    LDFLAGS="-L${HOME}/libuv-win32-x86_64/lib" \
    make CROSS="MINGW64"
```

- The compiled native binary will require `libwinpthread-1.dll` (located at `/usr/x86_64-w64-mingw32/sys-root/mingw/bin/libwinpthread-1.dll`) and `libuv.dll` (located at `${HOME}/libuv-win32-x86_64/bin/libuv.dll`) at runtime.

* It is sufficient to copy these files into the directory containing the `dps8.exe` binary.

MSYS2

- **DPS8M** can be built as a native **MSYS2** application without special configuration, using the “**MSYS2 Environment**”.
- Cross-compilation using the **MSYS2**-provided **MINGW32**, **MINGW64**, **UCRT64**, **CLANG32**, **CLANG64**, and **CLANGARM64** environments is *currently untested*.

Unix-hosted LLVM-MinGW Clang cross-compilation

The **LLVM-MinGW Clang** toolchain supports building native Windows binaries (**i686**, **x86_64**, **ARMv7**, and **ARM64** systems) on *non-Windows* host systems (or using the **Windows Subsystem for Linux**).

The **LLVM-MinGW Docker Container** provides pre-built and fully configured **LLVM-MinGW** toolchains (including appropriate compiler symlinks) which are regularly used by **The DPS8M Development Team**.

In the following cross-compilation examples, the *latest* **libuv** sources (from the `v1.x` *git* branch) are used, but the current official release (available from <https://libuv.org/>) can also be used.

Windows i686

- Using **Clang** (*the LLVM-MinGW compiler*) to cross-compile a local static `libuv` library and a native **32-bit** Windows/**i686** executable:

- Build `libuv`:

```
mkdir -p "${HOME}/libuv-build" && \
mkdir -p "${HOME}/libuv-win32-i686" && \
( cd "${HOME}/libuv-build" && \
  wget -v "https://github.com/libuv/libuv/archive/v1.x.zip" && \
  unzip -xa "v1.x.zip" && cd "libuv-1.x" && sh ./autogen.sh && \
  ./configure --prefix="${HOME}/libuv-win32-i686" \
  --enable-static --disable-shared --host="i686-w64-mingw32" && \
  make && make install )
```

- Build the simulator:

```
env CC="i686-w64-mingw32-clang" \
    CFLAGS="-I${HOME}/libuv-win32-i686/include -D__MINGW64__" \
    LDFLAGS="-L${HOME}/libuv-win32-i686/lib" NEED_128=1 \
    make CROSS="MINGW64"
```


Windows x86_64

- Using **Clang** (the **LLVM-MinGW** compiler) to cross-compile a local static `libuv` library and a native **64-bit** Windows/**x86_64** executable:

- Build `libuv`:

```
mkdir -p "${HOME}/libuv-build" && \
mkdir -p "${HOME}/libuv-win32-x86_64" && \
( cd "${HOME}/libuv-build" && \
  wget -v "https://github.com/libuv/libuv/archive/v1.x.zip" && \
  unzip -xa "v1.x.zip" && cd "libuv-1.x" && sh ./autogen.sh && \
  ./configure --prefix="${HOME}/libuv-win32-x86_64" \
  --enable-static --disable-shared --host="x86_64-w64-mingw32" && \
  make && make install )
```

- Build the simulator:

```
env CC="x86_64-w64-mingw32-clang" \
  CFLAGS="-I${HOME}/libuv-win32-x86_64/include -D__MINGW64__" \
  LDFLAGS="-L${HOME}/libuv-win32-x86_64/lib" \
  make CROSS="MINGW64"
```

Windows ARM64

- Using **Clang** (the **LLVM-MinGW** compiler) to cross-compile a local static `libuv` library and a native **64-bit** Windows/**ARM64** executable:

- Build `libuv`:

```
mkdir -p "${HOME}/libuv-build" && \
mkdir -p "${HOME}/libuv-win32-arm64" && \
( cd "${HOME}/libuv-build" && \
  wget -v "https://github.com/libuv/libuv/archive/v1.x.zip" && \
  unzip -xa "v1.x.zip" && cd "libuv-1.x" && sh ./autogen.sh && \
  ./configure --prefix="${HOME}/libuv-win32-arm64" \
  --enable-static --disable-shared --host="aarch64-w64-mingw32" && \
  make && make install )
```

- Build the simulator:

```
env CC="aarch64-w64-mingw32-clang" \
  CFLAGS="-I${HOME}/libuv-win32-arm64/include -D__MINGW64__" \
  LDFLAGS="-L${HOME}/libuv-win32-arm64/lib" \
  make CROSS="MINGW64"
```

Unix-hosted MinGW-w64 GCC cross-compilation

The **MinGW-w64 GCC** toolchain supports building native Windows (**i686** and **x86_64**) executables on *non-Windows* host systems (or **Windows** using the **Windows Subsystem for Linux**).

- Many **MinGW-w64 toolchains** are available for a wide variety of host platforms and operating systems.
- Version **9.0** is the *minimum* version of **MinGW-w64** tested with **DPS8M**; version **11.0** (or later) is *strongly* recommended.
- The DPS8M Development Team** regularly cross-compile **Windows** executables using **GCC**-based **MinGW-w64** toolchains on **Alpine Linux** and **Fedora Linux** host systems.

In the following cross-compilation examples, the *latest* **libuv** sources (from the `v1.x git` branch) are used, but the current official release (available from <https://libuv.org/>) can also be used.

Windows i686

- Using **GCC** (the **MinGW-w64** compiler) to cross-compile a local static `libuv` library and a native **32-bit** Windows/**i686** executable:

- Build `libuv`:

```
mkdir -p "${HOME}/libuv-build" && \
mkdir -p "${HOME}/libuv-win32-i686" && \
( cd "${HOME}/libuv-build" && \
  wget -v "https://github.com/libuv/libuv/archive/v1.x.zip" && \
  unzip -xa "v1.x.zip" && cd "libuv-1.x" && sh ./autogen.sh && \
  ./configure --prefix="${HOME}/libuv-win32-i686" \
    --enable-static --disable-shared --host="i686-w64-mingw32" && \
  make && make install )
```

- Build the simulator:

```
env CC="i686-w64-mingw32-gcc" \
  CFLAGS="-I${HOME}/libuv-win32-i686/include \
    -D__MINGW64__ -pthread" \
  LDFLAGS="-L${HOME}/libuv-win32-i686/lib -lpthread" \
  NEED_128=1 \
  make CROSS="MINGW64"
```

Windows x86_64

- Using **GCC** (the **MinGW-w64** compiler) to cross-compile a local static `libuv` library and a native **64-bit** Windows/**x86_64** executable:

- Build `libuv`:

```
mkdir -p "${HOME}/libuv-build" && \
mkdir -p "${HOME}/libuv-win32-x86_64" && \
( cd "${HOME}/libuv-build" && \
  wget -v "https://github.com/libuv/libuv/archive/v1.x.zip" && \
  unzip -xa "v1.x.zip" && cd "libuv-1.x" && sh ./autogen.sh && \
  ./configure --prefix="${HOME}/libuv-win32-x86_64" \
    --enable-static --disable-shared --host="x86_64-w64-mingw32" && \
  make && make install )
```

- Build the simulator:

```
env CC="x86_64-w64-mingw32-gcc" \
  CFLAGS="-I${HOME}/libuv-win32-x86_64/include \
    -D__MINGW64__ -pthread" \
  LDFLAGS="-L${HOME}/libuv-win32-x86_64/lib -lpthread" \
  make CROSS="MINGW64"
```

Simulator Command Reference

This chapter provides reference documentation for the **DPS8M** simulator command set.

- This information is also available from within the simulator; it is accessible by using the interactive [HELP](#) command.

!

Executing System Commands

- The simulator can execute host operating system commands with the “!” (*spawn*) command.

“!”	Spawn the hosts default command interpreter
“! <command>”	Execute the host operating system command

- **NOTE:** The *exit status* from the command which was executed is set as the *command completion status* for the “!” command. This may influence any enabled [ON](#) condition traps.

ASSERT

The [ASSERT](#) command tests a simulator state condition and halts command file execution if the condition is false:

```
ASSERT <Simulator State Expressions>
```

- If the indicated expression evaluates to false, the command completes with an [AFAIL](#) condition. By default, when a command file encounters a command which returns the [AFAIL](#) condition, it will exit the running command file with the [AFAIL](#) status to the calling command file. This behavior can be changed with the [ON](#) command as well as switches to the invoking [DO](#) command.

Examples

The command file below might be used to bootstrap a hypothetical system that halts after the initial load from disk. The [ASSERT](#) command can then be used to confirm that the load completed successfully by examining the CPU’s “A” register for the expected value:‘

```
; Example INI file
BOOT
; A register contains error code; 0 = good boot
ASSERT A=0
```

```
RUN
```

- In the above example, if the “A” register is *not* 0, the “`ASSERT A=0`” command will be displayed to the user, and the command file will be aborted with an “`Assertion failed`” message. Otherwise, the command file will continue to bring up the system.
- See the **IF** command documentation for more information and details regarding simulator state expressions.

ATTACH (AT)

The **ATTACH** (abbreviation **AT**) command associates a unit and a file:

```
ATTACH <unit> <filename>
```

Some devices have more detailed or specific help available with:

```
HELP <device> ATTACH
```

Switches

-n If the “-n” switch is specified when **ATTACH** is executed, a new file will be created when the filename specified does not exist, or an existing file will have its size truncated to zero, and an appropriate message is printed.

-e If the file does not exist, and the “-e” switch *was not* specified, a new file is created, and an appropriate message is printed. If the “-e” switch *was* specified, a new file is *not* created, and an error message is printed.

-r If the “-r” switch is specified, or the file is write protected by host operating system, **ATTACH** tries to open the file in read only mode. If the file does not exist, or the unit does not support read only operation, an error occurs. Input-only devices, such as card readers, or storage devices with write locking switches, such as disks or tapes, support read only operation - other devices do not. If a file is attached read only, its contents can be examined but not modified.

-q If the “-q” switch is specified when creating a new file (“-n”) or opening one read only (“-r”), the message announcing this fact is suppressed.

-f For simulated magnetic tapes, the **ATTACH** command can specify the format of the attached tape image file:

```
ATTACH -f <tape_unit> <format> <filename>
```

- The currently supported magnetic tape image file formats are:

“ SIMH ”	The SIMH / DPS8M native portable tape format
“ E11 ”	The <i>D Bit Ersatz-11</i> simulator format
“ TPC ”	The TPC format (<i>used by SIMH prior to V2.3</i>)
“ P7B ”	The Paul Pierce 7-track tape archive format

- The default tape format can also be specified with the **SET** command prior to using the **ATTACH** command:

```
SET <tape_unit> FORMAT=<format>
ATTACH <tape_unit> <filename>
```

- The format of a currently attached tape image can be displayed with the **SHOW FORMAT** command:

```
SHOW <unit> FORMAT
```

Examples

The following example illustrates common **ATTACH** usage:

```
; Associate the tape image file "12.8MULTICS.tap" with the tape0 unit
; in read-only mode, where tape0 corresponds to the first tape device.
ATTACH -r tape0 12.8MULTICS.tap

; Associate the disk image file "root.dsk" with the disk0 unit.
; The disk0 unit corresponds to the first disk device.
ATTACH disk0 root.dsk
```

AUTOINPUT (AI)

The **AUTOINPUT** command (abbreviated **AI**) provides the specified input to the primary operator console (OPC0):

```
AUTOINPUT <string>
```

- To send a **<CR><LF>** to the console, include “\n” in the *string*.
- Specifying “\z” as the content of the *string* will end all autoinput from the invoking script.
- The **AUTOINPUT** command can open the console for input only when a specific *matching string* is found.
 - To specify a *matching string*, use the form of “\yString\y” for a substring match, or “\xString\x” for an exact match.

Examples

```
; Opens the console when AUTOINPUT sees the "M->" string.
; Any line of text containing this string will match.
AUTOINPUT \yM->\y

; Open the console when AUTOINPUT sees the "Ready" string.
; A line of text containing only this exact string will match.
AUTOINPUT \xReady\x
```

AUTOINPUT2 (AI2)

The **AUTOINPUT2** command (abbreviated **AI2**) provides the specified input to the secondary operator console (OPC1).

- Refer to the documentation for the **AUTOINPUT** command for **AUTOINPUT2** usage.

BOOT (BO)

The **BOOT** command (*abbreviated BO*) resets all devices and bootstraps the device and unit given by its argument. If no unit is supplied, unit 0 is bootstrapped. The specified unit must be **ATTACH**'ed.

When booting Multics, the boot device should always be **iom0**. Assuming a tape is attached to the **tape0** device, it will be bootstrapped into memory and the system will transfer control to the boot record.

Example

```
; Boot Multics using iom0
boot iom0
```

BURST

Burst process output from printer.

CABLE (C)

The **CABLE** command (*abbreviated C*) connects (or “strings”) a simulated cable between devices.

```
CABLE <device> <port/channel> <device> {port/channel}
```

Examples

- Connect a cable from (*system controller unit*) “**SCU_i**” port “**j**” to (*central processing unit*) “**CPU_k**” port “**l**”.

```
CABLE SCUi j CPUk l
```

- Connect a cable from “**SCU_i**” port “**j**” to (*input/output multiplexer*) “**IOM_k**” port “**l**”.

```
CABLE SCUi j IOMk l
```

- Connect a cable from “**IOM_i**” channel “**j**” to (*magnetic tape processor*) “**MTP_k**” port “**l**”, where “**l**” defaults to “**0**” when not specified.

```
CABLE IOMi j MTPk
CABLE IOMi j MTPk l
```

- Connect a cable from “**IOM_i**” channel “**j**” to (*mass storage processor*) “**MSP_k**” port “**l**”, where “**l**” defaults to “**0**” when not specified.

```
CABLE IOMi j MSPk
CABLE IOMi j MSPk l
```

- Connect a cable from “**IOM_i**” channel “**j**” to (*integrated peripheral controller*) “**IPCK**” port “**l**”, where “**l**” defaults to “**0**” when not specified.

```
CABLE IOMi j IPCK
CABLE IOMi j IPCK l
```

- Connect a cable from “**IOMi**” channel “**j**” to (*operator console*) “**OPCK**”.

```
CABLE IOMi j OPCK
```

- Connect a cable from “**IOMi**” channel “**j**” to (*front-end network processor*) “**FNPk**”.

```
CABLE IOMi j FNPk
```

- Connect a cable from “**MTPi**” device code “**j**” to (*tape drive*) “**TAPEk**”.

```
CABLE MTPi j TAPEk
```

- Connect a cable from “**IPCi**” device code “**j**” to (*disk drive*) “**DISKk**”.

```
CABLE IPCi j DISKk
```

- Connect a cable from “**MSPi**” device code “**j**” to “**DISKk**”.

```
CABLE MSPi j DISKk
```

- Connect a cable from (*unit record processor*) “**URPi**” device code “**j**” to (*card reader*) “**RDRk**”.

```
CABLE URPi j RDRk
```

- Connect a cable from “**URPi**” device code “**j**” to (*card punch*) “**PUNK**”.

```
CABLE URPi j PUNK
```

- Connect a cable from “**URPi**” device code “**j**” to (*printer*) “**PRTk**”.

```
CABLE URPi j PRTk
```

UNCABLE (U)

The “**UNCABLE**” command (*abbreviated U*) removes (or “*unstrings*”) a simulated cable.

```
UNCABLE <device> <port/channel> <device>
```

Example

- Unstring the cable connecting “**IOM0**” channel “**12**” to “**MSP0**”.

```
UNCABLE IOM0 12 MSP0
```

CABLE_RIPOUT

The “**CABLE_RIPOUT**” command (*alias* “**CABLE RIPOUT**”) removes (or *unstrings*) **all** cables from the configuration.

Example

```
CABLE RIPOUT
CABLE_RIPOUT
```

CABLE_SHOW

The “**CABLE_SHOW**” command (*alias* “**CABLE SHOW**”) prints the current cabling configuration in human readable form.

Example

```
sim> CABLE SHOW
SCU <--> IOM
  SCU port --> IOM port
  0  0      0  0
  0  1      1  0
  1  0      0  1
  1  1      1  1
  2  0      0  2
  2  1      1  2
  3  0      0  3
  3  1      1  3

SCU <--> CPU
  SCU port --> CPU port
  0  2      5  0
  0  3      4  0
  0  4      3  0
  0  5      2  0
  0  6      1  0
  0  7      0  0
  1  2      5  1
  1  3      4  1
  1  4      3  1
  1  5      2  1
  1  6      1  1
  1  7      0  1
  2  2      5  2
  2  3      4  2
  2  4      3  2
  2  5      2  2
  2  6      1  2
  2  7      0  2
  3  2      5  3
  3  3      4  3
  3  4      3  3
  3  5      2  3
  3  6      1  3
```


3 7 0 3

IOM <--> controller

IOM	chan	-->	ctlr	ctlr	chan	device	board	command	
			idx	port	type				
0	10		0	0	MTP	PSI	0x4e5480	0x5aaa60	0x459660
0	11		0	0	IPC	PSI	0x4e5540	0x5abb60	0x433f10
0	12		0	0	MSP	PSI	0x4e5600	0x5ab2e0	0x433f10
0	13		0	0	URP	PSI	0x4e56c0	0x4e4b40	0x460cd0
0	14		1	0	URP	PSI	0x4e56c0	0x4e4bc8	0x460cd0
0	15		2	0	URP	PSI	0x4e56c0	0x4e4c50	0x460cd0
0	16		3	0	FNP	Direct	0x4e3d00	0x4e3f58	0x44c490
0	17		0	0	FNP	Direct	0x4e3d00	0x4e3dc0	0x44c490
0	18		1	0	FNP	Direct	0x4e3d00	0x4e3e48	0x44c490
0	19		2	0	FNP	Direct	0x4e3d00	0x4e3ed0	0x44c490
0	20		4	0	FNP	Direct	0x4e3d00	0x4e3fe0	0x44c490
0	21		5	0	FNP	Direct	0x4e3d00	0x4e4068	0x44c490
0	22		6	0	FNP	Direct	0x4e3d00	0x4e40f0	0x44c490
0	23		7	0	FNP	Direct	0x4e3d00	0x4e4178	0x44c490
0	30		0	0	OPC	CPI	0x4e4640	0x4e4700	0x41e010
0	40		3	0	URP	PSI	0x4e56c0	0x4e4cd8	0x460cd0
0	41		4	0	URP	PSI	0x4e56c0	0x4e4d60	0x460cd0
0	42		5	0	URP	PSI	0x4e56c0	0x4e4de8	0x460cd0
0	43		1	0	OPC	CPI	0x4e4640	0x4e4788	0x41e010
0	45		6	0	URP	PSI	0x4e56c0	0x4e4e70	0x460cd0
0	46		7	0	URP	PSI	0x4e56c0	0x4e4ef8	0x460cd0
0	47		8	0	URP	PSI	0x4e56c0	0x4e4f80	0x460cd0
0	48		9	0	URP	PSI	0x4e56c0	0x4e5008	0x460cd0
1	10		0	1	MTP	PSI	0x4e5480	0x5aaa60	0x459660
1	11		0	1	IPC	PSI	0x4e5540	0x5abb60	0x433f10
1	12		0	1	MSP	PSI	0x4e5600	0x5ab2e0	0x433f10

controller <--> device

MTP	dev_code	-->	TAPE	command
0	1		1	0x459660
0	2		2	0x459660
0	3		3	0x459660
0	4		4	0x459660
0	5		5	0x459660
0	6		6	0x459660
0	7		7	0x459660
0	8		8	0x459660
0	9		9	0x459660
0	10		10	0x459660
0	11		11	0x459660
0	12		12	0x459660
0	13		13	0x459660
0	14		14	0x459660
0	15		15	0x459660
0	16		16	0x459660
IPC	dev_code	-->	DISK	command
0	0		0	0x433f10
0	1		1	0x433f10
0	2		2	0x433f10
0	3		3	0x433f10

```

0      4      14  0x433f10
0      5      15  0x433f10
0      6      16  0x433f10
0      7      17  0x433f10
0      8      18  0x433f10
0      9      19  0x433f10
0     10     20  0x433f10
0     11     21  0x433f10
0     12     22  0x433f10
0     13     23  0x433f10
0     14     24  0x433f10
0     15     25  0x433f10
MSP dev_code --> DISK  command
0      1      4  0x433f10
0      2      5  0x433f10
0      3      6  0x433f10
0      4      7  0x433f10
0      5      8  0x433f10
0      6      9  0x433f10
0      7     10  0x433f10
0      8     11  0x433f10
0      9     12  0x433f10
0     10     13  0x433f10
URP dev_code --> URP   command
0      1      0  0x42a960
1      1      0  0x429800
2      1      0  0x45c610
3      1      1  0x45c610
4      1      2  0x45c610
5      1      3  0x45c610
6      1      1  0x42a960
7      1      2  0x42a960
8      1      1  0x429800
9      1      2  0x429800

```

CABLE DUMP


The “**CABLE DUMP**” command prints the current cabling configuration in great detail.

CABLE GRAPH

The “**CABLE GRAPH**” command prints the current cabling configuration in the “**DOT**” graph description language (suitable for rendering with *GraphViz*, etc).


Complete Cabling Graph

The following is a **complete** cabling graph of the *default base system*:




CPU / SCU / IOM Cabling Graph

The following graph shows the cabling configuration of the *default base system's* “CPU”, “SCU”, and “IOM” devices:




Storage Cabling Graph

The following graph shows the cabling configuration of the *default base system's storage* devices:



Controller Cabling Graph

The following graph shows the cabling configuration of the *default base system's controller* devices:



See the “**Simulator Defaults**” chapter for more details (including the full output of the “**CABLE DUMP**” command).

CALL

Control can be transferred to a labeled subroutine using **CALL**.

Example

```
CALL routine
BYE

:routine
ECHO routine called
RETURN
```

CHECKPOLL

Set polling check rate (in polling intervals).

CLRAUTOINPUT

The `CLRAUTOINPUT` command clears the auto-input buffer for the primary operator console (OPC0).

- This is normally not required, but may be useful for developers or when writing complex scripts.

CLRAUTOINPUT2

The `CLRAUTOINPUT2` command clears the auto-input buffer for the secondary operator console (OPC1).

- Refer to the documentation for the `CLRAUTOINPUT` command for `CLRAUTOINPUT2` usage.

CONTINUE (CO)

The `CONTINUE` command (*abbreviated* `CONT` or `CO`) resumes execution (if execution was stopped, possibly due to hitting a breakpoint) at the current program counter without resetting any devices.

DEFAULT_BASE_SYSTEM

The `DEFAULT_BASE_SYSTEM` command restores the configuration of the simulator to startup defaults by executing the *default base system script*.

- For complete details including all commands executed by the *default base system script*, see the “**Default Base System Script**” section of the “**Simulator Defaults**” chapter of this manual.

DETACH (DET)

The `DETACH` (*abbreviation* `DET`) command breaks the association between a unit and its backing file or device:

<code>DETACH ALL</code>	Detach all units
<code>DETACH <unit></code>	Detach specified unit

- **NOTE:** The `EXIT` command performs an automatic `DETACH ALL`.

DO

The simulator can invoke another script file with the “DO” command:

```
DO <filename> {arguments...}           execute commands in specified file
```

The “DO” command allows command files to contain substitutable arguments. The string “%n”, where “n” is a number between “1” and “9”, is replaced with argument “n” from the “DO” command line. (i.e. “%0”, “%1”, “%2”, etc.). The string “%0” is replaced with “<filename>”. The sequences “\%” and “\\” are replaced with the literal characters “%” and “\”, respectively. Arguments with spaces must be enclosed in matching single or double quotation marks.

- **NOTE:** Nested “DO” commands are supported, up to ten invocations deep.

Switches

–v If the switch “–v” is specified, commands in the command file are echoed *before* they are executed.

–e If the switch “–e” is specified, command processing (including nested command invocations) will be aborted if any command error is encountered. (A simulation stop **never** aborts processing; use [ASSERT](#) to catch unexpected stops.) Without this switch, all errors except [ASSERT](#) failures will be ignored, and command processing will continue.

–o If the switch “–o” is specified, the [ON](#) conditions and actions from the calling command file will be inherited by the command file being invoked.

–q If the switch “–q” is specified, *quiet mode* will be explicitly enabled for the called command file, otherwise the *quiet mode* setting is inherited from the calling context.

ECHO

The [ECHO](#) command is a useful way of annotating command files. [ECHO](#) prints out its arguments to the console (and to any applicable log file):

```
ECHO <string>           Output string to console
```

NOTE: If no arguments are specified, [ECHO](#) prints a blank line. This may be used to provide spacing for console messages or log file output.

EVALUATE

The [EVAL](#) command evaluates a symbolic expression and returns the equivalent numeric value.

EXIT (QUIT, BYE)

The **EXIT** command (*synonyms* **QUIT** and **BYE**) exits the simulator, returning control to the host operating system.

FNPSEVERADDRESS

The **FNPSEVERADDRESS** command directs the simulator to bind the simulated FNP (*front-end network processor*) **TELNET** server to the specified “<address>” of the host system. The **TELNET** server answers incoming connections and presents a list of open communication channels to the user. If the **FNPSEVERADDRESS** command is not issued prior to FNP bootload, a default “<address>” of “0.0.0.0” is used (*i.e.* listening to all addresses). Only IPv4 addresses may be specified, using quad-dotted decimal notation.

```
FNPSEVERADDRESS <address>
```

Example

- Listen on “127.0.0.1”:

```
FNPSEVERADDRESS 127.0.0.1
```

See also: [FNPSEVERPORT](#).

FNPSEVERPORT

The **FNPSEVERPORT** command directs the simulator to listen for FNP (*front-end network processor*) **TELNET** server connections on the specified “<port>” of the host system. If the **FNPSEVERPORT** command is not issued prior to FNP bootload, a default “<port>” of “6180” is used.

```
FNPSEVERPORT <port>
```

Example

- Listen on port “6180” (*the default port*):

```
FNPSEVERPORT 6180
```

See also: [FNPSEVERADDRESS](#).

FNPSTART

Directs the simulator to immediately start listening for FNP connections.

GO

The **GO** command does *not* reset devices, deposits its argument (if given) in the PC, and starts execution. If no argument is given, execution starts at the current PC (program counter).

GOTO

Commands in a command file execute in sequence until either an error trap occurs (when a command completes with an error status), or when an explicit request is made to start command execution elsewhere with the **GOTO** command:

```
GOTO <label>
```

- Labels are lines in a command file which the first non-whitespace character is a “:”.
- The target of a **GOTO** is the first matching label in the current **DO** command file which is encountered.

Example

The following example illustrates usage of the **GOTO** command (by creating an infinite loop):

```
:Label
:: This is a loop.
GOTO Label
```

IF

The **IF** command tests a simulator state condition and executes additional commands if the condition is true:

```
IF <Simulator State Expressions> commandtoprocess{; additionalcommand}...
```

Examples

The command file below might be used to bootstrap a hypothetical system that halts after the initial load from disk. The **IF** command can then be used to confirm that the load completed successfully by examining the CPU’s “A” register for an expected value:

```
; Example INI file
BOOT
; A register contains error code; 0 = good boot
IF NOT A=0 echo Boot failed - Failure Code ; EX A; exit AFAIL
RUN
```

- In the above example, if the “A” register is *not* 0, the message “**Boot failed - Failure Code**” will be displayed, the contents of the “A” register will be displayed, and the command file will be aborted with an “**Assertion failed**” message. Otherwise, the command file will continue to bring up the system.

Conditional Expressions

The **IF** and **ASSERT** commands evaluate the following two different forms of conditional expressions.

Simulator State Expressions

The values of simulator registers can be evaluated with:

```
{NOT} {<dev>} <reg>|<addr>{<logical-op><value>}<conditional-op><value>
```

- If “<dev>” is not specified, CPU is assumed. “<reg>” is a register belonging to the indicated device.
- The “<addr>” is an address in the address space of the indicated device.
- The “<conditional-op>” and optional “<logical-op>” are the same as those used for “search specifiers” by the EXAMINE and DEPOSIT commands. The “<value>” is expressed in the radix specified for “<reg>”, not in the radix for the device when referencing a register; when an address is referenced the device radix is used as the default.
- If “<logical-op>” and “<value>” are specified, the target register value is first altered as indicated. The result is then compared to the “<value>” via the “<conditional-op>”.
 - If the result is *true*, the command(s) are executed before proceeding to the next line in the command file.
 - If the result is *false*, the next command in the command file is processed.

String Comparison Expressions

String Values can be compared with:

```
{-i} {NOT} "<string1>" <compare-op> "<string2>"
```

- The “-i” switch, if present, causes a comparison to be case insensitive.
- The “<string1>” and “<string2>” arguments are quoted string values which may have environment variables substituted as desired.
- The “<compare-op>” may be one of:

“==”	equal
“ EQU ”	equal
“!=”	not equal
“ NEQ ”	not equal
“<”	less than
“ LSS ”	less than
“<=”	less than or equal
“ LEQ ”	less than or equal
“>”	greater than
“ GTR ”	greater than
“>=”	greater than or equal
“ GEQ ”	greater than or equal

- **NOTE:** Comparisons are *generic*. This means that if both “<string1>” and “<string2>” are comprised of all numeric digits, then the strings are converted to numbers and a numeric comparison is performed. For example, the comparison “+1 EQU 1” evaluates to *true*.

LOAD (UNLOAD)

The **LOAD** and **UNLOAD** commands mount or unmount a disk or tape image and signals Multics.

LUF (NOLUF)

The **LUF** and **NOLUF** commands enable or disable normal LUF (*lockup fault*) handling.

MOUNT

Mount tape image and signal Multics

NEXT (N)

The **NEXT** command (*abbreviated N*) resumes execution at the current PC for one instruction, attempting to execute *through* subroutine calls. If the next instruction to be executed is *not* a subroutine call, then one instruction is executed.

ON

The **ON** command performs actions after a condition, or clears a condition.

<code>ON <condition> <action></code>	Perform action after condition
<code>ON <condition></code>	Clears action of specified condition

POLL

Set polling interval (in milliseconds)

PROCEED (IGNORE)

The **PROCEED** (or **IGNORE**) command does nothing. It is potentially useful as a placeholder for any **ON** action condition that should be explicitly ignored, allowing command file execution to continue without taking any specific action.

READY

Signal Multics that media is ready

RESET

The **RESET** command (*abbreviated RE*) resets a device or the entire simulator to a predefined condition. If the switch “-p” is specified, the device is reset to its initial power-on state:

RESET	resets all devices
RESET -p	power-cycle all devices
RESET ALL	resets all devices
RESET <device>	resets the specified <device>

- Typically, **RESET** *aborts* in-progress I/O operations, *clears* any interrupt requests, and returns the device to a quiescent state.
- It does **NOT** clear the main memory or affect associated I/O connections.

RETURN

The **RETURN** command causes the current procedure call to be restored to the calling context, possibly returning a specific return status. If no return status is specified, the return status from the last command executed will be returned. The calling context may have **ON** traps defined which may redirect command flow in that context.

RETURN	return from command file with last command status
RETURN {-Q} <status>	return from command file with specific status

- The status return can be any numeric value or one of the standard SCPE_ condition names.
- The “-Q” switch on the **RETURN** command will cause the specified status to be returned, but normal error status message printing to be suppressed.

Condition Names

The available standard SCPE_ condition names and their meanings are:

Name	Meaning	Name	Meaning
NXM	Address space exceeded	UNATT	Unit not attached
IOERR	I/O error	CSUM	Checksum error
FMT	Format error	NOATT	Unit not attachable
OPENERR	File open error	MEM	Memory exhausted
ARG	Invalid argument	STEP	Step expired
UNK	Unknown command	RO	Read only argument
INCOMP	Command not completed	STOP	Simulation stopped

Name	Meaning	Name	Meaning
EXIT	Goodbye	TTIERR	Console input I/O error
TTOERR	Console output I/O error	EOF	End of file
REL	Relocation error	NOPARAM	No settable parameters
ALATT	Unit already attached	TIMER	Hardware timer error
SIGERR	Signal handler setup error	TTYERR	Console terminal setup error
NOFNC	Command not allowed	UDIS	Unit disabled
NORO	Read only operation not allowed	INVSW	Invalid switch
MISVAL	Missing value	2FARG	Too few arguments
2MARG	Too many arguments	NXDEV	Non-existent device
NXUN	Non-existent unit	NXREG	Non-existent register
NXPAR	Non-existent parameter	NEST	Nested DO command limit exceeded
IERR	Internal error	MTRLNT	Invalid magtape record length
LOST	Console Telnet connection lost	TTMO	Console Telnet connection timed out
STALL	Console Telnet output stall	AFAIL	Assertion failed
INVREM	Invalid remote console command		

REWIND

Rewind tape

RUN (RU)

The **RUN** command (*abbreviated RU*) resets all devices, deposits its argument, if given, in the PC (program counter), and starts execution. If no argument is given execution starts at the current PC.

SEGLDR

Segment Loader

SET

Logging

Interactions with the simulator session can be recorded to a log file.

SET LOG log_file	Specify the log destination (STDOUT, DEBUG, or filename)
SET NOLOG	Disables any currently active logging

Switches

-N By default, log output is written at the *end* of the specified log file. A new log file can be created if the “-N” switch is used on the command line.

-B By default, log output is written in *text* mode. The log file can be opened for *binary* mode writing if the “-B” switch is used on the command line.

Debug Messages

SET DEBUG debug_file	Specify the debug destination (STDOUT, STDERR, LOG, or filename)
SET NODEBUG	Disables any currently active debug output

Switches

Debug message output contains a timestamp which indicates the number of simulated instructions which have been executed prior to the debug event.

Debug message output can be enhanced to contain additional, potentially useful information.

NOTE: If neither “-T” or “-A” is specified, “-T” is implied.

-T The “-T” switch causes debug output to contain a time of day displayed as `hh:mm:ss.msec`.

-A The “-A” switch causes debug output to contain a time of day displayed as `seconds.msec`.

-R The “-R” switch causes timing to be relative to the start of debugging.

-P The “-P” switch adds the output of the PC (program counter) to each debug message.

-N The “-N” switch causes a new (empty) file to be written to. (The default is to append to an existing debug log file).

-D The “-D” switch causes data blob output to also display the data as **RADIX-50** characters.

-E The “-E” switch causes data blob output to also display the data as “**EBCDIC**” characters.

Environment Variables

SET ENVIRONMENT NAME=val	Set environment variable
SET ENVIRONMENT NAME	Clear environment variable

Command Status Trap Dispatching

SET ON	Enables error checking command execution
SET NOON	Disables error checking command execution
SET ON INHERIT	Enables inheritance of ON state and actions
SET ON NOINHERIT	Disables inheritance of ON state and actions

Command Execution Display

SET VERIFY	Enables display of processed script commands
SET VERBOSE	Enables display of processed script commands
SET NOVERIFY	Disables display of processed script commands
SET NOVERBOSE	Disables display of processed script commands

Command Error Status Display

SET MESSAGE	Re-enables display of script error messages
SET NOMESSAGE	Disables display of script error messages

Command Output Display

SET QUIET	Disables suppression of some messages
SET NOQUIET	Re-enables suppression of some messages

Local Operator Console

SET LOCALOPC	Enables local operator console
SET NOLOCALOPC	Disables local operator console

Command Prompt

SET PROMPT "string"	Sets an alternate simulator prompt string
---------------------	---

Device and Unit Settings

SET <dev> OCT DEC HEX	Set device display radix
SET <dev> ENABLED	Enable device
SET <dev> DISABLED	Disable device
SET <dev> DEBUG{=arg}	Set device debug flags
SET <dev> NODEBUG={arg}	Clear device debug flags
SET <dev> arg{,arg...}	Set device parameters
SET <unit> ENABLED	Enable unit
SET <unit> DISABLED	Disable unit
SET <unit> arg{,arg...}	Set unit parameters
HELP <dev> SET	Displays any device specific SET commands

CPU Configuration

L68 (DPS8M)

“**L68**” configures the “CPU” unit specified to simulate a **Level 68** processor, where “1” or “enable” configures the CPU as a **Level 68** and “0” or “disable” configures the CPU as a **DPS-8/M**.

“**DPS8M**” configures the “CPU” unit specified to simulate a **DPS-8/M** processor, where “1” or “enable” configures the CPU as a **DPS-8/M** and “0” or “disable” configures the CPU as a **Level 68**:

```
L68=<0 or 1>
L68=<disable or enable>
DPS8M=<0 or 1>
DPS8M=<disable or enable>
```

Examples

- Configure CPU0 to simulate a **Level 68** processor. (The default is to simulate a **DPS-8/M**):

```
SET CPU0 L68=1
SET CPU0 DPS8M=0
```

- Configure CPU1 to simulate a **DPS-8/M** processor:

```
SET CPU1 L68=disable
SET CPU1 DPS8M=enable
```

RESET

“**RESET**” will reset the specified “CPU” unit (or *all* “CPU” units when no unit is explicitly specified) when passed an argument of “1”.

```
RESET=<1>
```

Examples

- Reset all CPUs:

```
SET CPU RESET=1
```

- Reset CPU0:

```
SET CPU0 RESET=1
```

INITIALIZE

“**INITIALIZE**” will initialize the specified “CPU” unit (or *all* “CPU” units when no unit is explicitly specified) when passed an argument of “1”.

```
INITIALIZE=<1>
```

Examples

- Initialize all CPUs:

```
SET CPU INITIALIZE=1
```

- Initialize CPU0:

```
SET CPU0 INITIALIZE=1
```

INITIALIZEANDCLEAR (IAC)

“**INITIALIZEANDCLEAR**” (*abbreviated* “**IAC**”) will initialize the specified “CPU” unit and clear it’s state (or initialize *all* “CPU” units and clear their states when no unit is explicitly specified) when passed an argument of “1”.

```
INITIALIZEANDCLEAR=<1>  
IAC=<1>
```

Examples

- Initialize and clear CPUs:

```
SET CPU INITIALIZEANDCLEAR=1
```

- Initialize and clear CPU0:

```
SET CPU0 IAC=1
```

NUNITS

“**NUNITS**” configures the number of “CPU” units.

```
NUNITS=<n>
```

Example

- Set the number of “CPU” units to “6” (*the default number*):

```
SET CPU NUNITS=6
```

KIPS

“KIPS” configures the global CPU lockup fault timer scaling factor.

```
KIPS=<n>
```

When simulating multiple processors, occasional spurious “*Fault in idle process*” messages may be seen when additional CPU’s are brought online. This is caused by a lockup fault occurring while the Multics hardware is waiting on a flag to be set by the CPU being brought online.

Latency guarantees of the original hardware prevent this condition from occurring when the hardware is properly functioning. Unfortunately, without introducing strict hard-realtime requirements for simulated operations such as requiring the simulator execute under the control of a hard-realtime RTOS, there is no practical way to provide Multics these precision timing guarantees.

When running on original hardware, the lockup fault would be triggered by an independent watchdog timer that monitors the CPU’s polling of interrupts. If interrupts would be inhibited for too long, this watchdog timer would run out and trigger the lockup fault. Multics rightfully considers a lockup fault in hardware as indicative of a serious (*possibly fatal*) problem with the faulting CPU.

Unfortunately, what is a clear sign of hardware trouble on real hardware (*i.e* a CPU that is struggling to get up to speed, or running at fluctuating speeds) is the normal, expected, and unavoidable reality when the simulator is running on a general purpose system.

Configuring the “KIPS” scaling factor loosens this hard realtime requirement and avoids spurious lockup faults.

Note that if “KIPS” is set to a large value, a genuine hardware error or broken userspace process will still be detected, although it will take slightly longer for the lockup fault to occur.

Example

- Set the global CPU lockup fault scaling factor for 8 MIPS:

```
SET CPU KIPS=8000
```

It is not expected that the “KIPS” value will require modification by most users under normal operating circumstances. See also: “**STALL**”.

STALL

“**STALL**” configures a stall (*i.e.* a delay) of “<iterations>” when the IC reaches the address specified by “<segno>” and “<offset>”, identified by “<num>”.

```
STALL=<num>:<segno>:<offset>=<iterations>
```

- “<num>” is a number allowing for the identification (and modification) of multiple stall points.

- “<segno>” is the segment number of the Multics segment at which to stall.
- “<offset>” is the offset within the segment specified by “<segno>” at which to stall.
- “<iterations>” is a positive integer representing the number of iterations to loop.

Example

- Configure two stalls, #1 for 250 iterations at “0132:011227”, and #2 for 1250 iterations at “0122:052137”:

```
SET CPU STALL=1=0132:011227=250
SET CPU STALL=2=0122:052137=1250
```

DEBUG (NODEBUG)

“**DEBUG**” enables CPU debugging and/or enables specified debugging options.

“**NODEBUG**” disables CPU debugging and/or disables specified debugging options.

```
DEBUG ; Enables debugging
NODEBUG ; Disables debugging
DEBUG=<list-of-options> ; Enables specified debugging options
NODEBUG=<list-of-options> ; Disables specified debugging options
```

- The “<list-of-options>” is a semicolon (“;”) delimited list of one or more of the following options:

TRACE	TRACEEXT	MESSAGES	REGDUMPAQI	REGDUMPIDX
REGDUMPPR	REGDUMPPPR	REGDUMPDSBR	REGDUMPFILT	REGDUMP
ADDRMOD	APPENDING	NOTIFY	INFO	ERR
WARN	DEBUG	ALL	FAULT	INTR
CORE	CYCLE	CAC	FINAL	AVC

Examples

- Enable the debugging options “**TRACE**” and “**FAULT**” for all “**CPU**” units:

```
SET CPU DEBUG=TRACE; FAULT
```

- Disable all debugging options for all “**CPU**” units:

```
SET CPU NODEBUG
```

- Enable the debugging option “**CYCLE**” for **CPU0** and disable all debugging options for all other “**CPU**” units:

```
SET CPU NODEBUG
SET CPU0 DEBUG=CYCLE
```

CONFIG

The following “**CPU**” configuration options are associated with a specified “**CPU**” unit (*i.e.* CPU n) and are configured using the “**SET**” command (*i.e.* “**SET CPU n CONFIG**”):

```
SET CPU $n$  CONFIG=<set-option>
```

- The following “<set-option>”’s are available, in the form of “<option>=<value>”, for example:

```
SET CPU $n$  CONFIG=<option>=<value>
```

FAULTBASE

“**FAULTBASE**” configures the fault base of the specified “**CPU**” unit:

```
FAULTBASE=<value>
```

Example

- For Multics operation, configure the “<value>” to “**Multics**” (for CPU 0):

```
SET CPU $0$  CONFIG=FAULTBASE=Multics
```

NUM

“**NUM**” configures the CPU number of the specified “**CPU**” unit:

```
NUM=<n>
```

Example

- Set the CPU number of CPU 0 to **1**.

```
SET CPU $0$  CONFIG=NUM=1
```

DATA

“**DATA**” configures the CPU switches of the specified “**CPU**” unit:

```
DATA=<word>
```

Example

- Set CPU 0 switches to “024000717200” (*the default value*).

```
SET CPU $0$  CONFIG=DATA=024000717200
```

See Also

Refer to *GB61-01 Operators Guide, Appendix A* for more details.

STOPNUM

“**STOPNUM**” configures the CPU switches of the specified “**CPU**” unit so that Multics will stop during boot at the check stop specified by “<n>”.

```
STOPNUM=<n>
```

Example

- Set CPU**0** switches so Multics will stop during boot at check stop #2030.

```
SET CPU0 CONFIG=STOPNUM=2030
```

MODE

“**MODE**” configures the operating mode of specified “**CPU**” unit as indicated by “<value>”:

```
MODE=<value>
```

- The supported “<value>”s are:

<value>	Operating mode
“ 0 ” or “ GCOS ”	GCOS operating mode
“ 1 ” or “ Multics ”	Multics operating mode

Examples

- Set the operating mode of CPU**1** to **GCOS** operating mode:

```
SET CPU1 CONFIG=MODE=0
```

- Set the operating mode of CPU**0** to **Multics** operating mode:

```
SET CPU0 CONFIG=MODE=Multics
```

SPEED

“**SPEED**” configures the CPU speed setting of the specified **CPU** unit, where an “<identifier>” of “**0**” indicates a **DPS-8/M Model 70**.

```
SPEED=<identifier>
```

Example

- Configure CPU0 with a speed setting of “0”, indicating a **DPS-8/M Model 70** (the default setting):

```
SET CPU0 CONFIG SPEED=0
```

PORT

“**PORT**” selects the CPU port “<p>” for which subsequent “SET CPU*n* CONFIG=” configuration commands apply:

```
PORT=<p>
```

Example

- Configure **ASSIGNMENT**, **INTERLACE**, **ENABLE**, **INIT_ENABLE**, and **STORE_SIZE** for port “A” on CPU0:

```
SET CPU0 CONFIG=PORT=A
SET CPU0 CONFIG=ASSIGNMENT=0
SET CPU0 CONFIG=INTERLACE=0
SET CPU0 CONFIG=ENABLE=1
SET CPU0 CONFIG=INIT_ENABLE=1
SET CPU0 CONFIG=STORE_SIZE=4M
```

ASSIGNMENT

“**ASSIGNMENT**” configures the CPU port assignment to “<a>” of “CPU” unit “*n*”’s CPU port “*x*”, as specified by a previous “SET CPU*n* CONFIG=PORT=*x*” command:

```
ASSIGNMENT=<a>
```

Example

- Configure the CPU port assignment of CPU1’s port “B” to “2”:

```
SET CPU1 CONFIG=PORT=B
SET CPU1 CONFIG=ASSIGNMENT=2
```

INTERLACE

“**INTERLACE**” configures the position of the *interlace* switch for the currently selected CPU port:

```
INTERLACE=<0, 1, 2>
```

Example

- Configure the position of the *interlace* switch for the currently selected CPU port of CPU0 to “1”:

```
SET CPU0 CONFIG=INTERLACE=1
```

ENABLE

“**ENABLE**” configures whether the currently selected CPU port is enabled, where “0” or “**disable**” is disabled and “1” or “**enable**” is enabled:

```
ENABLE=<0 or 1>  
ENABLE=<disable or enable>
```

INIT_ENABLE

“**INIT_ENABLE**” configures whether *init* is enabled for the currently selected CPU port, where “0” or “**disable**” is disabled and “1” or “**enable**” is enabled:

```
INIT_ENABLE=<0 or 1>  
INIT_ENABLE=<disable or enable>
```

STORE_SIZE

“**STORE_SIZE**” configures the size of memory (in *megawords*) for the currently selected CPU port:

```
STORE_SIZE=<num>M
```

Example

- Configure the memory size of the currently selected CPU port on CPU0 to “4” megawords:

```
SET CPU0 CONFIG=STORE_SIZE=4M
```

ENABLE_CACHE

“**ENABLE_CACHE**” configures whether the CPU cache is enabled for a CPU with CPU cache, where “0” or “**disable**” is disabled and “1” or “**enable**” is enabled:

```
ENABLE_CACHE=<0 or 1>  
ENABLE_CACHE=<disable or enable>
```

Example

- Configure CPU0 to enable the CPU cache, if installed (*the default setting*):

```
SET CPU0 CONFIG=ENABLE_CACHE=1
```


SDWAM

“**SDWAM**” configures whether SDW associative memory is enabled, where “0” or “**disable**” is disabled and “1” or “**enable**” is enabled:

```
SDWAM=<0 or 1>  
SDWAM=<disable or enable>
```

Example

- Configure CPU0 to enable SDW associative memory (*the default setting*):

```
SET CPU0 CONFIG=SDWAM=1
```

PTWAM

“**PTWAM**” configures whether PTW associative memory is enabled, where “0” or “**disable**” is disabled and “1” or “**enable**” is enabled:

```
SDWAM=<0 or 1>  
SDWAM=<enable or disable>
```

Example

- Configure CPU0 to enable PTW associative memory (*the default setting*):

```
SET CPU0 CONFIG=PTWAM=1
```

DIS_ENABLE

“**DIS_ENABLE**” configures whether DIS (*delay until interrupt serviced*) handling is enabled, where “0” or “**disable**” is disabled and “1” or “**enable**” is enabled:

```
DIS_ENABLE=<0 or 1>  
DIS_ENABLE=<disable or enable>
```

Example

- Configure CPU0 to enable DIS handling (*the default setting*):

```
SET CPU0 CONFIG=DIS_ENABLE=1
```

STEADY_CLOCK

“**STEADY_CLOCK**” configures whether the *steady CPU clock* should be enabled, where “0” or “*disable*” is disabled and “1” or “*enable*” is enabled:

```
STEADY_CLOCK=<0 or 1>  
STEADY_CLOCK=<disable or enable>
```

Example

- Configure CPU0 with the *steady CPU clock*:

```
SET CPU0 CONFIG=STEADY_CLOCK=1
```

HALT_ON_UNIMPLEMENTED

“**HALT_ON_UNIMPLEMENTED**” configures whether the simulator should halt when the specified “CPU” unit encounters an unimplemented instruction, where “0” or “*disable*” is disabled and “1” or “*enable*” is enabled.

```
HALT_ON_UNIMPLEMENTED=<0 or 1>  
HALT_ON_UNIMPLEMENTED=<disable or enable>
```

Example

- Configure CPU0 to **not** halt when encountering an unimplemented instruction (*the default setting*):

```
SET CPU0 CONFIG=HALT_ON_UNIMPLEMENTED=0
```

ENABLE_WAM

“**ENABLE_WAM**” configures whether WAM (*word associative memory*) is enabled, where “0” or “*disable*” is disabled and “1” or “*enable*” is enabled:

```
ENABLE_WAM=<0 or 1>  
ENABLE_WAM=<disable or enable>
```

Example

- Configure CPU0 to disable word associative memory (*the default setting*):

```
SET CPU0 CONFIG=ENABLE_WAM=0
```

REPORT_FAULTS

“**REPORT_FAULTS**” configures whether fault reporting is enabled, where “0” or “*disable*” is disabled and “1” or “*enable*” is enabled:

```
REPORT_FAULTS=<0 or 1>  
REPORT_FAULTS=<disable or enable>
```

Example

- Configure CPU0 to disable fault reporting (*the default setting*):

```
SET CPU0 CONFIG=REPORT_FAULTS=0
```

TRO_ENABLE

“**TRO_ENABLE**” configures whether timer runout (*TRO*) is enabled, where “0” or “**disable**” is disabled and “1” or “**enable**” is enabled:

```
TRO_ENABLE=<0 or 1>  
TRO_ENABLE=<disable or enable>
```

Example

- Configure CPU0 to enable TRO (*the default setting*):

```
SET CPU0 CONFIG=TRO_ENABLE=1
```

DRL_FATAL

“**DRL_FATAL**” configures whether a DRL fault is fatal (stopping the simulator), where “0” or “**disable**” is disabled and “1” or “**enable**” is enabled:

```
DRL_FATAL=<0 or 1>  
DRL_FATAL=<disable or enable>
```

Example

- Configure CPU0 to not treat DRL faults as fatal (*the default setting*):

```
SET CPU0 CONFIG=DRL_FATAL=0
```

USEMAP

“**USEMAP**” configures whether to enable mapping, where “0” or “**disable**” is disabled and “1” or “**enable**” is enabled:

```
USEMAP=<0 or 1>  
USEMAP=<disable or enable>
```

Example

- Configure CPU0 to disable mapping (*the default setting*):

```
SET CPU0 CONFIG=USEMAP=0
```

ADDRESS

“**ADDRESS**” configures the CPU address to the specified “<word>”:

```
ADDRESS=<word>
```

Example

- Configure CPU0 address to “000000000000” (*the default setting*):

```
SET CPU0 CONFIG=ADDRESS=000000000000
```

See also

Refer to *GB61-01 Operators Guide, Appendix A* for more details.

PROM_INSTALLED

“**PROM_INSTALLED**” configures whether a CPU identification PROM is installed, where “0” or “disable” is *not installed* and “1” or “enable” is *installed*:

```
PROM_INSTALLED=<0 or 1>  
PROM_INSTALLED=<disable or enable>
```

Example

- Configure CPU0 to install a CPU identification PROM (*the default setting for DPS-8/M processors*):

```
SET CPU0 CONFIG=PROM_INSTALLED=1
```

HEX_MODE_INSTALLED

“**HEX_MODE_INSTALLED**” configures whether the hexadecimal floating point (**HFP**) CPU option is installed, where “0” or “disable” is *not installed* and “1” or “enable” is *installed*:

```
HEX_MODE_INSTALLED=<0 or 1>  
HEX_MODE_INSTALLED=<disable or enable>
```

Example

- Configure CPU0 to install the hexadecimal floating point (**HFP**) CPU option:

```
SET CPU0 CONFIG=HEX_MODE_INSTALLED=1
```

CACHE_INSTALLED

“**CACHE_INSTALLED**” configures whether the CPU cache option is installed, where “0” or “disable” is *not installed* and “1” or “enable” is *installed*:

```
CACHE_INSTALLED=<0 or 1>  
CACHE_INSTALLED=<disable or enable>
```

Example

- Configure CPU0 to install the CPU cache option (*the default setting*):

```
SET CPU0 CONFIG=CACHE_INSTALLED=1
```

CLOCK_SLAVE_INSTALLED

“**CLOCK_SLAVE_INSTALLED**” configures whether the CPU clock slave is installed, where “0” or “disable” is *not installed* and “1” or “enable” is *installed*:

```
CLOCK_SLAVE_INSTALLED=<0 or 1>  
CLOCK_SLAVE_INSTALLED=<disable or enable>
```

Example

- Configure CPU0 to install the CPU clock slave (*the default setting*):

```
SET CPU0 CONFIG=CLOCK_SLAVE_INSTALLED=1
```

ENABLE_EMCALL

“**ENABLE_EMCALL**” configures whether *emcall* is enabled, where “0” or “disable” is disabled and “1” or “enable” is enabled:

```
ENABLE_EMCALL=<0 or 1>  
ENABLE_EMCALL=<disable or enable>
```

Example

- Configure CPU0 to disable *emcall*:

```
SET CPU0 CONFIG=ENABLE_EMCALL=0
```

ISOLTS_MODE

“**ISOLTS_MODE**” configures the CPU in such a way that facilitates running *ISOLTS* diagnostics, where “0” or “disable” is disabled and “1” or “enable” is enabled:

```
ISOLTS_MODE=<0 or 1>  
ISOLTS_MODE=<disable or enable>
```

Example

- Configure CPU0 for *ISOLTS* testing:

```
SET CPU0 CONFIG=ISOLTS_MODE=1
```

NODIS

“**NODIS**” configures whether normal CPU initial DIS state is disabled, where “1” or “**enable**” enables the disabling of the normal state and “0” or “**disable**” disables the disabling the normal state if such disabling was previously enabled:

```
NODIS=<0 or 1>  
NODIS=<disable or enable>
```

Example

- Configure CPU0 to disable the normal initial DIS state:

```
SET CPU0 CONFIG=NODIS=1
```

L68_MODE

“**L68_MODE**” configures the “CPU” unit specified to simulate a **Level 68** processor, where “1” or “**enable**” configures the CPU as a **Level 68** and “0” or “**disable**” configures the CPU as a **DPS-8/M**.

```
L68_MODE=<0 or 1>  
L68_MODE=<disable or enable>
```

Examples

- Configure CPU0 to simulate a **Level 68** processor. (The default is to simulate a **DPS-8/M**):

```
SET CPU0 CONFIG=L68_MODE=1
```

IOM Configuration

NUNITS

“**NUNITS**” configures the number of “**IOM**” units.

```
NUNITS=<n>
```

Example

- Set the number of “**IOM**” units to “2” (*the default number*):

```
SET IOM NUNITS=2
```

DEBUG (NODEBUG)

- TBD

RESET

- TBD

CONFIG

The following “**IOM**” configuration options are associated with a specified “**IOM**” unit (*i.e.* “**IOMn**”) and are configured using the “**SET**” command (*i.e.* “**SET IOMn CONFIG**”):

```
SET IOMn CONFIG=<set-option>
```

- The following “<**set-option**>”s are available, in the form of “<**option**>=<**value**>”, for example:

```
SET IOMn CONFIG=<option>=<value>
```

PORT

“**PORT**” selects the IOM port “<**p**>” for which subsequent “**SET IOMn CONFIG=**” configuration commands apply:

```
PORT=<p>
```

Example

- Select port “0” of **IOM0** for subsequent “**SET IOM0 CONFIG=**” configuration commands:

```
SET IOM0 CONFIG=PORT=0
```

ADDR

* TBD (Address of the port)

INTERLACE

* TBD (Interlace switch setting)

ENABLE

* TBD (Port enabled or disabled)

INITENABLE

* TBD (Init enabled or disabled for port)

HALFSIZE

* TBD (Halfsize setting)

STORE_SIZE

* TBD (Size of memory - one of 32 64 128 256 512 1024 2048 4096 32K 64K 128K 256K 512K 1024K 2048K 4096K 1M 2M 4M, 4M is default.)

MODEL

“**MODEL**” configures the IOM model, where “<model>” is **iom** or **imu**.

```
MODEL=<model>
```

Example

- Set the model of **IOM0** to “**iom**” (*the default model*):

```
SET IOM0 CONFIG=MODEL=iom
```

OS

“**OS**” configures the allowed operating system for the **IOM** unit specified, where “<os>” is **gcos**, **gcosext**, or **multics**.

```
OS=<os>
```

Example

- Set the allowed operating system mode for **IOM0** to **multics** (the default allowed mode):

```
SET IOM0 CONFIG=OS=multics
```

BOOT

“**BOOT**” configures the device to boot from for the **IOM** unit specified, where “<value>” is **disk** or **tape**.

```
BOOT=<value>
```

Example

- Set **IOM0** to boot from “**tape**” (the default boot device setting):

```
SET IOM0 CONFIG=BOOT=tape
```

IOM_BASE

“**IOM_BASE**” configures the base address for the **IOM** unit specified, where “<base_value>” is **Multics** (014), **Multics1** (014), **Multics2** (020), **Multics3** (024), or **Multics4** (030).

```
IOM_BASE=<base_value>
```

Example

- Set the base address of **IOM0** to **Multics** (014) (the default base address):

```
SET IOM0 CONFIG=IOM_BASE=Multics
```

MULTIPLEX_BASE

“**MULTIPLEX_BASE**” configures the multiplex base address for the **IOM** unit specified, where “<n>” is “0120” (for **IOM0**) or “0121” (for **IOM1**).

```
MULTIPLEX_BASE=<n>
```

Example

- Set the multiplex base address of **IOM0** to 0120 (the default multiplex base address):

```
SET IOM0 CONFIG=MULTIPLEX_BASE=0120
```

TAPECHAN

“**TAPECHAN**” configures the default tape channel for the **IOM** unit specified:

```
TAPECHAN=<n>
```

Example

- Set the default tape channel of **IOM0** to 012 (*the default tape channel setting*):

```
SET IOM0 CONFIG=TAPECHAN=012
```

CARDCHAN

“**CARDCHAN**” configures the default card channel for the **IOM** unit specified:

```
CARDCHAN=<n>
```

Example

- Set the default card channel of **IOM0** to 011 (*the default card channel setting*):

```
SET IOM0 CONFIG=CARDCHAN=011
```

SCUPOINT

“**SCUPOINT**” configures which port on the SCU the **IOM** unit specified will be connected to.

```
SCUPOINT=<n>
```

Example

- Set the SCU port of **IOM0** to 0 (*the default port*):

```
SET IOM0 CONFIG=SCUPOINT=0
```

SCU Configuration

DEBUG (NODEBUG)

- TBD

NUNITS

“**NUNITS**” configures the number of “SCU” units.

```
NUNITS=<n>
```

Example

- Set the number of SCU units to “4” (*the default number*):

```
SET SCU NUNITS=6
```

RESET

- TBD

CONFIG

The following “**SCU**” configuration options are associated with a specified “**SCU**” unit (*i.e.* “**SCUn**”) and are configured using the “**SET**” command (*i.e.* “**SET SCUn CONFIG**”):

```
SET SCUn CONFIG=<set-option>
```

- The following “<**set-option**>”s are available, in the form of “<**option**>=<**value**>”, for example:

```
SET SCUn CONFIG=<option>=<value>
```

MODE

* TBD (0 or 1)

MASKA

* TBD (7 for SCU0 by default, and “off” for other SCUs.)

MASKB

* TBD (“off” for all SCUs by default)

PORT0

* TBD (0 or 1)

PORT1

* TBD (0 or 1)

PORT2

* TBD (0 or 1)

PORT3

* TBD (0 or 1)

PORT4

* TBD (0 or 1)

PORT5

* TBD (0 or 1)

PORT6

* TBD (0 or 1)

PORT7

* TBD (0 or 1)

LWRSTORESIZE

* TBD (32 64 128 256 512 1024 2048 4096 32K 64K 128K 256K 512K 1024K 2048K 4096K 1M 2M 4M, 4M is default)

CYCLIC

* TBD (0040 by default)

NEA

* TBD (0200 by default)

ONL

* TBD (014 by default)

INT

* TBD (0 or 1)

LW

* TBD (0 or 1)

ELAPSED_DAYS

* TBD (0 or 1)

STEADY_CLOCK

* TBD (0 or 1, disable or enable)

BULLET_TIME

* TBD (0 or 1, disable or enable)

CLOCK_DELTA

“**CLOCK_DELTA**” modifies the SCU clock to run a user-specified number of seconds ahead (or behind) the host clock, where “0”, the default, is no modification.

```
CLOCK_DELTA=<[-2147483648 to 2147483647]>
```

- Setting “**CLOCK_DELTA**” to a negative value is useful to enable booting older Multics releases (*i.e.* MR12.3 and MR12.5) that are *not* Y2K-compliant without modification.

- Setting “`CLOCK_DELTA`” to a positive value is useful for Multics development or working with disks that were used “in the future”.
- The GNU “`date`” tool (with the help of the Unix shell) can be used to calculate an appropriate value. The following example calculates a value representing a modification of 5 years:

```
printf '%s\n' "$(( $(date --date='5 years' +%s) - $(date +%s) ))"
```

- macOS and BSD users usually have this tool available as “`gdate`” (part of the GNU *coreutils* package, which may require separate installation).
- It is the responsibility of the user to set a reasonable “`CLOCK_DELTA`” value.
 - Multics may not handle times in the year 2043 and beyond.
 - Undefined behavior may result if the modified time is beyond *January 19 2038 03:14:07 UTC* on a host system that measures time as seconds elapsed since *January 1 1970 00:00:00 UTC* (the Unix epoch) and stores the result in a signed 32-bit integer (i.e. Unix systems using 32-bit `time_t`).
- It is not expected that the “`CLOCK_DELTA`” value will require modification by most users under normal operating circumstances.

Examples

- Configure the SCU0 clock to run 5 years ahead of the host clock:

```
SET SCU0 CONFIG=CLOCK_DELTA=157766400
```

- Configure the SCU0 clock to run 33 years, 6 months behind of the host clock:

```
SET SCU0 CONFIG=CLOCK_DELTA=-1057017600
```

TAPE Configuration

DEBUG (NODEBUG)

- TBD

DEFAULT_PATH

“`DEFAULT_PATH`” configures the default path to use when searching for tape files.

```
DEFAULT_PATH=<path>
```

- Setting this option will clear any previous “`ADD_PATH`” parameters.
- If “`DEFAULT_PATH`” is *not* set, the simulator will use the current working directory of the host operating system.
- When using relative paths (beginning with “`.`” or “`..`”) the starting point is the current working directory of the host operating system.

Example

- Set the default path to search for tape files to “./tapes”:

```
SET TAPE DEFAULT_PATH=./tapes
```

ADD_PATH

“ADD_PATH” adds a new tape search path at the end of the current search path list.

```
ADD_PATH=<prefix=directory>
```

- When using relative paths (beginning with “.” or “..”), the starting point is the current working directory of the host operating system.
- If “SET DEFAULT_PATH” is used, all previous “ADD_PATH” entries will be removed.
- New tape search paths cannot be added unless a “DEFAULT_PATH” has been explicitly set.

Example

- Look for tapes with a volume name starting with “BK” in the directory “./tapes/backups”:

```
SET TAPE ADD_PATH=BK=./tapes/backups
```

Notes

- When the tape search path table is evaluated during a tape file lookup, it is processed in order, with the first matching entry being accepted.
- For example, if the following commands are given, a tape with a volume name of “BK001” will be placed in the “./tapes/billing” directory and not the “./tapes/backups” directory, since it begins with the substring “B”, matching the first entry in the search table:

```
SET TAPE DEFAULT_PATH=./tapes/general
SET TAPE ADD_PATH=B=./tapes/billing
SET TAPE ADD_PATH=BK=./tapes/backups
```

- To get the intended effect, the commands may be reordered to ensure names starting with “BK” are checked before names starting with “B”:

```
SET TAPE DEFAULT_PATH=./tapes/general
SET TAPE ADD_PATH=BK=./tapes/backups
SET TAPE ADD_PATH=B=./tapes/billing
```

- The simulator “ATTACH” command used in script files (usually for mounting the boot tape) is *not* aware of the alternative tape search paths. If a directory is needed for an “ATTACH” command, the full path should be specified, for example:

```
ATTACH -r tape0 ./tapes/12.8/12.8MULTICS.tap
```

CAPACITY_ALL

“CAPACITY_ALL” configures the default maximum size (in megabytes) that can be written to a tape file for all tape devices.

```
CAPACITY_ALL=<n>
```

- If “CAPACITY_ALL” is *not* set, the simulator will default to using a maximum size of **40MB**.

Example

- Set the default maximum size of tape files for all tape devices to **40MB**:

```
SET TAPE CAPACITY_ALL=40
```

CAPACITY

“CAPACITY” configures the maximum size (in megabytes) that can be written to a tape file for a specific tape devices.

```
CAPACITY=<n>
```

- If “CAPACITY” is *not* set, the simulator will default to using a maximum size of **40MB**.

Example

- Set the maximum size of tape files for the “TAPE1” device to **40MB**:

```
SET TAPE1 CAPACITY_ALL=40
```

REWIND

- TBD

READY

- TBD

NAME

“NAME” configures the device name of the specified “TAPE” unit.

```
NAME=<name>
```

Example

- Set the device name of “TAPE1” to “tapa_01” (*the default device name*).


```
SET TAPE1 NAME=tapa_01
```

NUNITS

“**NUNITS**” configures the number of “**TAPE**” units.

```
NUNITS=<n>
```

Example

- Set the number of “**TAPE**” units to “16” (*the default number*):

```
SET TAPE NUNITS=16
```

MTP Configuration

DEBUG (NODEBUG)

- TBD

NAME

“**NAME**” configures the device name of the specified “**MTP**” unit.

```
NAME=<name>
```

Example

- Set the device name of **MTP0** to “**MTP0**” (*the default name*).

```
SET MTP0 NAME=MTP0
```

NUNITS

“**NUNITS**” configures the number of “**MTP**” units.

```
NUNITS=<n>
```

Example

- Set the number of “**MTP**” units to “1” (*the default number*):

```
SET MTP NUNITS=6
```

BOOT_DRIVE

- TBD

CONFIG

The following “**MTP**” configuration options are associated with a specified “**MTP**” unit (*i.e.* “**MTPn**”) and are configured using the “**SET**” command (*i.e.* “**SET MTPn CONFIG**”):

```
SET MTPn CONFIG=<set-option>
```

- The following “<**set-option**>”s are available, in the form of “<**option**>=<**value**>”, for example:

```
SET MTPn CONFIG=<option>=<value>
```

IPC Configuration

NAME

“**NAME**” configures the device name of the specified “**IPC**” unit.

```
NAME=<name>
```

Example

- Set the device name of **IPC0** to “**IPC0**” (*the default name*).

```
SET IPC0 NAME=IPC0
```

NUNITS

“**NUNITS**” configures the number of “**IPC**” units.

```
NUNITS=<n>
```

Example

- Set the number of “**IPC**” units to “**2**” (*the default number*):

```
SET IPC NUNITS=6
```

MSP Configuration

NAME

“**NAME**” configures the device name of the specified “**MSP**” unit.

```
NAME=<name>
```

Example

- Set the device name of **MSP0** to “**MSP0**” (*the default name*).

```
SET MSP0 NAME=MSP0
```

NUNITS

“**NUNITS**” configures the number of “**MSP**” units.

```
NUNITS=<n>
```

Example

- Set the number of “**MSP**” units to “**2**” (*the default number*):

```
SET MSP NUNITS=2
```

Disk Configuration

DEBUG (NODEBUG)

- TBD

TYPE

- TBD

READY

- TBD

NAME

“**NAME**” configures the device name of the specified “**DISK**” unit.

```
NAME=<name>
```

Example

- Set the device name of **DISK0** to “`disk_00`” (*the default name*).

```
SET DISK0 NAME=disk_00
```

NUNITS

“**NUNITS**” configures the number of “**DISK**” units.

```
NUNITS=<n>
```

Example

- Set the number of “**DISK**” units to “26” (*the default number*):

```
SET DISK NUNITS=26
```

RDR Configuration

The simulated card reader devices (**RDR**) operate by reading simulated punched card deck files from a queue directory.

The following sections document the commands for configuring the simulated card reader devices and provide an overview of their usage. The simulator includes a utility, “**punutil**”, used to manipulate punched card deck files, which is referred to in the following documentation.

Submitting punched card decks to the card reader

Decks are submitted by copying the deck files into the queue directory.

The location of the queue directory on the host system is controlled with the “**SET RDR PATH**” command (and can be viewed with the “**SHOW RDR PATH**” command).

Punched card formats

- There are three card formats recognized by the simulator:

1. ‘`card`’
2. ‘`stream`’
3. ‘`7punch`’
4. ‘`xDeck`’

Punched card “`card`” format

- In ‘`card`’ format, each line of text is treated as an 80-column card image.
- Newlines in the file are treated as card separators.
- Lines longer than 80 characters are silently extended to the next card image.

Punched card “stream” format

- In ‘stream’ format, each byte of input is read and translated to *MCC* punch codes, grouped into collections of 80 columns.
- No newline processing is done by the simulator.

Punched card “7punch” format

- In ‘7punch’ format, after the ‘++INPUT’ card, all input is treated as a *bit stream* intended to pass binary files (*in ‘7punch’ format*) to ‘++DATA’ decks for copying the file to a Multics segment.

Punched card “xDeck” format

- Newline (<NL>) delimited text.

Punched card format determination

- The deck format is determined by the prefix of the filename being submitted:
 1. ‘card’ format: “cdeck.*”
 2. ‘stream’ format: “sdeck.*”
 3. ‘7punch’ format: “7deck.*”
 4. ‘xDeck’ format: “xdeck.*”

Punched card format / simulator interaction

Any file in the card reader queue directory that does *not* start with one of these prefixes will be ignored (other than a file named “discard”, see “Restarting the card reader device” for more details).

Note that the simulator “peeks” at the card data, because it needs to know when to start using a specific encoding. The simulator always starts by translating the cards into *MCC* punch codes for the job control cards (*i.e.* those that start with a “++”). When it detects an “++input” card, it will switch to processing further input based on the deck format as specified by the filename prefixes given above.

Restarting the card reader device

If the card reader device gets jammed due to an error in a deck, use the following procedure to clear and reset it:

1. On the host system, create an empty file in the card reader queue directory named “discard”.
 - On Unix systems, this can be accomplished with “touch discard”.
2. On the Multics console, issue the following commands:

```
r rdra reinit
r rdra read_cards
```

- You should replace “rdra” above with the appropriate card reader device name if you have more than one card reader device configured.

This will close out the card reader file in the simulator and restart the card reader in Multics.

Working with card decks

When working with card decks, it is important to understand how Multics is going to process them. Refer to *AG91-04A (Multics Programmer's Reference Manual)*, Pages 5–50 through 5–60 (“*Bulk Input and Output*”), and Appendix C (“*Punched-Card Input Output and Returned Output Control*”) for complete details. Some simple examples follow, but *AG91-04A* is the definitive reference.

Note that other than the punched card deck format prefixes above, the rest of this information does not involve the simulator, only Multics. It is also important to note that, when dealing with punched card decks, you are using a simulated media that is limited to a maximum of 80 characters per line. Trying to use lines longer than 80 characters will cause unexpected behavior and will likely not result in what you expect.

Using the punched card format “card” (‘cdeck.*’)

The ‘++FORMAT’ card should read ‘++format mcc addnl trim’. This tells the card reader processor to trim trailing blanks and add newlines to each card image.

The following example loads a data file into Multics:

```
++data bootload_1.alm \Anthony \Sys\Eng
++password XXX
++format mcc addnl trim
++control overwrite
++input
```

- Since card input gets translated into lower case, there needs to be a method of designating upper case letters (because Multics is case-sensitive, and Multics *Person IDs* and *Project IDs* typically use mixed-case names). Therefore, prefixing a letter with a backslash ('\') will cause that character to be translated as upper case.
- The ‘++format’ card above will tell Multics to trim trailing blanks and add newlines to each card image. The “mcc” tells it that the cards are punched with *MCC* codes (this is done by the simulator when using ‘cdeck’ or ‘sdeck’ formats). Even though it is optional, it is best practice to *always* include a ‘++format’ card so you know how Multics will process your deck.

The following example executes a Multics absentee job:

```
++rje test.absin \Anthony \Sys\Eng
++password XXX
++format mcc addnl trim
++input
ccd bootload_1.alm
alm -list bootload_1
```

- This deck will log in as *Anthony.SysEng* and execute the two commands after the ‘++input’ card. When completed, a print job containing the results of executing these commands will be queued.

Using the punched card format “stream” (‘sdeck.*’)

This example is the same as the first ‘cdeck’ example above, except formatted to use ‘stream’ format:

```
++data bootload_1.alm \Anthony \Sys\Eng
++password XXX
++format mcc noaddnl notrim
++control overwrite
```

```
++input
```

- The ‘++**format**’ card specifies *not* to add newlines for each card and *not* to trim trailing spaces.
- The ‘++**control**’ card specifies “**overwrite**”, which will truncate an existing file with the same name if it already exists.
- For this example, compared to the equivalent example in ‘**cdeck**’ format above, there is no significant advantage to choose the ‘**sdeck**’ format over ‘**cdeck**’. Just pick one and use the correct ++**format** card.

Using the punched card format “7punch” (‘7deck.*’)

The ‘7punch’ format is used when you need to transfer a binary file via punched card. The simulator will just read raw bytes after the ‘++input’ card and transfer them to Multics. Using Multics, you can create a ‘7punch’ output deck on the card punch device and use the “**punutil**” utility to extract just the binary cards from the deck. The resulting file can be loaded by prefixing it with the following:

```
++data bound_segment_ \Anthony \Sys\Eng
++password XXX
++format viipunch noaddnl notrim
++control overwrite
++input
```

- The ‘++**format**’ card **must** have “**viipunch**” and specify *not* to add newlines and *not* to trim.

Using the punched card format “xDeck” (‘xdeck.*’)

The ‘xDeck’ format is used when you need to transfer <NL> delimited records, converting to Hollerith encoding. Does not add any additional card images. This is useful for submitting decks to the Multics **GCOS Daemon**. See the **GCOS** page on the Multics Wiki (<https://multics-wiki.swenson.org/index.php/GCOS>) for additional details and usage examples.

DEBUG (NODEBUG)

- TBD

PATH

“**PATH**” configures the path that will be used as the queue directory for reading simulated punched card deck files (for all ‘RDR’ devices).

```
PATH=<path>
```

Example

- Set the punched card reader queue directory to “/home/tom/card_decks”:

```
SET RDR PATH=/home/tom/card_decks
```

NAME

“**NAME**” configures the device name of the specified “**RDR**” unit.

```
NAME=<name>
```

Example

- Set the device name of **RDR0** to “**rdra**” (*the default name*).

```
SET RDR0 NAME=rdra
```

NUNITS

“**NUNITS**” configures the number of “**RDR**” units.

```
NUNITS=<n>
```

Example

- Set the number of “**RDR**” units to “**3**” (*the default number*):

```
SET RDR NUNITS=3
```


PUN Configuration

Overview

The following commands configure simulated card punch devices.

The simulated card punch devices operate by writing simulated punched card decks to *spool files*. The location of the spool files on the host system is controlled with the “**SET PUN PATH**” command.

The *spool file* will contain all ‘**banner**’, ‘**lace**’, and ‘**trailer**’ cards that Multics punches. The ‘**lace**’ cards are parsed to extract job information that is used to name the spool files on the host system.

- The simulator includes a utility, “**punutil**”, that can be used to extract the various cards from the deck in easily usable formats (such as **ASCII** text).

Card format

Each column in a punched card has **twelve** rows, designated from top to bottom:

‘&’	‘-’	‘0’	‘1’	‘2’	‘3’	‘4’	‘5’	‘6’	‘7’	‘8’	‘9’
-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----

Given the above, an **80-column** punched card would then look like:

&	&	&	&	&		&	&	&	&	&
-	-	-	-	-		-	-	-	-	-
0	0	0	0	0		0	0	0	0	0
1	1	1	1	1		1	1	1	1	1
2	2	2	2	2		2	2	2	2	2
3	3	3	3	3	[... +70 columns ...]	3	3	3	3	3
4	4	4	4	4		4	4	4	4	4
5	5	5	5	5		5	5	5	5	5
6	6	6	6	6		6	6	6	6	6
7	7	7	7	7		7	7	7	7	7
8	8	8	8	8		8	8	8	8	8
9	9	9	9	9		9	9	9	9	9

The most obvious way to represent a punched card column in a *spool file* is to assign a single bit per punch. This means that there are **12 bits** for each column. When looking at a hexadecimal dump of a *spool file*, each column occupies **three 4-bit nibbles**. The following representation is *big-endian*:

Column 1												Column 2											
&	-	0	1	2	3	4	5	6	7	8	9	&	-	0	1	2	3	4	5	6	7	8	9
Nibble 1				Nibble 2				Nibble 3				Nibble 1				Nibble 2				Nibble 3			
Byte 1						Byte 2						Byte 3											
7	6	5	4	3	2	1	0	7	6	5	4	3	2	1	0	7	6	5	4	3	2	1	0

DEBUG (NODEBUG)

- TBD

PATH

“**PATH**” configures the path that will be used as the location to write punch *spool files*.

```
PATH=<path>
```

Example

- Set the punch spool file path to “`/home/tom/punches`”:

```
SET PUN PATH=/home/tom/punches
```

Notes

- When unset, all punch spool files will be written to the current working directory of the host operating system.
- When set, the simulator expects a subdirectory to exist for each named punch device — the simulator will **not** automatically create these subdirectories. For example, if “**PATH**” is set to “`/home/tom/punches`” and three punch devices are configured (`puna`, `punb`, `punc`), then the following directory structure must exist for punch jobs to be output properly:

```
/home
├── tom
│   └── punches
│       ├── puna
│       ├── punb
│       └── punc
```

NAME

“**NAME**” configures the device name of the specified “**PUN**” unit.

```
NAME=<name>
```

Example

- Set the device name of **PUN0** to “`puna`” (*the default name*).

```
SET PUN0 NAME=puna
```

NUNITS

“**NUNITS**” configures the number of “**PUN**” units.

```
NUNITS=<n>
```

Example

- Set the number of “PUN” units to “3” (*the default number*):

```
SET PUN NUNITS=2
```

CONFIG

The following “PUN” configuration options are associated with a specified “PUN” unit (*i.e.* “PUNn”) and are configured using the “SET” command (*i.e.* “SET PUNn CONFIG”):

```
SET PUNn CONFIG=<set-option>
```

- The following “<set-option>”s are available, in the form of “<option>=<value>”, for example:

```
SET PUNn CONFIG=<option>=<value>
```

LOGCARDS

“LOGCARDS” configures the simulator to output a significant amount of diagnostic details regarding a punch device to the simulator console. This includes an “ASCII art” representation of the punched cards, where asterisks (*) are used to represent the punched holes. It is recommended to enable this option only if you are attempting to diagnose a card punch issue.

```
SET PUNn CONFIG=LOGCARDS=<0 or 1>  
SET PUNn CONFIG=LOGCARDS=<disable or enable>
```

Example

- Turn on logging of card punch diagnostic data for punch device “PUN0”:

```
SET PUN0 CONFIG=LOGCARDS=1
```

- Turn off logging of card punch diagnostic data for punch device “PUN1”:

```
SET PUN1 CONFIG=LOGCARDS=disable
```

PRT Configuration

DEBUG (NODEBUG)

- TBD

PATH

“**PATH**” configures the output path for printer devices.

```
PATH=<path>
```

- If “**PATH**” is *not* set, the simulator will use the current working directory of the host operating system for printer output.
- When using relative paths (beginning with “.” or “..”) the starting point is the current working directory of the host operating system.

Example

- Set the output path for printer devices to “/home/tom/printers”:

```
SET PRT PATH=/home/tom/printers
```

NOTE: Normally, no matter how many printers are configured, all print jobs will be output to the same directory (with guaranteed unique names). If it is desirable to have each printer output to a separate directory, refer to the documentation for the “**CONFIG=SPLIT**” option.

MODEL

- TBD

READY

- TBD

NAME

“**NAME**” configures the device name of the specified “**PRT**” unit.

```
NAME=<name>
```

Example

- Set the device name of **PRT0** to “**prta**” (*the default name*).

```
SET PRT0 NAME=prta
```

NUNITS

“**NUNITS**” configures the number of “**PRT**” units.

```
NUNITS=<n>
```

Example

- Set the number of “PRT” units to “4” (*the default number*):

```
SET PRT NUNITS=4
```

CONFIG

The following “PRT” configuration options are associated with a specified “PRT” unit (*i.e.* “PRTn”) and are configured using the “SET” command (*i.e.* “SET PRTn CONFIG”):

```
SET PRTn CONFIG=<set-option>
```

- The following “<set-option>”s are available, in the form of “<option>=<value>”, for example:

```
SET PRTn CONFIG=<option>=<value>
```

SPLIT

“SPLIT” configures the specified “PRT” unit to output jobs into a subdirectory of the directory specified by the “PATH” setting. Print devices that do not enable “SPLIT” will output their files into the directory specified by “PATH”.

```
SPLIT=<0 or 1>  
SPLIT=<off or on>
```

Example

- Enable output splitting for the “PRT1” device:

```
SET PRT1 CONFIG=SPLIT=on
```

FNP Configuration

DEBUG (NODEBUG)

- TBD

NUNITS

“NUNITS” configures the number of “FNP” units.

```
NUNITS=<n>
```

Example

- Set the number of “FNP” units to “8” (*the default number*):

```
SET FNP NUNITS=8
```

CONFIG

The following “FNP” configuration options are associated with a specified “FNP” unit (*i.e.* “FNPn”) and are configured using the “SET” command (*i.e.* “SET FNPn CONFIG”):

```
SET FNPn CONFIG=<set-option>
```

- The following “<set-option>”s are available, in the form of “<option>=<value>”, for example:

```
SET FNPn CONFIG=<option>=<value>
```

MAILBOX

* TBD

IPC_NAME

* TBD

SERVICE

* TBD

OPC Configuration

DEBUG (NODEBUG)

- TBD

AUTOINPUT

- TBD

NAME

“**NAME**” configures the device name of the specified “**OPC**” unit.

```
NAME=<name>
```

Example

- Set the device name of **OPC0** to “**OPC0**” (*the default name*).

```
SET OPC0 NAME=OPC0
```

NUNITS

“**NUNITS**” configures the number of “**OPC**” units.

```
NUNITS=<n>
```

Example

- Set the number of “**OPC**” units to “**2**” (*the default number*):

```
SET OPC NUNITS=2
```

CONFIG

The following “**OPC**” configuration options are associated with a specified “**OPC**” unit (*i.e.* “**OPCn**”) and are configured using the “**SET**” command (*i.e.* “**SET OPCn CONFIG**”):

```
SET OPCn CONFIG=<set-option>
```

- The following “**<set-option>**”’s are available, in the form of “**<option>=<value>**”, for example:

```
SET OPCn CONFIG=<option>=<value>
```

AUTOACCEPT

* TBD

NOEMPTY

* TBD

ATTN_FLUSH

* TBD

PORT

* TBD

ADDRESS

* TBD

PW

* TBD

URP Configuration**DEBUG (NODEBUG)**

- TBD

NAME

“**NAME**” configures the device name of the specified “**URP**” unit.

```
NAME=<name>
```

Example

- Set the device name of **URP0** to “**urpa**” (*the default name*).

```
SET URP0 NAME=urpa
```


NUNITS

“**NUNITS**” configures the number of “**URP**” units.

```
NUNITS=<n>
```

Example

- Set the number of “**URP**” units to “10” (*the default number*):

```
SET URP NUNITS=10
```

SHIFT

Shift the command files positional parameters

SHOW

SH{OW} B{UILDINFO}	Show build-time compilation information
SH{OW} CL{OCKS}	Show wall clock and timer information
SH{OW} C{ONFIGURATION}	Show simulator configuration
SH{OW} D{EFAULT_BASE_SYSTEM}	Show default base system script
SH{OW} DEV{ICES}	Show devices
SH{OW} H{INTS}	Show configuration hints
SH{OW} M{ODIFIERS}	Show SET commands for all devices
SH{OW} O{N}	Show ON condition actions
SH{OW} P{ROM}	Show CPU ID PROM initialization data
SH{OW} Q{UEUE}	Show event queue
SH{OW} S{HOW}	Show SHOW commands for all devices
SH{OW} T{IME}	Show simulated timer
SH{OW} VE{RSION}	Show simulator version
H{ELP} <dev> SHOW	Show device-specific SHOW commands
SH{OW} <dev> {arg,...}	Show device parameters
SH{OW} <dev> DEBUG	Show device debug flags
SH{OW} <dev> MODIFIERS	Show device modifiers
SH{OW} <dev> RADIX	Show device display radix
SH{OW} <dev> SHOW	Show device SHOW commands
SH{OW} <unit> {arg,...}	Show unit parameters

BUILDINFO (B)

“**BUILDINFO**” (*abbreviated “B”*) shows build-time compilation information including the complete compiler flags (*i.e.* “**CFLAGS**”, “**LDFLAGS**”, etc.) used when building the simulator, the libraries the simulator is statically and dynamically linked against and their versions, relevant definitions set by the C preprocessor at build-time, the types of file locking mechanisms available, and the style of atomic operation primitives in use.

Example

```

sim> SHOW BUILDINFO
Build Information:
  Compilation info: cc -Wall -O3 -g -U_FORTIFY_SOURCE -fno-stack-protector
-fno-math-errno -fno-trapping-math -fno-signed-zeros
-fomit-frame-pointer -ffp-contract=fast -fno-strict-aliasing
-D_LARGE_FILES -D_FILE_OFFSET_BITS=64 -DUSE_FLOCK=1 -DUSE_FCNTL=1
-I../libsir/include -std=c11 -U__STRICT_ANSI__ -D_GNU_SOURCE
-flto=auto -pthread -DLOCKLESS -DVER_CURRENT_TIME=2025-05-15 01:51
UTC -DBUILD_PROM_OSV_TEXT=Linux -DBUILD_PROM_OSA_TEXT=x86_64 -lpthread
-luv -lrt -ldl

Loaded shared objects: linux-vdso.so.1 /usr/libexec/coreutils/libstdbuf.so
/lib64/libm.so.6 /lib64/libuv.so.1 /lib64/libc.so.6
/lib64/ld-linux-x86-64.so.2

Event loop library: Built with libuv 1.51.0 (release); 1.51.0 in use
Log support library: Built with libsir 2.2.6-dev; 2.2.6-dev in use
Math library: decNumber 3.68-20210520p4
Atomic operations: C11 and GNU-style
File locking: POSIX-style fcntl() and BSD-style flock() locking

```

CLOCKS (CL)

“**CLOCKS**” (abbreviated “**CL**”) shows the current wall clock time and internal timer details.

Example

```

sim> SHOW CLOCKS
DPS8/M clock device is Internal Calibrated Timer()
Uncalibrated Timer 8:
  Seconds Running:          0 ( )
  Current Insts Per Tick:   50000
  Initializations:         1
  Total Ticks:             0
  Wall Clock Time Now:     01:52:43.748

```

CONFIGURATION (C)

“**CONFIGURATION**” (abbreviated “**C**”) shows a detailed overview of the current simulator configuration.

- See the **Default Base System Configuration** section of the **Simulator Defaults** chapter for example output of the “**SHOW CONFIGURATION**” command.

DEFAULT_BASE_SYSTEM (D)

“**DEFAULT_BASE_SYSTEM**” (abbreviated “**D**”) shows the *default base system configuration script* which is executed automatically at simulator startup or via the “**DEFAULT_BASE_SYSTEM**” command.

- See the documentation for the “**DEFAULT_BASE_SYSTEM**” command earlier in this chapter and the **Default Base System Script** section of the **Simulator Defaults** chapter for additional details.

DEVICES (DEV)

“**DEVICES**” (abbreviated “**DEV**”) shows devices by name and number of units (i.e. “**NUNITS**”) configured.

Example

```
sim> SHOW DEVICES
CPU      6 units
IOM      2 units
TAPE    17 units
MTP      1 unit
FNP      8 units
DISK    26 units
IPC      2 units
MSP      2 units
SCU      4 units
OPC      2 units
URP     10 units
RDR      3 units
PUN      3 units
PRT      4 units
```

MODIFIERS (M)

“**MODIFIERS**” (abbreviated “**M**”) shows a summary of available “**SET**” commands for all devices.

ON (O)

“**ON**” (abbreviated “**O**”) shows information about “**ON**” condition actions.

PROM (P)

“**PROM**” (abbreviated “**P**”) shows the CPU ID PROM initialization data.

Example

```

sim> SHOW PROM
PROM size: 1024 bytes
PROM initialization data:
  Field Description      Length  Offset      Contents
=====
CPU Model               11      0(8)      'DPS 8/SIM M'
CPU Serial              11     13(8)      '0          '
Ship Date                6     26(8)      '250514'
PROM Layout Version     1     74(8)      '2'
Release Git Commit Date 10    106(8)     '2025-05-14'
Release Major           3     120(8)     '003'
Release Minor           3     123(8)     '001'
Release Patch           3     126(8)     '000'
Release Iteration       3     131(8)     '000'
Release Build Number     8     134(8)     '          '
Release Type            1     144(8)     'X'
Release Version Text    29    145(8)     '3.1.0          '
Build Architecture      20    202(8)     'x86_64          '
Build Operating System  20    226(8)     'Linux          '
Target Architecture     20    252(8)     'Intel x86_64 (AMD64)'
Target Operating System 20    276(8)     'GNU/Linux          '

```

QUEUE (Q)

“**QUEUE**” (abbreviated “**Q**”) shows information about the simulator’s event queue.

SHOW (S)

“**SHOW**” (abbreviated “**S**”) shows a summary of available “**SHOW**” commands for all devices.

TIME (T)

“**TIME**” (abbreviated “**T**”) shows information about the simulated timer.

VERSION (V)

“**VERSION**” (abbreviated “**V**”) shows the version of the simulator.

- If available, additional related information will be shown, which may include:
 - a *git commit hash* to uniquely identify the simulator build,
 - the date and time the simulator was last modified,
 - the date and time the *source kit distribution* the simulator was built from was prepared,
 - the date and time the simulator was compiled,
 - a statement regarding support availability for the build (or lack thereof),

- the name and architecture of the operating system that was used to build the simulator,
- the name, version, and vendor of the compiler used to build the simulator,
- information about the person (*or automated process*) that performed the build,
- the name, version, and architecture of the host operating system executing the simulator,
- and information regarding licensing terms and conditions.

Example

```
sim> SHOW VERSION
DPS8/M Simulator:
  Version: X3.1.0+1 (64-bit)
  Commit: f0d311a99c630e4d7d067d16000b62ddca81fefc
  Modified: 2025-05-14 21:17 UTC - Kit Prepared: 2025-05-15 01:51 UTC
  Compiled: 2025-05-15 01:51 UTC

***** THIS BUILD IS NOT SUPPORTED BY THE DPS8M DEVELOPMENT TEAM *****

Build Information:
  Target: GNU/Linux on Intel x86_64 (AMD64)
  Build OS: Linux x86_64
  Compiler: GCC 15.1.1 20250425 (Red Hat 15.1.1-1) x86_64
  Built by: root@runner-punwssdb-project-10664906-concurrent-0

Host System Information:
  Host OS: Linux 6.14.0-0.rc7.56.fc42.x86_64 x86_64

This software is made available under the terms of the ICU License.
For complete license details, see the LICENSE file included with the
software or https://gitlab.com/dps8m/dps8m/-/blob/master/LICENSE.md
```

CPU

The following device-specific “**SHOW**” commands are available for the “**CPU**” device. If the “**SHOW CPU**” command can operate on a specific unit, but no unit is specified, the first unit (*i.e.* **CPU0**) is assumed.

Example

```
SHOW CPU COMMAND
SHOW CPUn COMMAND
```

CONFIG

“**CONFIG**” shows configuration details (set via “**SET CPU CONFIG**”) for the “**CPU**” unit specified.

Example

```
sim> SHOW CPU0 CONFIG
CPU unit number 0
Fault base:                002(8)
CPU number:                 0(8)
```

```

Data switches:          024000717200(8)
                        000010100000000000111001111010000000(2)
Address switches:      000000(8)
                        000000000000000000(2)
PortA enable:          1(8)
PortA init enable:     1(8)
PortA assignment:      0(8)
PortA interlace:       0(8)
PortA store size:      7(8)
PortB enable:          1(8)
PortB init enable:     1(8)
PortB assignment:      1(8)
PortB interlace:       0(8)
PortB store size:      7(8)
PortC enable:          1(8)
PortC init enable:     1(8)
PortC assignment:      2(8)
PortC interlace:       0(8)
PortC store size:      7(8)
PortD enable:          1(8)
PortD init enable:     1(8)
PortD assignment:      3(8)
PortD interlace:       0(8)
PortD store size:      7(8)
Processor mode:        Multics [0]
8K Cache:              Enabled
SDWAM:                 Enabled
PTWAM:                 Enabled
Processor speed:       00(8)
DIS enable:            1(8)
Steady clock:          0(8)
Halt on unimplemented: 0(8)
Enable simulated SDWAM/PTWAM: 0(8)
Report faults:         0(8)
TRO faults enabled:    1(8)
drl fatal enabled:     0(8)
useMap:                0
PROM installed:        1(8)
Hex mode installed:    0(8)
8K cache installed:    1(8)
Clock slave installed: 1(8)
ISOLTS mode:          0(8)
NODIS mode:            0(8)
6180 mode:             0(8) [DPS8/M]

```

NUNITS

“**NUNITS**” shows the number of “CPU” units configured (set via “**SET CPU NUNITS**”).

Example

```
sim> SHOW CPU NUNITS
Number of CPUs in system is 6
```

KIPS

“**KIPS**” shows the global CPU lockup fault scaling factor (set via “**SET CPU KIPS**”).

Example

```
sim> SHOW CPU KIPS
CPU KIPS 1000
```

STALL

“**STALL**” shows the currently configured stall points (set via “**SET CPU STALL**”).

Example

```
sim> SET CPU STALL=0=132:3737=12500
sim> SHOW CPU STALL
Stall points
 0 00132:003737      12500
```

DEBUG

“**DEBUG**” shows the currently configured debug options (set via “**SET CPU DEBUG**”).

Example

```
sim> SHOW CPU DEBUG
Debugging disabled
```

DISK

The following device-specific “**SHOW**” commands are available for the “**DISK**” device. If the “**SHOW DISK**” command can operate on a specific unit, but no unit is specified, the first unit (*i.e.* **DISK0**) is assumed.

NAME

“**NAME**” shows the currently configured device name (set via “**SET DISK_n NAME**”).

Example

```
sim> SHOW DISK0 NAME
name      : dska_00
```

NUNITS

“**NUNITS**” shows the number of “**DISK**” units configured (set via “**SET DISK NUNITS**”).

Example

```
sim> SHOW DISK NUNITS
Number of DISK units in system is 26
```

TYPE

“**TYPE**” shows the currently configured disk type (set via “**SET DISK TYPE**”).

Example

```
sim> SHOW DISK TYPE
type      : 3381
```

DEBUG

“**DEBUG**” shows the currently configured debug options (set via “**SET DISK DEBUG**”).

Example

```
sim> SHOW DISK DEBUG
Debugging disabled
```

FNP

The following device-specific “**SHOW**” commands are available for the “**FNP**” device. If the “**SHOW FNP**” command can operate on a specific unit, but no unit is specified, the first unit (*i.e.* **FNP0**) is assumed.

CONFIG

“**CONFIG**” shows configuration details (set via “**SET FNPn CONFIG**”) for the “**FNP**” unit specified.

Example


```
sim> SHOW FNP0 CONFIG
FNP unit number 0
FNP mailbox address:      3400(8)
```

IPC_NAME

“**IPC_NAME**” shows the IPC name for the “FNP” unit specified (set via “**SET FNPn IPC_NAME**”).

Example

```
sim> SHOW FNP0 IPC_NAME
FNP IPC name: fnp-a
```

NAME

“**NAME**” shows the currently configured device name (set via “**SET FNPn NAME**”).

Example

```
sim> SHOW FNP0 NAME
name: default
```

NUNITS

“**NUNITS**” shows the number of “FNP” units configured (set via “**SET FNP NUNITS**”).

Example

```
sim> SHOW FNP NUNITS
Number of FNP units in system is 8
```

SERVICE

“**SERVICE**” shows the configured service for each line for the “FNP” unit specified.

- **NOTE:** Only the first ten lines of command output have been reproduced here; the remaining output has been excluded for brevity.

Example

```
sim> SHOW FNP0 SERVICE
a.000: undefined
      a.001: undefined
      a.002: undefined
      a.003: undefined
```

```
a.004: undefined
a.005: undefined
a.006: undefined
a.007: undefined
a.008: undefined
a.009: undefined
a.010: undefined
```

STATUS

“**STATUS**” shows detailed line status information for the “**FNP**” unit specified.

- **NOTE:** Only the status of the first line has been reproduced here; the remaining output has been excluded for brevity.

Example

```
sim> SHOW FNP0 STATUS
FNP unit number 0:
  mailboxAddress:      3400
  fnpIsRunning:        0
  fnpMBXinUse:         0 0 0 0
  lineWaiting:         0 0 0 0
  fnpMBXlineno:        0 0 0 0
  accept_calls:        0
line 0:
  service:              0
  line_client:          (nil)
  was_CR:               0
  listen:               0
  inputBufferSize:     0
  line_break:           0
  send_output:          0
  accept_new_terminal: 0
  line_disconnected:   0
  acu_dial_failure:    0
  accept_input:         0
  waitForMbxDone:      0
  input_reply_pending: 0
  input_break:          0
  nPos:                 0
  inBuffer:             (nil)
  inSize:               0
  inUsed:               0
  port:                 0
```

DEBUG

“**DEBUG**” shows the currently configured debug options (set via “**SET FNP DEBUG**”).

Example

```
sim> SHOW FNP DEBUG
Debugging disabled
```

IOM

The following device-specific “**SHOW**” commands are available for the “**IOM**” device. If the “**SHOW IOM**” command can operate on a specific unit, but no unit is specified, the first unit (*i.e.* **IOM0**) is assumed.

CONFIG

Example

“**CONFIG**” shows configuration details (set via “**SET IOMn CONFIG**”) for the “**IOM**” unit specified.

```
sim> SHOW IOM0 CONFIG
IOM unit number 0
Allowed Operating System: Multics
IOM Base Address:      014(8)
Multiplex Base Address: 0120(8)
Bootload Card/Tape:    TAPE
Bootload Tape Channel: 12(8)
Bootload Card Channel: 11(8)
Bootload Port:         00(8)
Port Address:          000 001 002 003 000 000 000 000
Port Interlace:        0  0  0  0  0  0  0  0
Port Enable:           1  1  1  1  0  0  0  0
Port Sysinit Enable:   0  0  0  0  0  0  0  0
Port Halfsize:         0  0  0  0  0  0  0  0
Port Storesize:        7  7  7  7  0  0  0  0
```

NUNITS

“**NUNITS**” shows the number of “**IOM**” units configured (set via “**SET IOM NUNITS**”).

Example

```
sim> SHOW IOM NUNITS
Number of IOM units in system is 2
```

DEBUG

“**DEBUG**” shows the currently configured debug options (set via “**SET IOM DEBUG**”).

```
sim> SHOW IOM DEBUG
Debugging disabled
```

IPC

The following device-specific “**SHOW**” commands are available for the “**IPC**” device. If the “**SHOW IPC**” command can operate on a specific unit, but no unit is specified, the first unit (*i.e.* **IPC0**) is assumed.

NAME

“**NAME**” shows the currently configured device name (set via “**SET IPCn NAME**”).

Example

```
sim> SHOW IPC0 NAME
name      : IPC0
```

NUNITS

“**NUNITS**” shows the number of “**IPC**” units configured (set via “**SET IPC NUNITS**”).

Example

```
sim> SHOW IPC NUNITS
Number of IPC units in system is 2
```

MSP

The following device-specific “**SHOW**” commands are available for the “**MSP**” device. If the “**SHOW MSP**” command can operate on a specific unit, but no unit is specified, the first unit (*i.e.* **MSP0**) is assumed.

NAME

“**NAME**” shows the currently configured device name (set via “**SET MSPn NAME**”).

Example

```
sim> SHOW MSP0 NAME
name      : MSP0
```

NUNITS

“**NUNITS**” shows the number of “**MSP**” units configured (set via “**SET MSP NUNITS**”).

Example

```
sim> SHOW MSP NUNITS
Number of MSP units in system is 2
```

MTP

The following device-specific “**SHOW**” commands are available for the “**MTP**” device. If the “**SHOW MTP**” command can operate on a specific unit, but no unit is specified, the first unit (*i.e.* **MTP0**) is assumed.

BOOT_DRIVE

“**BOOT_DRIVE**” shows the currently configured boot drive for the unit specified (set via “**SET MTPn BOOT_DRIVE**”).

Example

```
sim> SHOW MTP0 BOOT_DRIVE
boot      : 0
```

NAME

“**NAME**” shows the currently configured device name (set via “**SET MTPn NAME**”).

Example

```
sim> SHOW MTP0 NAME
name      : MTP0
```

NUNITS

“**NUNITS**” shows the number of “**MTP**” units configured (set via “**SET MTP NUNITS**”).

Example

```
sim> SHOW MTP NUNITS
Number of MTP controllers in the system is 1
```

DEBUG

“**DEBUG**” shows the currently configured debug options (set via “**SET MTP DEBUG**”).

Example

```
sim> SHOW MTP DEBUG
Debugging disabled
```

OPC

The following device-specific “**SHOW**” commands are available for the “**OPC**” device. If the “**SHOW OPC**” command can operate on a specific unit, but no unit is specified, the first unit (*i.e.* **OPC0**) is assumed.

CONFIG

“**CONFIG**” shows configuration details (set via “**SET OPCn CONFIG**”) for the “**OPC**” unit specified.

Example

```
sim> SHOW OPC0 CONFIG
flags      : autoaccept=0, noempty=0, attn_flush=1
```

ADDRESS

“**ADDRESS**” shows the currently configured address for the specified unit (set via “**SET OPCn ADDRESS**”).

Example

```
sim> SHOW OPC0 ADDRESS
address    : any
```

AUTOINPUT

“**AUTOINPUT**” shows the autoinput buffer of the specified **OPC** unit.

Example

```
sim> SHOW OPC0 AUTOINPUT
autoinput: empty
```

NAME

“**NAME**” shows the currently configured device name (set via “**SET OPCn NAME**”).

Example

```
sim> SHOW OPC0 NAME
name      : OPC0
```

NUNITS

“**NUNITS**” shows the number of “**OPC**” units configured (set via “**SET OPC NUNITS**”).

Example

```
sim> SHOW OPC NUNITS
2 units
```

PORT

“**PORT**” shows the currently configured port for the specified unit (set via “**SET OPCn PORT**”).

Example

```
sim> SHOW OPC0 PORT
port      : disabled
```

PW

“**PW**” shows the currently configured password for the specified unit (set via “**SET OPCn PW**”).

Example

```
sim> SHOW OPC0 PW
password  : MulticsRulez
```

DEBUG

“**DEBUG**” shows the currently configured debug options (set via “**SET OPC DEBUG**”).

Example

```
sim> SHOW OPC DEBUG
Debugging disabled
```

PRT

The following device-specific “**SHOW**” commands are available for the “**PRT**” device. If the “**SHOW PRT**” command can operate on a specific unit, but no unit is specified, the first unit (*i.e.* **PRT0**) is assumed.

CONFIG

“**CONFIG**” shows configuration details (set via “**SET PRTn CONFIG**”) for the “**PRT**” unit specified.

Example

```
sim> SHOW PRT0 CONFIG
split      : 0
```

MODEL

“**MODEL**” shows configured model (set via “**SET PRTn MODEL**”) for the “**PRT**” unit specified.

Example

```
sim> SHOW PRT0 MODEL
model      : 1600
```

NAME

“**NAME**” shows the currently configured device name (set via “**SET PRTn NAME**”).

Example

```
sim> SHOW PRT0 NAME
name       : prta
```

NUNITS

“**NUNITS**” shows the number of “**PRT**” units configured (set via “**SET PRT NUNITS**”).

Example

```
sim> SHOW PRT NUNITS
Number of PRT units in system is 4
```


PATH

“**PATH**” shows the currently configured output path (set via “**SET PRT PATH**”).

- The default path is the current working directory of the host operating system.

Example

```
sim> SHOW PRT PATH
Path to PRT files is /builds/dps8m/dps8m/docs
```

DEBUG

“**DEBUG**” shows the currently configured debug options (set via “**SET PRT DEBUG**”).

Example

```
sim> SHOW PRT DEBUG
Debugging disabled
```

PUN

The following device-specific “**SHOW**” commands are available for the “**PUN**” device. If the “**SHOW PUN**” command can operate on a specific unit, but no unit is specified, the first unit (*i.e.* **PUN0**) is assumed.

For details on usage and configuration of “**PUN**” devices, see the “**SET PUN**” section of this documentation.

CONFIG

“**CONFIG**” shows configuration details (set via “**SET PUNn CONFIG**”) for the “**PUN**” unit specified.

Example

```
sim> SHOW PUN0 CONFIG
logcards : 0
```

NAME

“**NAME**” shows the currently configured device name (set via “**SET PUNn NAME**”).

Example

```
sim> SHOW PUN0 NAME
name      : puna
```

NUNITS

“**NUNITS**” shows the number of “**PUN**” units configured (set via “**SET PUN NUNITS**”).

Example

```
sim> SHOW PUN NUNITS
Number of PUN units in system is 3
```

PATH

“**PATH**” shows the currently configured output path. (set via “**SET PUN PATH**”).

- An empty path is equivalent to the host operating system current working directory.

Example

```
sim> SHOW PUN PATH
Path to card punch directories is unset.
```

DEBUG

“**DEBUG**” shows the currently configured debug options (set via “**SET PUN DEBUG**”).

Example

```
sim> SHOW PUN DEBUG
Debugging disabled
```

RDR

The following device-specific “**SHOW**” commands are available for the “**RDR**” device. If the “**SHOW RDR**” command can operate on a specific unit, but no unit is specified, the first unit (*i.e.* **RDR0**) is assumed.

For details on usage and configuration of “**RDR**” devices, see the “**SET RDR**” section of this documentation.

NAME

“**NAME**” shows the currently configured device name (set via “**SET RDRn NAME**”).

Example

```
sim> SHOW RDR0 NAME
name      : rdra
```

NUNITS

“**NUNITS**” shows the number of “**RDR**” units configured (set via “**SET RDR NUNITS**”).

Example

```
sim> SHOW RDR NUNITS
Number of RDR units in system is 3
```

PATH

“**PATH**” shows the currently configured card reader directory path. (set via “**SET RDR PATH**”).

- An empty path is equivalent to the host operating system current working directory.

Example

```
sim> SHOW RDR PATH
Path to card reader directories is unset.
```

DEBUG

“**DEBUG**” shows the currently configured debug options (set via “**SET RDR DEBUG**”).

Example

```
sim> SHOW RDR DEBUG
Debugging disabled
```

SCU

The following device-specific “**SHOW**” commands are available for the “**SCU**” device. If the “**SHOW SCU**” command can operate on a specific unit, but no unit is specified, the first unit (*i.e.* **SCU0**) is assumed.

CONFIG

“**CONFIG**” shows configuration details (set via “**SET SCU_n CONFIG**”) for the “**SCU**” unit specified.

Example

```
sim> SHOW SCU0 CONFIG
SCU unit number 0
Mode:                               Program
Port Enable:                        1  1  1  1  1  1  1  1
Mask A:                              7
Mask B:                             Off
Lower Store Size:                    7
Cyclic:                              040
```

```
Non-existent address:      200
```

NUNITS

“**NUNITS**” shows the number of “**SCU**” units configured (set via “**SET SCU NUNITS**”).

Example

```
sim> SHOW SCU NUNITS
Number of SCU units in system is 4
```

STATE

“**STATE**” shows detailed information about the state of the “**SCU**” unit specified.

Example

```
sim> SHOW SCU0 STATE
SCU unit number 0
  Mode PROGRAM
  Port 0 ENABLE dev_idx 0 dev_port 0 type IOM
  Port 1 ENABLE dev_idx 1 dev_port 0 type IOM
  Port 2 ENABLE dev_idx 5 dev_port 0 type CPU
  Port 3 ENABLE dev_idx 4 dev_port 0 type CPU
  Port 4 ENABLE dev_idx 3 dev_port 0 type CPU
  Port 5 ENABLE dev_idx 2 dev_port 0 type CPU
  Port 6 ENABLE dev_idx 1 dev_port 0 type CPU
  Port 7 ENABLE dev_idx 0 dev_port 0 type CPU
  Cell A
    exec_intr_mask 037777777777
    mask_enable ENABLE
    mask_assignment 7
    cells 00000000000000000000000000000000
  Cell B
    exec_intr_mask 037777777777
    mask_enable DISABLE
    mask_assignment 0
    cells 00000000000000000000000000000000
Lower store size: 7
Cyclic: 040
NEA: 200
Online: 14
Interlace: 0
Lower: 0
ID: 2
mode_reg: 000000
Elapsed days: 0
Steady clock: 0
Bullet time: 0
Clock delta: 0
```

DEBUG

“**DEBUG**” shows the currently configured debug options (set via “**SET SCU DEBUG**”).

Example

```
sim> SHOW SCU DEBUG
Debugging disabled
```

TAPE

The following device-specific “**SHOW**” commands are available for the “**TAPE**” device. If the “**SHOW TAPE**” command can operate on a specific unit, but no unit is specified, the first unit (*i.e.* **TAPE0**) is assumed.

ADD_PATH

“**ADD_PATH**” shows the currently configured tape directory search paths (set via “**SET TAPE ADD_PATH**”).

Example

```
sim> SHOW TAPE ADD_PATH
Tape directory search paths:
Prefix                Directory
-----                -
[default]
```

CAPACITY

“**CAPACITY**” shows the storage capacity of the specified “**TAPE**” unit.

Example

```
sim> SHOW TAPE0 CAPACITY
capacity : 40MB
```

DEFAULT_PATH

“**DEFAULT_PATH**” shows the currently configured default tape path (set via “**SET TAPE DEFAULT_PATH**”).

- An empty path is equivalent to the host operating system current working directory.

Example

```
sim> SHOW TAPE DEFAULT_PATH
TAPE DEFAULT_PATH:
```

NAME

“**NAME**” shows the currently configured device name (set via “**SET TAPE_n NAME**”).

Example

```
sim> SHOW TAPE0 NAME
name      : default
```

NUNITS

“**NUNITS**” shows the number of “**TAPE**” units configured (set via “**SET TAPE NUNITS**”).

Example

```
sim> SHOW TAPE NUNITS
Number of TAPE units in system is 17
```

DEBUG

“**DEBUG**” shows the currently configured debug options (set via “**SET TAPE DEBUG**”).

Example

```
sim> SHOW TAPE DEBUG
Debugging disabled
```

URP

The following device-specific “**SHOW**” commands are available for the “**URP**” device. If the “**SHOW URP**” command can operate on a specific unit, but no unit is specified, the first unit (*i.e.* **URP0**) is assumed.

NAME

“**NAME**” shows the currently configured device name (set via “**SET URP_n NAME**”).

Example

```
sim> SHOW URP0 NAME
name      : urpa
```

NUNITS

“**NUNITS**” shows the number of “**URP**” units configured (set via “**SET URP NUNITS**”).

Example

```
sim> SHOW URP NUNITS
Number of URP units in system is 10
```

DEBUG

“**DEBUG**” shows the currently configured debug options (set via “**SET URP DEBUG**”).

Example

```
sim> SHOW URP DEBUG
Debugging disabled
```

SKIPBOOT

Skip forward on boot tape

SLOWPOLL

Set slow polling interval (in polling intervals).

STEP (S)

Step Execution

The **STEP** command (*abbreviated S*) resumes execution at the current PC for the number of instructions given by its argument. If no argument is supplied, one instruction is executed.

Switches

-T If the **STEP** command is invoked with the “**-T**” switch, the step command will cause execution to run for *microseconds* rather than instructions.

Simulator Defaults

Default Base System Script

The following script defines the *default base system* configuration, and is executed automatically at simulator startup. It may also be explicitly re-executed via the “**DEFAULT_BASE_SYSTEM**” command.

- See the “**DEFAULT_BASE_SYSTEM**” command documentation for more information.

```
;; DPS8/M simulator X3.1.0+1
; DEFAULT_BASE_SYSTEM_SCRIPT (658 lines follow)
CABLE_RIPOUT
SET CPU NUNITS=6
SET IOM NUNITS=2
SET TAPE NUNITS=17
SET MTP NUNITS=1
SET IPC NUNITS=2
SET MSP NUNITS=2
SET DISK NUNITS=26
SET SCU NUNITS=4
SET OPC NUNITS=2
SET FNP NUNITS=8
SET URP NUNITS=10
SET RDR NUNITS=3
SET PUN NUNITS=3
SET PRT NUNITS=4
SET CPU0 CONFIG=FAULTBASE=Multics
SET CPU0 CONFIG=NUM=0
SET CPU0 CONFIG=DATA=024000717200
SET CPU0 CONFIG=ADDRESS=000000000000
SET CPU0 CONFIG=PORT=A
SET CPU0 CONFIG=ASSIGNMENT=0
SET CPU0 CONFIG=INTERLACE=0
SET CPU0 CONFIG=ENABLE=1
SET CPU0 CONFIG=INIT_ENABLE=1
SET CPU0 CONFIG=STORE_SIZE=4M
SET CPU0 CONFIG=PORT=B
SET CPU0 CONFIG=ASSIGNMENT=1
SET CPU0 CONFIG=INTERLACE=0
SET CPU0 CONFIG=ENABLE=1
SET CPU0 CONFIG=INIT_ENABLE=1
SET CPU0 CONFIG=STORE_SIZE=4M
SET CPU0 CONFIG=PORT=C
SET CPU0 CONFIG=ASSIGNMENT=2
SET CPU0 CONFIG=INTERLACE=0
SET CPU0 CONFIG=ENABLE=1
SET CPU0 CONFIG=INIT_ENABLE=1
SET CPU0 CONFIG=STORE_SIZE=4M
```

```
SET CPU0 CONFIG=PORT=D
SET CPU0 CONFIG=ASSIGNMENT=3
SET CPU0 CONFIG=INTERLACE=0
SET CPU0 CONFIG=ENABLE=1
SET CPU0 CONFIG=INIT_ENABLE=1
SET CPU0 CONFIG=STORE_SIZE=4M
SET CPU0 CONFIG=MODE=Multics
SET CPU0 CONFIG=ENABLE_CACHE=enable
SET CPU0 CONFIG=SDWAM=enable
SET CPU0 CONFIG=PTWAM=enable
SET CPU0 CONFIG=SPEED=0
SET CPU0 CONFIG=DIS_ENABLE=enable
SET CPU0 CONFIG=STEADY_CLOCK=disable
SET CPU0 CONFIG=HALT_ON_UNIMPLEMENTED=disable
SET CPU0 CONFIG=ENABLE_WAM=disable
SET CPU0 CONFIG=REPORT_FAULTS=disable
SET CPU0 CONFIG=TRO_ENABLE=enable
SET CPU0 CONFIG=DRL_FATAL=disable
SET CPU0 CONFIG=USEMAP=disable
SET CPU0 CONFIG=PROM_INSTALLED=enable
SET CPU0 CONFIG=HEX_MODE_INSTALLED=disable
SET CPU0 CONFIG=CACHE_INSTALLED=enable
SET CPU0 CONFIG=CLOCK_SLAVE_INSTALLED=enable
SET CPU1 CONFIG=FAULTBASE=Multics
SET CPU1 CONFIG=NUM=1
SET CPU1 CONFIG=DATA=024000717200
SET CPU1 CONFIG=ADDRESS=000000000000
SET CPU1 CONFIG=PORT=A
SET CPU1 CONFIG=ASSIGNMENT=0
SET CPU1 CONFIG=INTERLACE=0
SET CPU1 CONFIG=ENABLE=1
SET CPU1 CONFIG=INIT_ENABLE=1
SET CPU1 CONFIG=STORE_SIZE=4M
SET CPU1 CONFIG=PORT=B
SET CPU1 CONFIG=ASSIGNMENT=1
SET CPU1 CONFIG=INTERLACE=0
SET CPU1 CONFIG=ENABLE=1
SET CPU1 CONFIG=INIT_ENABLE=1
SET CPU1 CONFIG=STORE_SIZE=4M
SET CPU1 CONFIG=PORT=C
SET CPU1 CONFIG=ASSIGNMENT=2
SET CPU1 CONFIG=INTERLACE=0
SET CPU1 CONFIG=ENABLE=1
SET CPU1 CONFIG=INIT_ENABLE=1
SET CPU1 CONFIG=STORE_SIZE=4M
SET CPU1 CONFIG=PORT=D
SET CPU1 CONFIG=ASSIGNMENT=3
SET CPU1 CONFIG=INTERLACE=0
SET CPU1 CONFIG=ENABLE=1
SET CPU1 CONFIG=INIT_ENABLE=1
SET CPU1 CONFIG=STORE_SIZE=4M
SET CPU1 CONFIG=MODE=Multics
SET CPU1 CONFIG=ENABLE_CACHE=enable
SET CPU1 CONFIG=SDWAM=enable
SET CPU1 CONFIG=PTWAM=enable
```

```
SET CPU1 CONFIG=SPEED=0
SET CPU1 CONFIG=DIS_ENABLE=enable
SET CPU1 CONFIG=STEADY_CLOCK=disable
SET CPU1 CONFIG=HALT_ON_UNIMPLEMENTED=disable
SET CPU1 CONFIG=ENABLE_WAM=disable
SET CPU1 CONFIG=REPORT_FAULTS=disable
SET CPU1 CONFIG=TRO_ENABLE=enable
SET CPU1 CONFIG=DRL_FATAL=disable
SET CPU1 CONFIG=USEMAP=disable
SET CPU1 CONFIG=PROM_INSTALLED=enable
SET CPU1 CONFIG=HEX_MODE_INSTALLED=disable
SET CPU1 CONFIG=CACHE_INSTALLED=enable
SET CPU1 CONFIG=CLOCK_SLAVE_INSTALLED=enable
SET CPU2 CONFIG=FAULTBASE=Multics
SET CPU2 CONFIG=NUM=2
SET CPU2 CONFIG=DATA=024000717200
SET CPU2 CONFIG=ADDRESS=000000000000
SET CPU2 CONFIG=PORT=A
SET CPU2 CONFIG=ASSIGNMENT=0
SET CPU2 CONFIG=INTERLACE=0
SET CPU2 CONFIG=ENABLE=1
SET CPU2 CONFIG=INIT_ENABLE=1
SET CPU2 CONFIG=STORE_SIZE=4M
SET CPU2 CONFIG=PORT=B
SET CPU2 CONFIG=ASSIGNMENT=1
SET CPU2 CONFIG=INTERLACE=0
SET CPU2 CONFIG=ENABLE=1
SET CPU2 CONFIG=INIT_ENABLE=1
SET CPU2 CONFIG=STORE_SIZE=4M
SET CPU2 CONFIG=PORT=C
SET CPU2 CONFIG=ASSIGNMENT=2
SET CPU2 CONFIG=INTERLACE=0
SET CPU2 CONFIG=ENABLE=1
SET CPU2 CONFIG=INIT_ENABLE=1
SET CPU2 CONFIG=STORE_SIZE=4M
SET CPU2 CONFIG=PORT=D
SET CPU2 CONFIG=ASSIGNMENT=3
SET CPU2 CONFIG=INTERLACE=0
SET CPU2 CONFIG=ENABLE=1
SET CPU2 CONFIG=INIT_ENABLE=1
SET CPU2 CONFIG=STORE_SIZE=4M
SET CPU2 CONFIG=MODE=Multics
SET CPU2 CONFIG=ENABLE_CACHE=enable
SET CPU2 CONFIG=SDWAM=enable
SET CPU2 CONFIG=PTWAM=enable
SET CPU2 CONFIG=SPEED=0
SET CPU2 CONFIG=DIS_ENABLE=enable
SET CPU2 CONFIG=STEADY_CLOCK=disable
SET CPU2 CONFIG=HALT_ON_UNIMPLEMENTED=disable
SET CPU2 CONFIG=ENABLE_WAM=disable
SET CPU2 CONFIG=REPORT_FAULTS=disable
SET CPU2 CONFIG=TRO_ENABLE=enable
SET CPU2 CONFIG=DRL_FATAL=disable
SET CPU2 CONFIG=USEMAP=disable
SET CPU2 CONFIG=PROM_INSTALLED=enable
```

```
SET CPU2 CONFIG=HEX_MODE_INSTALLED=disable
SET CPU2 CONFIG=CACHE_INSTALLED=enable
SET CPU2 CONFIG=CLOCK_SLAVE_INSTALLED=enable
SET CPU3 CONFIG=FAULTBASE=Multics
SET CPU3 CONFIG=NUM=3
SET CPU3 CONFIG=DATA=024000717200
SET CPU3 CONFIG=ADDRESS=000000000000
SET CPU3 CONFIG=PORT=A
SET CPU3 CONFIG=ASSIGNMENT=0
SET CPU3 CONFIG=INTERLACE=0
SET CPU3 CONFIG=ENABLE=1
SET CPU3 CONFIG=INIT_ENABLE=1
SET CPU3 CONFIG=STORE_SIZE=4M
SET CPU3 CONFIG=PORT=B
SET CPU3 CONFIG=ASSIGNMENT=1
SET CPU3 CONFIG=INTERLACE=0
SET CPU3 CONFIG=ENABLE=1
SET CPU3 CONFIG=INIT_ENABLE=1
SET CPU3 CONFIG=STORE_SIZE=4M
SET CPU3 CONFIG=PORT=C
SET CPU3 CONFIG=ASSIGNMENT=2
SET CPU3 CONFIG=INTERLACE=0
SET CPU3 CONFIG=ENABLE=1
SET CPU3 CONFIG=INIT_ENABLE=1
SET CPU3 CONFIG=STORE_SIZE=4M
SET CPU3 CONFIG=PORT=D
SET CPU3 CONFIG=ASSIGNMENT=3
SET CPU3 CONFIG=INTERLACE=0
SET CPU3 CONFIG=ENABLE=1
SET CPU3 CONFIG=INIT_ENABLE=1
SET CPU3 CONFIG=STORE_SIZE=4M
SET CPU3 CONFIG=MODE=Multics
SET CPU3 CONFIG=ENABLE_CACHE=enable
SET CPU3 CONFIG=SDWAM=enable
SET CPU3 CONFIG=PTWAM=enable
SET CPU3 CONFIG=SPEED=0
SET CPU3 CONFIG=DIS_ENABLE=enable
SET CPU3 CONFIG=STEADY_CLOCK=disable
SET CPU3 CONFIG=HALT_ON_UNIMPLEMENTED=disable
SET CPU3 CONFIG=ENABLE_WAM=disable
SET CPU3 CONFIG=REPORT_FAULTS=disable
SET CPU3 CONFIG=TRO_ENABLE=enable
SET CPU3 CONFIG=DRL_FATAL=disable
SET CPU3 CONFIG=USEMAP=disable
SET CPU3 CONFIG=PROM_INSTALLED=enable
SET CPU3 CONFIG=HEX_MODE_INSTALLED=disable
SET CPU3 CONFIG=CACHE_INSTALLED=enable
SET CPU3 CONFIG=CLOCK_SLAVE_INSTALLED=enable
SET CPU4 CONFIG=FAULTBASE=Multics
SET CPU4 CONFIG=NUM=4
SET CPU4 CONFIG=DATA=024000717200
SET CPU4 CONFIG=ADDRESS=000000000000
SET CPU4 CONFIG=PORT=A
SET CPU4 CONFIG=ASSIGNMENT=0
SET CPU4 CONFIG=INTERLACE=0
```

```
SET CPU4 CONFIG=ENABLE=1
SET CPU4 CONFIG=INIT_ENABLE=1
SET CPU4 CONFIG=STORE_SIZE=4M
SET CPU4 CONFIG=PORT=B
SET CPU4 CONFIG=ASSIGNMENT=1
SET CPU4 CONFIG=INTERLACE=0
SET CPU4 CONFIG=ENABLE=1
SET CPU4 CONFIG=INIT_ENABLE=1
SET CPU4 CONFIG=STORE_SIZE=4M
SET CPU4 CONFIG=PORT=C
SET CPU4 CONFIG=ASSIGNMENT=2
SET CPU4 CONFIG=INTERLACE=0
SET CPU4 CONFIG=ENABLE=1
SET CPU4 CONFIG=INIT_ENABLE=1
SET CPU4 CONFIG=STORE_SIZE=4M
SET CPU4 CONFIG=PORT=D
SET CPU4 CONFIG=ASSIGNMENT=3
SET CPU4 CONFIG=INTERLACE=0
SET CPU4 CONFIG=ENABLE=1
SET CPU4 CONFIG=INIT_ENABLE=1
SET CPU4 CONFIG=STORE_SIZE=4M
SET CPU4 CONFIG=MODE=Multics
SET CPU4 CONFIG=ENABLE_CACHE=enable
SET CPU4 CONFIG=SDWAM=enable
SET CPU4 CONFIG=PTWAM=enable
SET CPU4 CONFIG=SPEED=0
SET CPU4 CONFIG=DIS_ENABLE=enable
SET CPU4 CONFIG=STEADY_CLOCK=disable
SET CPU4 CONFIG=HALT_ON_UNIMPLEMENTED=disable
SET CPU4 CONFIG=ENABLE_WAM=disable
SET CPU4 CONFIG=REPORT_FAULTS=disable
SET CPU4 CONFIG=TRO_ENABLE=enable
SET CPU4 CONFIG=DRL_FATAL=disable
SET CPU4 CONFIG=USEMAP=disable
SET CPU4 CONFIG=PROM_INSTALLED=enable
SET CPU4 CONFIG=HEX_MODE_INSTALLED=disable
SET CPU4 CONFIG=CACHE_INSTALLED=enable
SET CPU4 CONFIG=CLOCK_SLAVE_INSTALLED=enable
SET CPU5 CONFIG=FAULTBASE=Multics
SET CPU5 CONFIG=NUM=5
SET CPU5 CONFIG=DATA=024000717200
SET CPU5 CONFIG=ADDRESS=000000000000
SET CPU5 CONFIG=PORT=A
SET CPU5 CONFIG=ASSIGNMENT=0
SET CPU5 CONFIG=INTERLACE=0
SET CPU5 CONFIG=ENABLE=1
SET CPU5 CONFIG=INIT_ENABLE=1
SET CPU5 CONFIG=STORE_SIZE=4M
SET CPU5 CONFIG=PORT=B
SET CPU5 CONFIG=ASSIGNMENT=1
SET CPU5 CONFIG=INTERLACE=0
SET CPU5 CONFIG=ENABLE=1
SET CPU5 CONFIG=INIT_ENABLE=1
SET CPU5 CONFIG=STORE_SIZE=4M
SET CPU5 CONFIG=PORT=C
```

```
SET CPU5 CONFIG=ASSIGNMENT=2
SET CPU5 CONFIG=INTERLACE=0
SET CPU5 CONFIG=ENABLE=1
SET CPU5 CONFIG=INIT_ENABLE=1
SET CPU5 CONFIG=STORE_SIZE=4M
SET CPU5 CONFIG=PORT=D
SET CPU5 CONFIG=ASSIGNMENT=3
SET CPU5 CONFIG=INTERLACE=0
SET CPU5 CONFIG=ENABLE=1
SET CPU5 CONFIG=INIT_ENABLE=1
SET CPU5 CONFIG=STORE_SIZE=4M
SET CPU5 CONFIG=MODE=Multics
SET CPU5 CONFIG=ENABLE_CACHE=enable
SET CPU5 CONFIG=SDWAM=enable
SET CPU5 CONFIG=PTWAM=enable
SET CPU5 CONFIG=SPEED=0
SET CPU5 CONFIG=DIS_ENABLE=enable
SET CPU5 CONFIG=STEADY_CLOCK=disable
SET CPU5 CONFIG=HALT_ON_UNIMPLEMENTED=disable
SET CPU5 CONFIG=ENABLE_WAM=disable
SET CPU5 CONFIG=REPORT_FAULTS=disable
SET CPU5 CONFIG=TRO_ENABLE=enable
SET CPU5 CONFIG=DRL_FATAL=disable
SET CPU5 CONFIG=USEMAP=disable
SET CPU5 CONFIG=PROM_INSTALLED=enable
SET CPU5 CONFIG=HEX_MODE_INSTALLED=disable
SET CPU5 CONFIG=CACHE_INSTALLED=enable
SET CPU5 CONFIG=CLOCK_SLAVE_INSTALLED=enable
SET IOM0 CONFIG=IOM_BASE=Multics
SET IOM0 CONFIG=MULTIPLEX_BASE=0120
SET IOM0 CONFIG=OS=Multics
SET IOM0 CONFIG=BOOT=tape
SET IOM0 CONFIG=TAPECHAN=012
SET IOM0 CONFIG=CARDCHAN=011
SET IOM0 CONFIG=SCUPOINT=0
SET IOM0 CONFIG=PORT=0
SET IOM0 CONFIG=ADDR=0
SET IOM0 CONFIG=INTERLACE=0
SET IOM0 CONFIG=ENABLE=1
SET IOM0 CONFIG=INITENABLE=0
SET IOM0 CONFIG=HALFSIZE=0
SET IOM0 CONFIG=STORE_SIZE=4M
SET IOM0 CONFIG=PORT=1
SET IOM0 CONFIG=ADDR=1
SET IOM0 CONFIG=INTERLACE=0
SET IOM0 CONFIG=ENABLE=1
SET IOM0 CONFIG=INITENABLE=0
SET IOM0 CONFIG=HALFSIZE=0
SET IOM0 CONFIG=STORE_SIZE=4M
SET IOM0 CONFIG=PORT=2
SET IOM0 CONFIG=ADDR=2
SET IOM0 CONFIG=INTERLACE=0
SET IOM0 CONFIG=ENABLE=1
SET IOM0 CONFIG=INITENABLE=0
SET IOM0 CONFIG=HALFSIZE=0
```

```
SET IOM0 CONFIG=STORE_SIZE=4M
SET IOM0 CONFIG=PORT=3
SET IOM0 CONFIG=ADDR=3
SET IOM0 CONFIG=INTERLACE=0
SET IOM0 CONFIG=ENABLE=1
SET IOM0 CONFIG=INITENABLE=0
SET IOM0 CONFIG=HALFSIZE=0
SET IOM0 CONFIG=STORE_SIZE=4M
SET IOM0 CONFIG=PORT=4
SET IOM0 CONFIG=ENABLE=0
SET IOM0 CONFIG=PORT=5
SET IOM0 CONFIG=ENABLE=0
SET IOM0 CONFIG=PORT=6
SET IOM0 CONFIG=ENABLE=0
SET IOM0 CONFIG=PORT=7
SET IOM0 CONFIG=ENABLE=0
SET IOM1 CONFIG=IOM_BASE=Multics2
SET IOM1 CONFIG=MULTIPLEX_BASE=0121
SET IOM1 CONFIG=OS=Multics
SET IOM1 CONFIG=BOOT=tape
SET IOM1 CONFIG=TAPECHAN=012
SET IOM1 CONFIG=CARDCHAN=011
SET IOM1 CONFIG=SCUPORT=0
SET IOM1 CONFIG=PORT=0
SET IOM1 CONFIG=ADDR=0
SET IOM1 CONFIG=INTERLACE=0
SET IOM1 CONFIG=ENABLE=1
SET IOM1 CONFIG=INITENABLE=0
SET IOM1 CONFIG=HALFSIZE=0
SET IOM1 CONFIG=PORT=1
SET IOM1 CONFIG=ADDR=1
SET IOM1 CONFIG=INTERLACE=0
SET IOM1 CONFIG=ENABLE=1
SET IOM1 CONFIG=INITENABLE=0
SET IOM1 CONFIG=HALFSIZE=0
SET IOM1 CONFIG=PORT=2
SET IOM1 CONFIG=ENABLE=0
SET IOM1 CONFIG=PORT=3
SET IOM1 CONFIG=ENABLE=0
SET IOM1 CONFIG=PORT=4
SET IOM1 CONFIG=ENABLE=0
SET IOM1 CONFIG=PORT=5
SET IOM1 CONFIG=ENABLE=0
SET IOM1 CONFIG=PORT=6
SET IOM1 CONFIG=ENABLE=0
SET IOM1 CONFIG=PORT=7
SET IOM1 CONFIG=ENABLE=0
SET SCU0 CONFIG=MODE=program
SET SCU0 CONFIG=PORT0=enable
SET SCU0 CONFIG=PORT1=enable
SET SCU0 CONFIG=PORT2=enable
SET SCU0 CONFIG=PORT3=enable
SET SCU0 CONFIG=PORT4=enable
SET SCU0 CONFIG=PORT5=enable
SET SCU0 CONFIG=PORT6=enable
```

```
SET SCU0 CONFIG=PORT7=enable
SET SCU0 CONFIG=MASKA=7
SET SCU0 CONFIG=MASKB=off
SET SCU0 CONFIG=LWRSTORESIZE=7
SET SCU0 CONFIG=CYCLIC=0040
SET SCU0 CONFIG=NEA=0200
SET SCU0 CONFIG=ONL=014
SET SCU0 CONFIG=INT=0
SET SCU0 CONFIG=LWR=0
SET SCU0 CONFIG=CLOCK_DELTA=0
SET SCU1 CONFIG=MODE=program
SET SCU1 CONFIG=PORT0=enable
SET SCU1 CONFIG=PORT1=enable
SET SCU1 CONFIG=PORT2=enable
SET SCU1 CONFIG=PORT3=enable
SET SCU1 CONFIG=PORT4=enable
SET SCU1 CONFIG=PORT5=enable
SET SCU1 CONFIG=PORT6=enable
SET SCU1 CONFIG=PORT7=enable
SET SCU1 CONFIG=MASKA=off
SET SCU1 CONFIG=MASKB=off
SET SCU1 CONFIG=LWRSTORESIZE=7
SET SCU1 CONFIG=CYCLIC=0040
SET SCU1 CONFIG=NEA=0200
SET SCU1 CONFIG=ONL=014
SET SCU1 CONFIG=INT=0
SET SCU1 CONFIG=LWR=0
SET SCU1 CONFIG=CLOCK_DELTA=0
SET SCU2 CONFIG=MODE=program
SET SCU2 CONFIG=PORT0=enable
SET SCU2 CONFIG=PORT1=enable
SET SCU2 CONFIG=PORT2=enable
SET SCU2 CONFIG=PORT3=enable
SET SCU2 CONFIG=PORT4=enable
SET SCU2 CONFIG=PORT5=enable
SET SCU2 CONFIG=PORT6=enable
SET SCU2 CONFIG=PORT7=enable
SET SCU2 CONFIG=MASKA=off
SET SCU2 CONFIG=MASKB=off
SET SCU2 CONFIG=LWRSTORESIZE=7
SET SCU2 CONFIG=CYCLIC=0040
SET SCU2 CONFIG=NEA=0200
SET SCU2 CONFIG=ONL=014
SET SCU2 CONFIG=INT=0
SET SCU2 CONFIG=LWR=0
SET SCU2 CONFIG=CLOCK_DELTA=0
SET SCU3 CONFIG=MODE=program
SET SCU3 CONFIG=PORT0=enable
SET SCU3 CONFIG=PORT1=enable
SET SCU3 CONFIG=PORT2=enable
SET SCU3 CONFIG=PORT3=enable
SET SCU3 CONFIG=PORT4=enable
SET SCU3 CONFIG=PORT5=enable
SET SCU3 CONFIG=PORT6=enable
SET SCU3 CONFIG=PORT7=enable
```



```
SET SCU3 CONFIG=MASKA=off
SET SCU3 CONFIG=MASKB=off
SET SCU3 CONFIG=LWRSTORESIZE=7
SET SCU3 CONFIG=CYCLIC=0040
SET SCU3 CONFIG=NEA=0200
SET SCU3 CONFIG=ONL=014
SET SCU3 CONFIG=INT=0
SET SCU3 CONFIG=LWR=0
SET SCU3 CONFIG=CLOCK_DELTA=0
SET FNP0 CONFIG=MAILBOX=03400
SET FNP0 IPC_NAME=fnp-a
SET FNP1 CONFIG=MAILBOX=03700
SET FNP1 IPC_NAME=fnp-b
SET FNP2 CONFIG=MAILBOX=04200
SET FNP2 IPC_NAME=fnp-c
SET FNP3 CONFIG=MAILBOX=04500
SET FNP3 IPC_NAME=fnp-d
SET FNP4 CONFIG=MAILBOX=05000
SET FNP4 IPC_NAME=fnp-e
SET FNP5 CONFIG=MAILBOX=05300
SET FNP5 IPC_NAME=fnp-f
SET FNP6 CONFIG=MAILBOX=05600
SET FNP6 IPC_NAME=fnp-g
SET FNP7 CONFIG=MAILBOX=06100
SET FNP7 IPC_NAME=fnp-h
SET MTP0 BOOT_DRIVE=0
SET MTP0 NAME=MTP0
CABLE IOM0 012 MTP0 0
CABLE IOM1 012 MTP0 1
CABLE MTP0 1 TAPE1
SET TAPE1 NAME=tapa_01
CABLE MTP0 2 TAPE2
SET TAPE2 NAME=tapa_02
CABLE MTP0 3 TAPE3
SET TAPE3 NAME=tapa_03
CABLE MTP0 4 TAPE4
SET TAPE4 NAME=tapa_04
CABLE MTP0 5 TAPE5
SET TAPE5 NAME=tapa_05
CABLE MTP0 6 TAPE6
SET TAPE6 NAME=tapa_06
CABLE MTP0 7 TAPE7
SET TAPE7 NAME=tapa_07
CABLE MTP0 8 TAPE8
SET TAPE8 NAME=tapa_08
CABLE MTP0 9 TAPE9
SET TAPE9 NAME=tapa_09
CABLE MTP0 10 TAPE10
SET TAPE10 NAME=tapa_10
CABLE MTP0 11 TAPE11
SET TAPE11 NAME=tapa_11
CABLE MTP0 12 TAPE12
SET TAPE12 NAME=tapa_12
CABLE MTP0 13 TAPE13
SET TAPE13 NAME=tapa_13
```

```
CABLE MTP0 14 TAPE14
SET TAPE14 NAME=tapa_14
CABLE MTP0 15 TAPE15
SET TAPE15 NAME=tapa_15
CABLE MTP0 16 TAPE16
SET TAPE16 NAME=tapa_16
SET IPC0 NAME=IPC0
CABLE IOM0 013 IPC0 0
CABLE IOM1 013 IPC0 1
CABLE IPC0 0 DISK0
SET DISK0 TYPE=3381
SET DISK0 NAME=dsk_a_00
cable IPC0 1 DISK1
set disk1 type=3381
set disk1 name=dsk_a_01
CABLE IPC0 2 DISK2
SET DISK2 TYPE=3381
SET DISK2 NAME=dsk_a_02
CABLE IPC0 3 DISK3
SET DISK3 TYPE=3381
SET DISK3 NAME=dsk_a_03
SET MSP0 NAME=MSP0
CABLE IOM0 014 MSP0 0
CABLE IOM1 014 MSP0 1
CABLE MSP0 1 DISK4
SET disk4 TYPE=d501
SET disk4 NAME=dsk_b_01
CABLE MSP0 2 DISK5
SET DISK5 TYPE=d501
SET DISK5 NAME=dsk_b_02
CABLE MSP0 3 DISK6
SET DISK6 TYPE=d501
SET DISK6 NAME=dsk_b_03
CABLE MSP0 4 DISK7
SET DISK7 TYPE=d501
SET DISK7 NAME=dsk_b_04
CABLE MSP0 5 DISK8
SET DISK8 TYPE=d451
SET DISK8 NAME=dsk_b_05
CABLE MSP0 6 DISK9
SET DISK9 TYPE=d451
SET DISK9 NAME=dsk_b_06
CABLE MSP0 7 DISK10
SET DISK10 TYPE=d451
SET DISK10 NAME=dsk_b_07
CABLE MSP0 8 DISK11
SET DISK11 TYPE=d451
SET DISK11 NAME=dsk_b_08
CABLE MSP0 9 DISK12
SET DISK12 TYPE=d500
SET DISK12 NAME=dsk_b_09
CABLE MSP0 10 DISK13
SET DISK13 TYPE=d500
SET DISK13 NAME=dsk_b_10
CABLE IPC0 4 DISK14
```

```
SET DISK14 TYPE=3381
SET DISK14 NAME=dska_04
CABLE IPC0 5 DISK15
SET DISK15 TYPE=3381
SET DISK15 NAME=dska_05
CABLE IPC0 6 DISK16
SET DISK16 TYPE=3381
SET DISK16 NAME=dska_06
CABLE IPC0 7 DISK17
SET DISK17 TYPE=3381
SET DISK17 NAME=dska_07
CABLE IPC0 8 DISK18
SET DISK18 TYPE=3381
SET DISK18 NAME=dska_08
CABLE IPC0 9 DISK19
SET DISK19 TYPE=3381
SET DISK19 NAME=dska_09
CABLE IPC0 10 DISK20
SET DISK20 TYPE=3381
SET DISK20 NAME=dska_10
CABLE IPC0 11 DISK21
SET DISK21 TYPE=3381
SET DISK21 NAME=dska_11
CABLE IPC0 12 DISK22
SET DISK22 TYPE=3381
SET DISK22 NAME=dska_12
CABLE IPC0 13 DISK23
SET DISK23 TYPE=3381
SET DISK23 NAME=dska_13
CABLE IPC0 14 DISK24
SET DISK24 TYPE=3381
SET DISK24 NAME=dska_14
CABLE IPC0 15 DISK25
SET DISK25 TYPE=3381
SET DISK25 NAME=dska_15
CABLE IOMA 036 OPC0
CABLE IOMA 053 OPC1
SET OPC1 CONFIG=MODEL=m6601
CABLE IOMA 020 FNPD
CABLE IOMA 021 FNPA
CABLE IOMA 022 FNPB
CABLE IOMA 023 FNPC
CABLE IOMA 024 FNPE
CABLE IOMA 025 FNPF
CABLE IOMA 026 FNPG
CABLE IOMA 027 FNPH
CABLE IOM0 015 URP0
SET URP0 NAME=urpa
CABLE URP0 1 RDR0
SET RDR0 NAME=rdra
CABLE IOM0 016 URP1
SET URP1 NAME=urpb
CABLE URP1 1 PUN0
SET PUN0 NAME=puna
CABLE IOM0 017 URP2
```

```
SET URP2 NAME=urpc
CABLE URP2 1 PRT0
SET PRT0 NAME=prta
CABLE IOMA 050 URP3
SET URP3 NAME=urpd
CABLE URP3 1 PRT1
SET PRT1 NAME=prtb
CABLE IOMA 051 URP4
SET URP4 NAME=urpe
CABLE URP4 1 PRT2
SET PRT2 NAME=prtc
CABLE IOMA 052 URP5
SET URP5 NAME=urpf
CABLE URP5 1 PRT3
SET PRT3 NAME=prtd
CABLE IOMA 055 URP6
SET URP6 NAME=urpg
CABLE URP6 1 RDRB
SET RDR1 NAME=rdrb
CABLE IOMA 056 URP7
SET URP7 NAME=urph
CABLE URP7 1 RDRC
SET RDR2 NAME=rdrc
CABLE IOMA 057 URP8
SET URP8 NAME=urpi
CABLE URP8 1 PUNB
SET PUN1 NAME=punb
CABLE IOMA 060 URP9
SET URP9 NAME=urpj
CABLE URP9 1 PUNC
SET PUN2 NAME=punc
CABLE SCU0 0 IOM0 0
CABLE SCU1 0 IOM0 1
CABLE SCU2 0 IOM0 2
CABLE SCU3 0 IOM0 3
CABLE SCU0 1 IOM1 0
CABLE SCU1 1 IOM1 1
CABLE SCU2 1 IOM1 2
CABLE SCU3 1 IOM1 3
CABLE SCU0 7 CPU0 0
CABLE SCU0 6 CPU1 0
CABLE SCU0 5 CPU2 0
CABLE SCU0 4 CPU3 0
CABLE SCU0 3 CPU4 0
CABLE SCU0 2 CPU5 0
CABLE SCU1 7 CPU0 1
CABLE SCU1 6 CPU1 1
CABLE SCU1 5 CPU2 1
CABLE SCU1 4 CPU3 1
CABLE SCU1 3 CPU4 1
CABLE SCU1 2 CPU5 1
CABLE SCU2 7 CPU0 2
CABLE SCU2 6 CPU1 2
CABLE SCU2 5 CPU2 2
CABLE SCU2 4 CPU3 2
```

```

CABLE SCU2 3 CPU4 2
CABLE SCU2 2 CPU5 2
CABLE SCU3 7 CPU0 3
CABLE SCU3 6 CPU1 3
CABLE SCU3 5 CPU2 3
CABLE SCU3 4 CPU3 3
CABLE SCU3 3 CPU4 3
CABLE SCU3 2 CPU5 3
SET CPU0 RESET
SET SCU0 RESET
SET SCU1 RESET
SET SCU2 RESET
SET SCU3 RESET
SET IOM0 RESET
SET CPU NUNITS=6
SET SYS CONFIG=CONNECT_TIME=-1

```

Default Base System Configuration

The following listing of configuration details, generated by the “**SHOW CONFIGURATION**” command, shows the configuration state of the simulator immediately after the execution of the *default base system script* (documented in the previous section of this chapter).

This configuration state is the default state upon simulator startup. The simulator may also be explicitly reconfigured to this state after startup by using the “**DEFAULT_BASE_SYSTEM**” command.

- **NOTE:** The configuration details of individual FNP lines have been excluded for brevity.
- See the documentation for the “**DEFAULT_BASE_SYSTEM**” command (in the **Simulator Command Reference** chapter) and the “**Default Base System Script**” section of this chapter for additional details.

```
DPS8/M simulator configuration
```

```
CPU 6 units
```

```
  CPU0
```

```
    16MW
```

```
  CPU1
```

```
    16MW
```

```
  CPU2
```

```
    16MW
```

```
  CPU3
```

```
    16MW
```

```
  CPU4
```

```
    16MW
```

```
  CPU5
```

```
    16MW
```

```
IOM 2 units
```

```
  IOM0
```

```
  IOM1
```

```
TAPE 17 units
```

```
  TAPE0
```

```
    status : not attached
```

```
name      : default
capacity  : 40MB
TAPE1
status    : not attached
name      : tapa_01
capacity  : 40MB
TAPE2
status    : not attached
name      : tapa_02
capacity  : 40MB
TAPE3
status    : not attached
name      : tapa_03
capacity  : 40MB
TAPE4
status    : not attached
name      : tapa_04
capacity  : 40MB
TAPE5
status    : not attached
name      : tapa_05
capacity  : 40MB
TAPE6
status    : not attached
name      : tapa_06
capacity  : 40MB
TAPE7
status    : not attached
name      : tapa_07
capacity  : 40MB
TAPE8
status    : not attached
name      : tapa_08
capacity  : 40MB
TAPE9
status    : not attached
name      : tapa_09
capacity  : 40MB
TAPE10
status    : not attached
name      : tapa_10
capacity  : 40MB
TAPE11
status    : not attached
name      : tapa_11
capacity  : 40MB
TAPE12
status    : not attached
name      : tapa_12
capacity  : 40MB
TAPE13
status    : not attached
name      : tapa_13
capacity  : 40MB
TAPE14
```

```
    status : not attached
    name   : tapa_14
    capacity : 40MB
TAPE15
    status : not attached
    name   : tapa_15
    capacity : 40MB
TAPE16
    status : not attached
    name   : tapa_16
    capacity : 40MB
MTP 1 unit
    boot   : 0
    name   : MTP0
FNP 8 units
FNP0
    FNP IPC name: fnp-a
           name: default
FNP1
    FNP IPC name: fnp-b
           name: default
FNP2
    FNP IPC name: fnp-c
           name: default
FNP3
    FNP IPC name: fnp-d
           name: default
FNP4
    FNP IPC name: fnp-e
           name: default
FNP5
    FNP IPC name: fnp-f
           name: default
FNP6
    FNP IPC name: fnp-g
           name: default
FNP7
    FNP IPC name: fnp-h
           name: default
DISK 26 units
DISK0
    status : not attached 451KW
    type   : 3381
    name   : dska_00
DISK1
    status : not attached 451KW
    type   : 3381
    name   : dska_01
DISK2
    status : not attached 451KW
    type   : 3381
    name   : dska_02
DISK3
    status : not attached 451KW
    type   : 3381
```

```
name      : dska_03
DISK4
status    : not attached 1075KW
type      : d501
name      : dskb_01
DISK5
status    : not attached 1075KW
type      : d501
name      : dskb_02
DISK6
status    : not attached 1075KW
type      : d501
name      : dskb_03
DISK7
status    : not attached 1075KW
type      : d501
name      : dskb_04
DISK8
status    : not attached 616KW
type      : d451
name      : dskb_05
DISK9
status    : not attached 616KW
type      : d451
name      : dskb_06
DISK10
status    : not attached 616KW
type      : d451
name      : dskb_07
DISK11
status    : not attached 616KW
type      : d451
name      : dskb_08
DISK12
status    : not attached 618KW
type      : d500
name      : dskb_09
DISK13
status    : not attached 618KW
type      : d500
name      : dskb_10
DISK14
status    : not attached 451KW
type      : 3381
name      : dska_04
DISK15
status    : not attached 451KW
type      : 3381
name      : dska_05
DISK16
status    : not attached 451KW
type      : 3381
name      : dska_06
DISK17
status    : not attached 451KW
```



```
type      : 3381
name      : dska_07
DISK18
status    : not attached 451KW
type      : 3381
name      : dska_08
DISK19
status    : not attached 451KW
type      : 3381
name      : dska_09
DISK20
status    : not attached 451KW
type      : 3381
name      : dska_10
DISK21
status    : not attached 451KW
type      : 3381
name      : dska_11
DISK22
status    : not attached 451KW
type      : 3381
name      : dska_12
DISK23
status    : not attached 451KW
type      : 3381
name      : dska_13
DISK24
status    : not attached 451KW
type      : 3381
name      : dska_14
DISK25
status    : not attached 451KW
type      : 3381
name      : dska_15
IPC  2 units
IPC0
name     : IPC0
IPC1
name     : default
MSP  2 units
MSP0
name     : MSP0
MSP1
name     : default
SCU  4 units
SCU0

SCU1

SCU2

SCU3

OPC  2 units
OPC0
```

```
  autoinput: empty
  flags    : autoaccept=0, noempty=0, attn_flush=1
  name     : OPC0
  port     : disabled
  address  : any
  password : MulticsRulez
OPC1
  autoinput: empty
  flags    : autoaccept=0, noempty=0, attn_flush=1
  name     : OPC1
  port     : disabled
  address  : any
  password : MulticsRulez
URP 10 units
URP0
  status  : not attached
  name    : urpa
URP1
  status  : not attached
  name    : urpb
URP2
  status  : not attached
  name    : urpc
URP3
  status  : not attached
  name    : urpd
URP4
  status  : not attached
  name    : urpe
URP5
  status  : not attached
  name    : urpf
URP6
  status  : not attached
  name    : urpg
URP7
  status  : not attached
  name    : urph
URP8
  status  : not attached
  name    : urpi
URP9
  status  : not attached
  name    : urpj
RDR 3 units
RDR0
  status  : not attached
  name    : rdra
RDR1
  status  : not attached
  name    : rdrb
RDR2
  status  : not attached
  name    : rdrc
PUN 3 units
```

```

PUN0
  status   : not attached
  name     : puna
  logcards : 0
PUN1
  status   : not attached
  name     : punb
  logcards : 0
PUN2
  status   : not attached
  name     : punc
  logcards : 0
PRT 4 units
PRT0
  status   : not attached
  name     : prta
  model    : 1600
  split    : 0
PRT1
  status   : not attached
  name     : prtb
  model    : 1600
  split    : 0
PRT2
  status   : not attached
  name     : prtc
  model    : 1600
  split    : 0
PRT3
  status   : not attached
  name     : prtd
  model    : 1600
  split    : 0

```

Default Base System Cable Dump

The following cabling configuration listing, generated by the **CABLE DUMP** command, shows the cabling configuration of the simulator immediately after the execution of the *default base system script* (documented in an earlier section of this chapter).

- See the documentation for the **CABLE** commands (**CABLE**, **UNCABLE**, **CABLE_RIPOUT**, **CABLE_SHOW**, **CABLE DUMP**, **CABLE GRAPH**) in the **Simulator Command Reference** chapter for additional details.

```

SCU <--> IOM
  SCU port --> IOM port
    0  0      0  0
    0  1      1  0
    1  0      0  1
    1  1      1  1
    2  0      0  2
    2  1      1  2
    3  0      0  3
    3  1      1  3

```

IOM port --> SCU port

0	0	0	0
0	1	1	0
0	2	2	0
0	3	3	0
1	0	0	1
1	1	1	1
1	2	2	1
1	3	3	1

SCU <--> CPU

SCU port --> CPU port

0	2	5	0
0	3	4	0
0	4	3	0
0	5	2	0
0	6	1	0
0	7	0	0
1	2	5	1
1	3	4	1
1	4	3	1
1	5	2	1
1	6	1	1
1	7	0	1
2	2	5	2
2	3	4	2
2	4	3	2
2	5	2	2
2	6	1	2
2	7	0	2
3	2	5	3
3	3	4	3
3	4	3	3
3	5	2	3
3	6	1	3
3	7	0	3

CPU port --> SCU port subport

0	0	0	7	0
0	1	1	7	0
0	2	2	7	0
0	3	3	7	0
1	0	0	6	0
1	1	1	6	0
1	2	2	6	0
1	3	3	6	0
2	0	0	5	0
2	1	1	5	0
2	2	2	5	0
2	3	3	5	0
3	0	0	4	0
3	1	1	4	0
3	2	2	4	0
3	3	3	4	0
4	0	0	3	0
4	1	1	3	0

```

4 2 2 3 0
4 3 3 3 0
5 0 0 2 0
5 1 1 2 0
5 2 2 2 0
5 3 3 2 0

```

IOM <--> controller

IOM	chan	-->	ctlr idx	port	ctlr type	chan type	device	board	command
0	10		0	0	MTP	PSI	0x4e5480	0x5aaa60	0x459660
0	11		0	0	IPC	PSI	0x4e5540	0x5abb60	0x433f10
0	12		0	0	MSP	PSI	0x4e5600	0x5ab2e0	0x433f10
0	13		0	0	URP	PSI	0x4e56c0	0x4e4b40	0x460cd0
0	14		1	0	URP	PSI	0x4e56c0	0x4e4bc8	0x460cd0
0	15		2	0	URP	PSI	0x4e56c0	0x4e4c50	0x460cd0
0	16		3	0	FNP	Direct	0x4e3d00	0x4e3f58	0x44c490
0	17		0	0	FNP	Direct	0x4e3d00	0x4e3dc0	0x44c490
0	18		1	0	FNP	Direct	0x4e3d00	0x4e3e48	0x44c490
0	19		2	0	FNP	Direct	0x4e3d00	0x4e3ed0	0x44c490
0	20		4	0	FNP	Direct	0x4e3d00	0x4e3fe0	0x44c490
0	21		5	0	FNP	Direct	0x4e3d00	0x4e4068	0x44c490
0	22		6	0	FNP	Direct	0x4e3d00	0x4e40f0	0x44c490
0	23		7	0	FNP	Direct	0x4e3d00	0x4e4178	0x44c490
0	30		0	0	OPC	CPI	0x4e4640	0x4e4700	0x41e010
0	40		3	0	URP	PSI	0x4e56c0	0x4e4cd8	0x460cd0
0	41		4	0	URP	PSI	0x4e56c0	0x4e4d60	0x460cd0
0	42		5	0	URP	PSI	0x4e56c0	0x4e4de8	0x460cd0
0	43		1	0	OPC	CPI	0x4e4640	0x4e4788	0x41e010
0	45		6	0	URP	PSI	0x4e56c0	0x4e4e70	0x460cd0
0	46		7	0	URP	PSI	0x4e56c0	0x4e4ef8	0x460cd0
0	47		8	0	URP	PSI	0x4e56c0	0x4e4f80	0x460cd0
0	48		9	0	URP	PSI	0x4e56c0	0x4e5008	0x460cd0
1	10		0	1	MTP	PSI	0x4e5480	0x5aaa60	0x459660
1	11		0	1	IPC	PSI	0x4e5540	0x5abb60	0x433f10
1	12		0	1	MSP	PSI	0x4e5600	0x5ab2e0	0x433f10

MTP port --> IOM channel

```

0 0 0 10
0 1 1 10

```

MSP port --> IOM channel

```

0 0 0 12
0 1 1 12

```

IPC port --> IOM channel

```

0 0 0 11
0 1 1 11

```

URP port --> IOM channel

```

0 0 0 13
1 0 0 14
2 0 0 15
3 0 0 40
4 0 0 41
5 0 0 42
6 0 0 45
7 0 0 46
8 0 0 47

```

```

 9   0   0  48
FNP port --> IOM channel
 0   0   0  17
 1   0   0  18
 2   0   0  19
 3   0   0  16
 4   0   0  20
 5   0   0  21
 6   0   0  22
 7   0   0  23
DIA port --> IOM channel
OPC port --> IOM channel
 0   0   0  30
 1   0   0  43

```

controller <--> device

```

MTP dev_code --> TAPE  command
 0   1         1    0x459660
 0   2         2    0x459660
 0   3         3    0x459660
 0   4         4    0x459660
 0   5         5    0x459660
 0   6         6    0x459660
 0   7         7    0x459660
 0   8         8    0x459660
 0   9         9    0x459660
 0  10        10    0x459660
 0  11        11    0x459660
 0  12        12    0x459660
 0  13        13    0x459660
 0  14        14    0x459660
 0  15        15    0x459660
 0  16        16    0x459660

```

```

TAPE --> MTP  dev_code type
 1     0     1    MTP
 2     0     2    MTP
 3     0     3    MTP
 4     0     4    MTP
 5     0     5    MTP
 6     0     6    MTP
 7     0     7    MTP
 8     0     8    MTP
 9     0     9    MTP
10     0    10    MTP
11     0    11    MTP
12     0    12    MTP
13     0    13    MTP
14     0    14    MTP
15     0    15    MTP
16     0    16    MTP

```

```

IPC dev_code --> DISK  command
 0   0         0    0x433f10
 0   1         1    0x433f10
 0   2         2    0x433f10
 0   3         3    0x433f10

```

```

0      4      14  0x433f10
0      5      15  0x433f10
0      6      16  0x433f10
0      7      17  0x433f10
0      8      18  0x433f10
0      9      19  0x433f10
0     10     20  0x433f10
0     11     21  0x433f10
0     12     22  0x433f10
0     13     23  0x433f10
0     14     24  0x433f10
0     15     25  0x433f10
MSP  dev_code --> DISK  command
0      1      4  0x433f10
0      2      5  0x433f10
0      3      6  0x433f10
0      4      7  0x433f10
0      5      8  0x433f10
0      6      9  0x433f10
0      7     10  0x433f10
0      8     11  0x433f10
0      9     12  0x433f10
0     10     13  0x433f10
DISK --> CTRLR dev_code type
0      0      0   IPC
1      0      1   IPC
2      0      2   IPC
3      0      3   IPC
4      0      1   MSP
5      0      2   MSP
6      0      3   MSP
7      0      4   MSP
8      0      5   MSP
9      0      6   MSP
10     0      7   MSP
11     0      8   MSP
12     0      9   MSP
13     0     10   MSP
14     0      4   IPC
15     0      5   IPC
16     0      6   IPC
17     0      7   IPC
18     0      8   IPC
19     0      9   IPC
20     0     10   IPC
21     0     11   IPC
22     0     12   IPC
23     0     13   IPC
24     0     14   IPC
25     0     15   IPC
URP  dev_code --> URP  command
0      1      0  0x42a960
1      1      0  0x429800
2      1      0  0x45c610
3      1      1  0x45c610

```

```
4      1      2  0x45c610
5      1      3  0x45c610
6      1      1  0x42a960
7      1      2  0x42a960
8      1      1  0x429800
9      1      2  0x429800
RDR --> URP  dev_code type
0      0      1  URP
1      6      1  URP
2      7      1  URP
PUN --> URP  dev_code type
0      1      1  URP
1      8      1  URP
2      9      1  URP
PRT --> URP  dev_code type
0      2      1  URP
1      3      1  URP
2      4      1  URP
3      5      1  URP
```


External Simulator Utilities

The following sections document the various utilities included with the simulator distribution.

Multics Punched Card Utility – `punutil`

The “`punutil`” utility (version 0.2) manipulates punched card deck files for use with simulated punch devices.

```
Multics Punch Utility Program
```

```
Invoking:
```

```
  punutil [options]
```

```
Where options are:
```

- `-h, --help` = Output this message
- `-a, --auto` = Attempt to automatically determine the type of card deck
(Default; disables any previously enabled output options)
- `-n, --no-auto` = Disable auto selection of the card format
(You must specify output control options)
- `-v, --version` = Add version information to stderr output

```
Output control options:
```

```
  By default 'auto' mode is active, where a scan attempts to determine the  
  type of deck. The scan order is: 'MCC', '7punch', and 'raw' (if neither  
  of the first two seem to apply). Note that the options below are  
  mutually exclusive.
```

- `-7, --7punch` = Interpret the cards as 7punch data and output the data
(currently not supported!)
- `-c, --cards` = Output an ASCII art form of the punched cards with an '*'
representing the punches
- `-f, --flip` = If --cards is specified, the banner cards will be 'flipped'
so they can be read normally
- `-g, --glyphs` = Output the glyphs parsed from the banner cards as ASCII
- `-m, --mcc` = Interpret the cards as MCC Punch Codes
(Invalid punch codes will be converted to spaces)
- `-r, --raw` = Dump the raw card data as 12-bit words in column order

```
This program will read a card spool file produced by the DPS8M Simulator,  
parse it, and produce the requested output on standard output.
```

```
Note that only one output mode may be selected per execution.
```

```
This software is made available under the terms of the ICU License.  
For complete license details, see the LICENSE file included with the  
software or https://gitlab.com/dps8m/dps8m/-/blob/master/LICENSE.md
```

Multics Print File Utility — prt2pdf

The “**prt2pdf**” utility (version 3.0.3) converts the output of simulated line printer devices to ISO 32000 Portable Document Format (*PDF*).

prt2pdf: A filter to convert text files with ASA carriage control to a PDF.

prt2pdf(1) reads input from standard input. The first character of each line is interpreted as a control character. Lines beginning with any character other than those listed in the ASA carriage-control characters table are interpreted as if they began with a blank, and an appropriate diagnostic appears on standard error. The first character of each line is not printed.

Control Character	Description
+	Do not advance; overstrike previous line.
blank	Advance one line.
null lines	Treated as if they started with a blank
0	Advance two lines.
-	Advance three lines (IBM extension).
1	Advance to top of next page.
all others	Discarded (except for extensions listed below)

Extensions:

H Advance one-half line.
 R Do not advance; overstrike previous line. Use red text color
 G Do not advance; overstrike previous line. Use green text color
 B Do not advance; overstrike previous line. Use blue text color
 r Advance one line. Use red text color
 g Advance one line. Use green text color
 b Advance one line. Use blue text color
 ^ Overprint but add 127 to the ADE value of the character
 (i.e. use ASCII extended character set)

PRINTABLE PAGE AREA:

The page size may be specified using -H for height, -W for width, and -u to indicate the points per unit (72 makes H and W in inches, 1 is used when units are in font points). For example:

```
-u 72 -H 8.5 -W 11 # page Height and Width in inches
-u 72 -B 0.5 -L 0.5 -R 0.5 -T 0.5 # margins (Top, Bottom, Left, Right)
```

Common media sizes with -u 1:

Name	W	H	
Letterdj (11x8.5)	792	612	(LandScape)
A4dj	842	595	
Letter (8.5x11)	612	792	(Portrait)
Legal	612	1008	
A5	420	595	
A4	595	842	
A3	842	1190	

SHADING:

```

-g 0.800781    # gray-scale value for shaded bars ( 0 < g 1 )
                # 0 is black, 1 is white.
-i 2           # repeat shade pattern every N lines
-d ' '        # dashcode pattern (seems buggy!)
-G            # green bar

MARGIN LABELS:
-s ''         # top middle page label.
-t ''         # top left page label.
-P           # add page numbers to right corners

TEXT OPTIONS:
-l 60         # lines per page
-f Courier    # font names: Courier, Courier-Bold,Courier-Oblique
                Helvetica, Symbol, Times-Bold, Helvetica-Bold,
                ZapfDingbats, Times-Italic, Helvetica-Oblique,
                Times-BoldItalic, Helvetica-BoldOblique,
                Times-Roman, Courier-BoldOblique

OTHER OPTIONS:
-S 0         # right shift 1 for non-ASA files
-N          # add line numbers

VERSION AND HELP:
-v          # version number
-h          # display this help

ENVIRONMENT VARIABLES:
$IMPACT_TOP # will be printed in large red letters across the page top
$IMPACT_GRAY # sets the default gray-scale value, same as the -g switch

```

Multics Tape Conversion Utility – tap2raw

The “**tap2raw**” utility (version 1.1.1) converts **tap** files produced by the simulated tape devices to **raw** format.

```

Usage:
tap2raw < infile.tap > outfile.raw
tap2raw [ -v | --version ]
tap2raw [ -h | --help ]

```


Tips and Tricks

Protecting DPS8M in low-memory situations

If the simulator is terminated unexpectedly, data loss or corruption could occur. Users may wish to exempt the **DPS8M** process from being terminated in low memory situations.

- Exempting the simulator from the operating system out-of-memory handler does *not* necessarily ensure stability in out-of-memory situations. The system could decide to kill other important system processes leaving the machine in a hung or otherwise unusable state. It is always best to ensure that enough memory is free to avoid triggering the out-of-memory condition in the first place.

Exempting DPS8M from the Linux OOM Killer

Linux users may wish to exempt the **DPS8M** process from the Linux “**OOM (out-of-memory) Killer**” to avoid unexpected terminations in low memory situations.

Before initiating a kernel panic due to total memory exhaustion, the Linux *OOM Killer* is activated to inspect all running processes and assigns a score to each one. It then terminates the process with the highest score, repeating the procedure until enough memory has been freed to avoid a kernel panic.

The actual scoring algorithm is complex and varies greatly depending on the Linux kernel version. The algorithm may be further tuned by the vendor or distributor. The score is generally based on a large number of factors including the amount of memory allocated by a process, the length of time a process has been running, the status of overall system memory overcommitment, the user running the process, any cgroups-based configuration constraints, and most importantly, an “oom_adj” value.

- There may be additional considerations involved if you are running the simulator in a namespace or container (e.g. Docker, Kubernetes, LXC, Virtuozzo/OpenVZ, etc.) or using a Linux distribution with vendor kernel modifications or additional system daemons (e.g. Android’s ‘lmkd’, systemd’s ‘systemd-oomd’, Facebook’s ‘oomd’, the ‘earlyoom’ daemon, etc.) that are outside the scope of this documentation. Consult your Linux distribution documentation for further details.

Users who are running the simulator in production environments should adjust the “oom_adj” value so other processes are considered for termination first (or to exempt the simulator completely). The “oom_adj” is one of 32 values ranging from ‘14’ through ‘-17’, with ‘14’ indicating the process should most likely be selected by the *OOM Killer* and ‘-16’ indicating the process should most likely *not* be selected by the *OOM Killer*. The special value of ‘-17’ exempts the process from consideration entirely.

At the time of writing, this functionality is *not* integrated in the simulator itself, because allowing a non-`root` process to *securely* adjust its own “oom_adj” value requires adding a compile-time dependency on the “libcap” headers and a run-time dependency on the “libcap” library.

- To adjust the “oom_adj” value to ‘-17’ for all running “dps8” processes, use the following shell commands:

```
pgrep "dps8" | while read pid; do
  printf '%s\n' "-17" | sudo tee "/proc/${pid:?}/oom_adj"
done
```

- If running with appropriate privileges (*i.e.* from `root`'s crontab) you can use the following shell commands:

```
pgrep "dps8" | while read pid; do
  printf '%s\n' "-17" > "/proc/${pid:?}/oom_adj"
done
```

Automatic Linux `oom_adj` adjustment

If you want to automate the process of adjusting the “`oom_adj`” value, or completely exempt the simulator from consideration by the Linux *OOM Killer* each time the simulator starts, you can do so using “`sudo`” and a “`bash`” script.

1. First, create the file “`/usr/local/sbin/dps8-oom`” containing the “`dps8-oom`” script. This script is available from “<https://gitlab.com/dps8m/misc-scripts/-/raw/master/dps8-oom>”:

- Download using ‘`wget`’:

```
wget -O - - https://gitlab.com/dps8m/misc-scripts/-/raw/master/dps8-oom | \
sudo tee /usr/local/sbin/dps8-oom > /dev/null
```

- Download using ‘`curl`’:

```
curl -fSSL https://gitlab.com/dps8m/misc-scripts/-/raw/master/dps8-oom | \
sudo tee /usr/local/sbin/dps8-oom > /dev/null
```

2. Ensure the script has secure ownership and proper permissions:

```
sudo chown root:root /usr/local/sbin/dps8-oom
sudo chmod 755 /usr/local/sbin/dps8-oom
```

3. Next, use the “`sudo visudo`” command to edit the “`sudoers`” file and add the following line:

```
username ALL=(ALL) NOPASSWD: /usr/local/sbin/dps8-oom
```

- You should replace “`username`” in the text above with the actual name of the user that runs the simulator. If you want to allow all users of a particular group to run the script, prefix the group name with the “`%`” symbol (*i.e.* “`%wheel`”).

4. Finally, at the top of your simulator script (`INI` file), add the following line:

```
! sudo /usr/local/sbin/dps8-oom
```

- You will see a message similar to the following when the “`dps8-oom`” script is called from the simulator:

```
PID 375995 oom_adj value adjusted successfully.
```

Exempting DPS8M from FreeBSD OOM termination

The **FreeBSD** operating system will automatically terminate processes that are not explicitly protected if all memory and swap space is exhausted. FreeBSD users may wish to protect the **DPS8M** process to avoid unexpected termination of the simulator in low memory situations.

The system decides which processes to terminate based on a large number of factors and heuristics which vary from release to release, but include process priority, memory usage, resource consumption, interactive vs. non-interactive status, and most importantly, the setting of the process ‘`protect`’ flag.

Users running the simulator on FreeBSD in production environments should set the ‘`protect`’ flag for the simulator process using the “`protect(1)`” utility.

- To set the ‘protect’ flag for all running “dps8” processes, use the following shell command (as *root*):

```
pgrep dps8 | xargs protect -p
```

- For more information on the “protect(1)” utility, see the FreeBSD *man* pages (i.e. ‘*man protect*’).

Automatic FreeBSD OOM protection

If you want to automate the process of setting the ‘protect’ flag each time the simulator starts, you can do so using “*sudo*” and a shell script. These instructions assume your user is member of the “wheel” group.

1. First, install and configure the “*sudo*” package (as *root*):

```
pkg install sudo
```

- Run “*visudo -f /usr/local/etc/sudoers.d/0000-wheel*” (as *root*) and add the following line to enable “*sudo*” for the “wheel” group:

```
%wheel ALL=(ALL) ALL
```

2. Create the file “*/usr/local/sbin/dps8-oom*” containing the “*dps8-oom-fbsd*” script. This script is available from “<https://gitlab.com/dps8m/misc-scripts/-/raw/master/dps8-oom-fbsd>”:

```
sudo fetch https://gitlab.com/dps8m/misc-scripts/-/raw/master/dps8-oom-fbsd \
-o /usr/local/sbin/dps8-oom
```

3. Ensure the script has secure ownership and proper permissions:

```
sudo chown root:wheel /usr/local/sbin/dps8-oom
sudo chmod 755 /usr/local/sbin/dps8-oom
```

4. Run “*sudo visudo -f /usr/local/etc/sudoers.d/9999-dps8-oom*” and add the following line:

```
username ALL=(ALL) NOPASSWD: /usr/local/sbin/dps8-oom
```

- You should replace “*username*” in the text above with the actual name of the user that runs the simulator. If you want to allow all users of a particular group to run the script, prefix the group name with the “%” symbol (i.e. “%wheel”).

5. Finally, at the top of your simulator script (*INI* file), add the following line:

```
! sudo /usr/local/sbin/dps8-oom
```

- You will see a message similar to the following when the “*dps8-oom*” script is called from the simulator:

```
PID 55290 protected successfully.
```

NOTE: If “*sudo*” asks for a password to run the script (executed via the full absolute path) even after the above configuration you should examine the output of “*sudo -l*” to review your rule ordering, and ensure that the entry for “*dps8-oom*” appears *after* any generic “(ALL)ALL” or similar entries. See the “*sudo*” documentation for further details.

Legal

DPS8M Omnibus Documentation Licensing Terms

DPS8M Omnibus Documentation-specific Content Licensing

- The *complete* **DPS8M Omnibus Documentation** (“*this documentation*”) is licensed under the terms of the **General Attribution License**.
- **Third-party content** *within* this documentation is copyrighted by their respective owners and licensed as indicated in the following disclosures.

General Attribution License (Documentation)

General Attribution License

- Copyright © 2019-2025 **The DPS8M Development Team**

This work is provided “AS IS”, without any express or implied warranties, including but not limited to the implied warranties of merchantability and fitness for a particular purpose. In no event will the authors or contributors be held liable for any direct, indirect, incidental, special, exemplary, or consequential damages however caused and on any theory of liability, whether in contract, strict liability, or tort (including negligence or otherwise), arising in any way out of the use of this work, even if advised of the possibility of such damage.

Permission is granted to anyone to use this work for any purpose, including commercial applications, and to alter and distribute it freely in any form, provided that the following conditions are met:

1. The origin of this work must not be misrepresented; you must not claim that you authored the original work. If you use this work in a product, an acknowledgment in the product documentation would be appreciated but is not required.
2. Altered versions in any form may not be misrepresented as being the original work, and neither the name of **The DPS8M Development Team** nor the names of authors or contributors may be used to endorse or promote products derived from this work without specific prior written permission.
3. The text of this notice must be included, unaltered, with any distribution.

Multics License (Documentation)

This documentation may adapt, include, and/or incorporate **Multics** program code and/or documentation, which is distributed under the **Multics License**.

Multics License

- Copyright © 1972 **The Massachusetts Institute of Technology**
- Copyright © 1972 **Honeywell Information Systems, Inc.**
- Copyright © 2006 **Bull HN Information Systems, Inc.**
- Copyright © 2006 **Bull SAS**

All rights reserved.

- This edition of the **Multics** software materials and documentation is provided and donated to **The Massachusetts Institute of Technology** by **Group BULL** including **BULL HN Information Systems, Inc.** as a contribution to computer science knowledge.
- This donation is made also to give evidence of the common contributions of **The Massachusetts Institute of Technology, Bell Laboratories, General Electric, Honeywell Information Systems, Inc., Honeywell BULL, Inc., Groupe BULL** and **BULL HN Information Systems, Inc.** to the development of this operating system.
- **Multics** development was initiated by **The Massachusetts Institute of Technology Project MAC** (1963-1970), renamed the **MIT Laboratory for Computer Science and Artificial Intelligence** in the mid 1970s, under the leadership of *Professor Fernando José Corbató*. Users consider that **Multics** provided the best software architecture for managing computer hardware properly and for executing programs. Many subsequent operating systems incorporated **Multics** principles.
- **Multics** was distributed in 1975 to 2000 by **Group Bull** in Europe, and in the U.S. by **Bull HN Information Systems, Inc.**, as successor in interest by change in name only to **Honeywell Bull, Inc.** and **Honeywell Information Systems, Inc.**

Permission to use, copy, modify, and distribute these programs and their documentation for any purpose and without fee is hereby granted, provided that this copyright notice and the above historical background appear in all copies and that both the copyright notice and historical background and this permission notice appear in supporting documentation, and that the names of MIT, HIS, BULL, or BULL HN not be used in advertising or publicity pertaining to distribution of the programs without specific prior written permission.

General Attribution License (Multics Rings Logo)

This documentation may adapt, include, and/or incorporate the **Multics Rings Logo**, a stylized rendering of concentric rings, representing the logical structure of the protection domains designed specifically for the Multics operating system.

The stylized rendering and the Adobe® PostScript™ code used to produce it were created by **Stanley R. Zanarotti** and distributed under the **General Attribution License**.

- The **Multics Rings Logo** used herein has been altered for use in this documentation by **The DPS8M Development Team**.

Multics Rings Logo License

- Copyright © 1984-2021 **Stanley R. Zanarotti** <srz@mit.edu>
- Copyright © 2021-2025 **The DPS8M Development Team**

This work is provided “AS IS”, without any express or implied warranties, including but not limited to the implied warranties of merchantability and fitness for a particular purpose. In no event will the authors or contributors be held liable for any direct, indirect, incidental, special, exemplary, or consequential damages however caused and on any theory of liability, whether in contract, strict liability, or tort (including negligence or otherwise), arising in any way out of the use of this work, even if advised of the possibility of such damage.

Permission is granted to anyone to use this work for any purpose, including commercial applications, and to alter and distribute it freely in any form, provided that the following conditions are met:

1. The origin of this work must not be misrepresented; you must not claim that you authored the original work. If you use this work in a product, an acknowledgment in the product documentation would be appreciated but is not required.
2. Altered versions in any form may not be misrepresented as being the original work, and neither the name of **Stanley R. Zanarotti** nor the names of authors or contributors may be used to endorse or promote products derived from this work without specific prior written permission.
3. The text of this notice must be included, unaltered, with any distribution.

BSD License (Eisvogel)

This documentation may adapt, include, and/or incorporate **Eisvogel**, a LaTeX template for *pandoc*, which is distributed under a three-clause BSD license.

Eisvogel License

- Copyright © 2017-2021 **Pascal Wagler**
- Copyright © 2014-2021 **John MacFarlane**

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. Neither the name of **John MacFarlane** nor the names of other contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS “AS IS” AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT OWNER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

ISC License (Pagebreak)

This documentation may adapt, include, and/or incorporate **Pagebreak**, a Lua filter for *pandoc*, which is distributed under the **ISC License**.

ISC License

- Copyright © 2017-2021 **Benct Philip Jonsson**
- Copyright © 2017-2021 **Albert Krewinkel**

Permission to use, copy, modify, and/or distribute this software for any purpose with or without fee is hereby granted, provided that the above copyright notice and this permission notice appear in all copies.

THE SOFTWARE IS PROVIDED “AS IS” AND THE AUTHOR DISCLAIMS ALL WARRANTIES WITH REGARD TO THIS SOFTWARE INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS. IN NO EVENT SHALL THE AUTHOR BE LIABLE FOR ANY SPECIAL, DIRECT, INDIRECT, OR CONSEQUENTIAL DAMAGES OR ANY DAMAGES WHATSOEVER RESULTING FROM LOSS OF USE, DATA OR PROFITS, WHETHER IN AN ACTION OF CONTRACT, NEGLIGENCE OR OTHER TORTIOUS ACTION, ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THIS SOFTWARE.

SIL™ Open Font License 1.1 (Source™ Code Pro)

This documentation may embed **Source™ Code Pro**, a font, which is distributed under the **SIL™ Open Font License 1.1**.

SIL™ Open Font License Version 1.1

- Copyright © 2010-2019 **Adobe®** (*adobe.com*), with Reserved Font Name **Source™**. **Source™** is a trademark of Adobe® in the United States and/or other countries. All rights reserved.

PREAMBLE: The goals of the Open Font License (*OFL*) are to stimulate worldwide development of collaborative font projects, to support the font creation efforts of academic and linguistic communities, and to provide a free and open framework in which fonts may be shared and improved in partnership with others. The *OFL* allows the licensed fonts to be used, studied, modified and redistributed freely as long as they are not sold by themselves. The fonts, including any derivative works, can be bundled, embedded, redistributed and/or sold with any software provided that any reserved names are not used by derivative works. The fonts and derivatives, however, cannot be released under any other type of license. The requirement for fonts to remain under this license does not apply to any document created using the fonts or their derivatives.

DEFINITIONS: “Font Software” refers to the set of files released by the Copyright Holder(s) under this license and clearly marked as such. This may include source files, build scripts and documentation. “Reserved Font Name” refers to any names specified as such after the copyright statement(s). “Original Version” refers to the collection of Font Software components as distributed by the Copyright Holder(s). “Modified Version” refers to any derivative made by adding to, deleting, or substituting – in part or in whole – any of the components of the Original Version, by changing formats or by porting the Font Software to a new environment. “Author” refers to any designer, engineer, programmer, technical writer or other person who contributed to the Font Software.

PERMISSION & CONDITIONS: Permission is hereby granted, free of charge, to any person obtaining a copy of the Font Software, to use, study, copy, merge, embed, modify, redistribute, and sell modified and unmodified copies of the Font Software, subject to the following conditions:

1. Neither the Font Software nor any of its individual components, in Original or Modified Versions, may be sold by itself.
2. Original or Modified Versions of the Font Software may be bundled, redistributed and/or sold with any software, provided that each copy contains the above copyright notice and this license. These can be included either as stand-alone text files, human-readable headers or in the appropriate machine-readable metadata fields within text or binary files as long as those fields can be easily viewed by the user.
3. No Modified Version of the Font Software may use the Reserved Font Name(s) unless explicit written permission is granted by the corresponding Copyright Holder. This restriction only applies to the primary font name as presented to the users.
4. The name(s) of the Copyright Holder(s) or the Author(s) of the Font Software shall not be used to promote, endorse or advertise any Modified Version, except to acknowledge the contribution(s) of the Copyright Holder(s) and the Author(s) or with their explicit written permission.
5. The Font Software, modified or unmodified, in part or in whole, must be distributed entirely under this license, and must not be distributed under any other license. The requirement for fonts to remain under this license does not apply to any document created using the Font Software.

TERMINATION: This license becomes null and void if any of the above conditions are not met.

DISCLAIMER: THE FONT SOFTWARE IS PROVIDED “AS IS”, WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OF COPYRIGHT, PATENT, TRADEMARK, OR OTHER RIGHT. IN NO EVENT SHALL THE COPYRIGHT HOLDER BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, INCLUDING ANY GENERAL, SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF THE USE OR INABILITY TO USE THE FONT SOFTWARE OR FROM OTHER DEALINGS IN THE FONT SOFTWARE.

SIL™ Open Font License 1.1 (Source™ Sans Pro)

This documentation may embed **Source™ Sans Pro**, a font, which is distributed under the **SIL™ Open Font License 1.1**.

SIL™ Open Font License Version 1.1

- Copyright © 2010-2020 **Adobe®** (*adobe.com*), with Reserved Font Name **Source™**. **Source™** is a trademark of Adobe® in the United States and/or other countries. All rights reserved.

PREAMBLE: The goals of the Open Font License (*OFL*) are to stimulate worldwide development of collaborative font projects, to support the font creation efforts of academic and linguistic communities, and to provide a free and open framework in which fonts may be shared and improved in partnership with others. The *OFL* allows the licensed fonts to be used, studied, modified and redistributed freely as long as they are not sold by themselves. The fonts, including any derivative works, can be bundled, embedded, redistributed and/or sold with any software provided that any reserved names are not used by derivative works. The fonts and derivatives, however, cannot be released under any other type of license. The requirement for fonts to remain under this license does not apply to any document created using the fonts or their derivatives.

DEFINITIONS: “Font Software” refers to the set of files released by the Copyright Holder(s) under this license and clearly marked as such. This may include source files, build scripts and documentation. “Reserved Font Name” refers to any names specified as such after the copyright statement(s). “Original Version” refers to the collection of Font Software components as distributed by the Copyright Holder(s). “Modified Version” refers to any derivative made by adding to, deleting, or substituting – in part or in whole – any of the components of the Original Version, by changing formats or by porting the Font Software to a new environment. “Author” refers to any designer, engineer, programmer, technical writer or other person who contributed to the Font Software.

PERMISSION & CONDITIONS: Permission is hereby granted, free of charge, to any person obtaining a copy of the Font Software, to use, study, copy, merge, embed, modify, redistribute, and sell modified and unmodified copies of the Font Software, subject to the following conditions:

1. Neither the Font Software nor any of its individual components, in Original or Modified Versions, may be sold by itself.
2. Original or Modified Versions of the Font Software may be bundled, redistributed and/or sold with any software, provided that each copy contains the above copyright notice and this license. These can be included either as stand-alone text files, human-readable headers or in the appropriate machine-readable metadata fields within text or binary files as long as those fields can be easily viewed by the user.
3. No Modified Version of the Font Software may use the Reserved Font Name(s) unless explicit written permission is granted by the corresponding Copyright Holder. This restriction only applies to the primary font name as presented to the users.
4. The name(s) of the Copyright Holder(s) or the Author(s) of the Font Software shall not be used to promote, endorse or advertise any Modified Version, except to acknowledge the contribution(s) of the Copyright Holder(s) and the Author(s) or with their explicit written permission.
5. The Font Software, modified or unmodified, in part or in whole, must be distributed entirely under this license, and must not be distributed under any other license. The requirement for fonts to remain under this license does not apply to any document created using the Font Software.

TERMINATION: This license becomes null and void if any of the above conditions are not met.

DISCLAIMER: THE FONT SOFTWARE IS PROVIDED “AS IS”, WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OF COPYRIGHT, PATENT, TRADEMARK, OR OTHER RIGHT. IN NO EVENT SHALL THE COPYRIGHT HOLDER BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, INCLUDING ANY GENERAL, SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF THE USE OR INABILITY TO USE THE FONT SOFTWARE OR FROM OTHER DEALINGS IN THE FONT SOFTWARE.

DPS8M Software Licensing Terms

DPS8M Simulator

ICU License (DPS8M Simulator)

- The **DPS8M Simulator** (“**DPS8M**”) is distributed under the **ICU License**.

COPYRIGHT AND PERMISSION NOTICE

- Copyright © 2006-2025 **Michael Mondy, Harry Reed, Charles Anthony**, and others
- Copyright © 2012 **Dave Jordan**
- Copyright © 2015-2016 **Craig Ruff**
- Copyright © 2015-2023 **Eric Swenson**
- Copyright © 2016 **Jean-Michel Merliot**
- Copyright © 2017-2025 **Jeffrey H. Johnson**
- Copyright © 2018-2021 **Juergen Weiss**
- Copyright © 2021 **Dean S. Anderson**
- Copyright © 2023 **Björn Victor**
- Copyright © 2021-2025 **The DPS8M Development Team**

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the “Software”), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, provided that the above copyright notice(s) and this permission notice appear in all copies of the Software and that both the above copyright notice(s) and this permission notice appear in supporting documentation.

THE SOFTWARE IS PROVIDED “AS IS”, WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OF THIRD PARTY RIGHTS. IN NO EVENT SHALL THE COPYRIGHT HOLDER OR HOLDERS INCLUDED IN THIS NOTICE BE LIABLE FOR ANY CLAIM, OR ANY SPECIAL INDIRECT OR CONSEQUENTIAL DAMAGES, OR ANY DAMAGES WHATSOEVER RESULTING FROM LOSS OF USE, DATA OR PROFITS, WHETHER IN AN ACTION OF CONTRACT, NEGLIGENCE OR OTHER TORTIOUS ACTION, ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THIS SOFTWARE.

Except as contained in this notice, the name of a copyright holder shall not be used in advertising or otherwise to promote the sale, use or other dealings in this Software without prior written authorization of the copyright holder.

Multics License (Simulator Code Comments)

- The **DPS8M Simulator** (“**DPS8M**”) **source code** may contain **code comments** that adapt, include, and/or incorporate Multics program code and/or documentation distributed under the **Multics License**.
- In the event of any discrepancy between the source code comments and the original Multics materials, the original Multics materials should be considered authoritative unless otherwise noted.
- The **Multics License** covers **only** the simulator’s source code comments, and **is not** applicable to compiled object code or binary distributions of the simulator.

Multics License

- Copyright © 1972 **The Massachusetts Institute of Technology**
- Copyright © 1972 **Honeywell Information Systems, Inc.**
- Copyright © 2006 **Bull HN Information Systems, Inc.**
- Copyright © 2006 **Bull SAS**

All rights reserved.

- This edition of the **Multics** software materials and documentation is provided and donated to **The Massachusetts Institute of Technology** by **Group BULL** including **BULL HN Information Systems, Inc.** as a contribution to computer science knowledge.
- This donation is made also to give evidence of the common contributions of **The Massachusetts Institute of Technology, Bell Laboratories, General Electric, Honeywell Information Systems, Inc., Honeywell BULL, Inc., Groupe BULL** and **BULL HN Information Systems, Inc.** to the development of this operating system.
- **Multics** development was initiated by **The Massachusetts Institute of Technology Project MAC** (1963-1970), renamed the **MIT Laboratory for Computer Science and Artificial Intelligence** in the mid 1970s, under the leadership of *Professor Fernando José Corbató*. Users consider that **Multics** provided the best software architecture for managing computer hardware properly and for executing programs. Many subsequent operating systems incorporated **Multics** principles.
- **Multics** was distributed in 1975 to 2000 by **Group Bull** in Europe, and in the U.S. by **Bull HN Information Systems, Inc.**, as successor in interest by change in name only to **Honeywell Bull, Inc.** and **Honeywell Information Systems, Inc.**

Permission to use, copy, modify, and distribute these programs and their documentation for any purpose and without fee is hereby granted, provided that this copyright notice and the above historical background appear in all copies and that both the copyright notice and historical background and this permission notice appear in supporting documentation, and that the names of MIT, HIS, BULL, or BULL HN not be used in advertising or publicity pertaining to distribution of the programs without specific prior written permission.

Third-party Software

- **DPS8M** may incorporate, adapt, or utilize software from third-parties.
- Third-party software is copyrighted by their respective owners and licensed as indicated in the following disclosures.

libsir

- **libsir** is a cross-platform, thread-safe logging and utility library written in C (ISO/IEC 9899:2011 C11) that is designed to simplify and streamline the generation and distribution of human-readable information in software. It is developed by **Ryan M. Lederman** and **Jeffrey H. Johnson** and is distributed under the terms of the **MIT License**.

libsir License

- Copyright © 2018-2025 Ryan M. Lederman <lederman@gmail.com>
- Copyright © 2018-2025 Jeffrey H. Johnson <trnsz@pobox.com>

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the “Software”), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

- The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED “AS IS”, WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

libuv

- **libuv** is a portable high-performance platform support library, with a focus on asynchronous-I/O based on event loops, originally developed by **Ben Noordhuis** to support the *Node.js*® runtime. It is distributed under the terms of the **MIT License**.

libuv License

- Copyright © 2015-present **libuv project contributors**.

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the “Software”), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

- The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED “AS IS”, WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

UDPLib

- **UDPLib** is a library that implements the BBN ARPAnet IMP/TIP Modem/Host Interface over UDP. It is derived from code written by **Robert Armstrong**, and is distributed under the terms of the following **MIT license**.

UDPLib License

- Copyright © 2013 **Robert Armstrong** <bob@jfc1.com>
- Copyright © 2015-2016 **Charles Anthony**
- Copyright © 2021-2025 **The DPS8M Development Team**

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the “Software”), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

- The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED “AS IS”, WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL ROBERT ARMSTRONG BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

Except as contained in this notice, the name of **Robert Armstrong** shall not be used in advertising or otherwise to promote the sale, use or other dealings in this Software without prior written authorization from **Robert Armstrong**.

Open SIMH

- **Open SIMH** is a portable systems simulation framework, written by **Robert M. Supnik** and others, and distributed under the terms of the following **MIT-style license**.

Open SIMH License

Original code published in 1993-2023, written by Robert M. Supnik.

- Copyright © 1993-2023 **Robert M. Supnik**
- Copyright © 2002-2007 **David T. Hittner**
- Copyright © 2005-2016 **Richard Cornwell**
- Copyright © 2006-2023 **The DPS8M Development Team**
- Copyright © 2007-2008 **Howard M. Harte**
- Copyright © 2008-2009 **J. David Bryan**
- Copyright © 2011-2013 **Matt Burke**
- Copyright © 2011-2015 **Mark Pizzolato**
- Copyright © 2013 **Timothe Litt**

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the “Software”), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

- The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED “AS IS”, WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHOR BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

Except as contained in this notice, the names of the authors shall not be used in advertising or otherwise to promote the sale, use or other dealings in this Software without prior written authorization from the authors.

punutil

- **punutil** is a utility to process the output of the **DPS8M** punch device. It was written by **Dean S. Anderson** of **The DPS8M Development Team** and is distributed under the **ICU License**.

COPYRIGHT AND PERMISSION NOTICE

- Copyright © 2021-2025 **The DPS8M Development Team**

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the “Software”), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, provided that the above copyright notice(s) and this permission notice appear in all copies of the Software and that both the above copyright notice(s) and this permission notice appear in supporting documentation.

THE SOFTWARE IS PROVIDED “AS IS”, WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OF THIRD PARTY RIGHTS. IN NO EVENT SHALL THE COPYRIGHT HOLDER OR HOLDERS INCLUDED IN THIS NOTICE BE LIABLE FOR ANY CLAIM, OR ANY SPECIAL INDIRECT OR CONSEQUENTIAL DAMAGES, OR ANY DAMAGES WHATSOEVER RESULTING FROM LOSS OF USE, DATA OR PROFITS, WHETHER IN AN ACTION OF CONTRACT, NEGLIGENCE OR OTHER TORTIOUS ACTION, ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THIS SOFTWARE.

Except as contained in this notice, the name of a copyright holder shall not be used in advertising or otherwise to promote the sale, use or other dealings in this Software without prior written authorization of the copyright holder.

tap2raw

- **tap2raw** is a utility to convert the `tap` output of the simulated **DPS8M** tape devices to `raw` format. It was written by **Jeffrey H. Johnson** and distributed under the terms of the **MIT No Attribution License (MIT-0)**.
- Copyright © 2024-2025 **Jeffrey H. Johnson** <trnsz@pobox.com>
- Copyright © 2024-2025 **The DPS8M Development Team**

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the “Software”), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so.

THE SOFTWARE IS PROVIDED “AS IS”, WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

prt2pdf

- **prt2pdf** is a utility to convert the output of the simulated **DPS8M** line printer device to ISO 32000 Portable Document Format (*PDF*), and is distributed under the **ICU License**. It is derived from **Txt2PDF**, a utility to transform ASCII text files to Adobe Acrobat PDF documents written by **P. G. Womack**.

COPYRIGHT AND PERMISSION NOTICE

- Copyright © 1998 **P. G. Womack, Diss, Norfolk, UK**.
- Copyright © 2013-2016 **Charles Anthony** <charles.unix.pro@gmail.com>
- Copyright © 2006 **John S. Urban, USA**. <urbanjost@comcast.net>
- Copyright © 2021-2025 **The DPS8M Development Team**

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the “Software”), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, provided that the above copyright notice(s) and this permission notice appear in all copies of the Software and that both the above copyright notice(s) and this permission notice appear in supporting documentation.

THE SOFTWARE IS PROVIDED “AS IS”, WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OF THIRD PARTY RIGHTS. IN NO EVENT SHALL THE COPYRIGHT HOLDER OR HOLDERS INCLUDED IN THIS NOTICE BE LIABLE FOR ANY CLAIM, OR ANY SPECIAL INDIRECT OR CONSEQUENTIAL DAMAGES, OR ANY DAMAGES WHATSOEVER RESULTING FROM LOSS OF USE, DATA OR PROFITS, WHETHER IN AN ACTION OF CONTRACT, NEGLIGENCE OR OTHER TORTIOUS ACTION, ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THIS SOFTWARE.

Except as contained in this notice, the name of a copyright holder shall not be used in advertising or otherwise to promote the sale, use or other dealings in this Software without prior written authorization of the copyright holder.

decNumber

- **decNumber** is an *ANSI C* reference implementation of the *IBM General Decimal Arithmetic* standard, implementing the decimal floating-point arithmetic and encoding formats described by the (*revised*) IEEE 754 specification. It was written by *IBM* and *IEEE* Fellow **Mike Cowlshaw**, with contributions by **Matthew Hagerty**, **John Matzka**, **Klaus Kretzschmar**, **Stefan Krahl**, and **The DPS8M Development Team**. It is distributed under the terms of the **ICU License**.

COPYRIGHT AND PERMISSION NOTICE

- Copyright © 1995-2010 **International Business Machines Corporation** and others

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the “Software”), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, provided that the above copyright notice(s) and this permission notice appear in all copies of the Software and that both the above copyright notice(s) and this permission notice appear in supporting documentation.

THE SOFTWARE IS PROVIDED “AS IS”, WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OF THIRD PARTY RIGHTS. IN NO EVENT SHALL THE COPYRIGHT HOLDER OR HOLDERS INCLUDED IN THIS NOTICE BE LIABLE FOR ANY CLAIM, OR ANY SPECIAL INDIRECT OR CONSEQUENTIAL DAMAGES, OR ANY DAMAGES WHATSOEVER RESULTING FROM LOSS OF USE, DATA OR PROFITS, WHETHER IN AN ACTION OF CONTRACT, NEGLIGENCE OR OTHER TORTIOUS ACTION, ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THIS SOFTWARE.

Except as contained in this notice, the name of a copyright holder shall not be used in advertising or otherwise to promote the sale, use or other dealings in this Software without prior written authorization of the copyright holder.

LibTELNET

- **LibTELNET** is an implementation of the protocol specified by the Network Working Group of the Internet Engineering Task Force, as described in RFC-854, RFC-855, RFC-1091, RFC-1143, RFC-1408, and RFC-1572 — the TELNET protocol and the Q method for TELNET protocol option negotiation — written by **Sean Middleditch** and other contributors.

- **LibTELNET Redistribution Terms**
 - **LibTELNET** has been identified by **The DPS8M Development Team** as being free of known restrictions under copyright law, including all related and neighboring rights.
 - **The DPS8M Development Team** makes no warranties about **LibTELNET**, and disclaims liability for all uses of **LibTELNET** to the fullest extent permitted by applicable law.
 - **The author or authors of this code dedicate any and all copyright interest in this code to the public domain. We make this dedication for the benefit of the public at large and to the detriment of our heirs and successors. We intend this dedication to be an overt act of relinquishment in perpetuity of all present and future rights to this code under copyright law.**

Line History

- **Line History** is a small and self-contained line editor, implementing *Emacs*-style line editing functionality similar to GNU *readline* or BSD *libedit*. It is derived from the *linenose* library written by **Salvatore “antirez” Sanfilippo** and **Pieter Noordhuis** and distributed under a **two-clause BSD license**.

Line History License

- Copyright © 2010-2016 **Salvatore Sanfilippo** <antirez@gmail.com>
- Copyright © 2010-2013 **Pieter Noordhuis** <pcnoordhuis@gmail.com>
- Copyright © 2021-2025 **The DPS8M Development Team**

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS “AS IS” AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

BSD Random

- **BSD Random** is a collection of random number generation functions derived from software originally developed for the *Berkeley Software Distribution* by the *Computer Systems Research Group* at the *University of California, Berkeley*, and copyrighted by *The Regents of the University of California*. It is distributed under a **three-clause BSD license**.

BSD Random License

- Copyright © 1983-1991 **The Regents of the University of California**
- Copyright © 2021-2025 **The DPS8M Development Team**

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. Neither the name of the University nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE REGENTS AND CONTRIBUTORS “AS IS” AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE REGENTS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

musl libc

- **musl libc** is a lightweight and standards conforming implementation of the C standard library, which includes the interfaces defined in the base language standard, POSIX™, and widely agreed-upon extensions. It was written by **Rich “dalias” Felker** and other contributors, and is distributed under the terms of the **MIT License**.

musl libc License

- Copyright © 2005-2020 **Rich Felker**, et al.

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the “Software”), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

- The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED “AS IS”, WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

mcmb

- **mcmb** (*miniature cmb*) is a general-purpose tool for complex combinatorics, derived from the `libcmb` combinatorics library and the `cmb` combinatorics utility developed **Devin Teske**. It is distributed under the terms of a **two-clause BSD license**.

mcmb License

- Copyright © 2002-2019 **Devin Teske** <dteske@FreeBSD.org>
- Copyright © 2020-2025 **Jeffrey H. Johnson** <trnsz@pobox.com>
- Copyright © 2021-2025 **The DPS8M Development Team**

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR AND CONTRIBUTORS “AS IS”, AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Multics Software Materials and Documentation

- **DPS8M** includes some **Multics** software materials and documentation. These materials and documentation are distributed under the terms of the **Multics License**.

Multics License

- Copyright © 1972 **The Massachusetts Institute of Technology**
- Copyright © 1972 **Honeywell Information Systems, Inc.**
- Copyright © 2006 **Bull HN Information Systems, Inc.**
- Copyright © 2006 **Bull SAS**

All rights reserved.

- This edition of the **Multics** software materials and documentation is provided and donated to **The Massachusetts Institute of Technology** by **Group BULL** including **BULL HN Information Systems, Inc.** as a contribution to computer science knowledge.
- This donation is made also to give evidence of the common contributions of **The Massachusetts Institute of Technology, Bell Laboratories, General Electric, Honeywell Information Systems, Inc., Honeywell BULL, Inc., Groupe BULL** and **BULL HN Information Systems, Inc.** to the development of this operating system.
- **Multics** development was initiated by **The Massachusetts Institute of Technology Project MAC** (1963-1970), renamed the **MIT Laboratory for Computer Science and Artificial Intelligence** in the mid 1970s, under the leadership of *Professor Fernando José Corbató*. Users consider that **Multics** provided the best software architecture for managing computer hardware properly and for executing programs. Many subsequent operating systems incorporated **Multics** principles.
- **Multics** was distributed in 1975 to 2000 by **Group Bull** in Europe, and in the U.S. by **Bull HN Information Systems, Inc.**, as successor in interest by change in name only to **Honeywell Bull, Inc.** and **Honeywell Information Systems, Inc.**

Permission to use, copy, modify, and distribute these programs and their documentation for any purpose and without fee is hereby granted, provided that this copyright notice and the above historical background appear in all copies and that both the copyright notice and historical background and this permission notice appear in supporting documentation, and that the names of MIT, HIS, BULL, or BULL HN not be used in advertising or publicity pertaining to distribution of the programs without specific prior written permission.

Scope of Intended Application

- The **DPS8M Simulator** is **not designed or intended** for use in any safety-critical, life-critical, or life-sustaining applications or activities.
 - These applications and activities include, but are not limited to, military, nuclear reactor control, power generation and transmission, factory automation, industrial process control, robotics, avionics, aerospace, air traffic control, emergency communications, railway, marine, motor vehicle, fire suppression, pharmaceutical, medical or safety devices, any conventional, nuclear, biological or chemical weaponry, or any other applications or activities that could reasonably be expected to potentially impact human health and safety or lead to environmental damage.
-

Disclaimer of Liability and Endorsement

- While **The DPS8M Development Team** (“*the Team*”) has expended reasonable efforts to make the information available in this document as accurate as possible, the Team makes no claims, promises, or guarantees regarding accuracy, completeness, or adequacy of any information contained in this document.
- **The DPS8M Development Team** expressly disclaims liability for any errors and omissions in the contents of this document.
- **NO WARRANTY OF ANY KIND**, either express or implied, including but not limited to the warranties of non-infringement, merchantability, or fitness for a particular purpose, is given with respect to the contents of this document or the contents of linked external resources. Linked external resources are not under the control of **The DPS8M Development Team**.
- Any reference in this document to any specific entity, process, or service, or the use of any trade, firm, or corporation name, or any links to external resources are provided for information and convenience purposes only, and in no way constitute endorsement, sponsorship, affiliation, or recommendation by **The DPS8M Development Team**.

